



- 7 If there are other parts to be erased in the same program: select “NEXT” and press [SELECT].



- 8 Select “Erase” using [◀], and press [SELECT].

- The part on the play list created from the deleted part is also deleted.



- 9 Only when “NEXT” was selected in step 7, repeat steps 5 through 8.



■ To stop the erasing process

Press [RETURN].

Notes:


- If more than one START (or END) point has been set, the point which was set last will take effect.
- If the START point comes after the END point, the two points are automatically changed around.
- The START and END points may not be set if they are less than 3 seconds apart.
- Still pictures cannot be partially erased.
- If the erased part is very short, the remaining disc space may not be increased.
- When the end of the program is reached, the pause mode is automatically established.
- Parts of programs which have been write-protected as described on p. 73 cannot be erased.
- To erase the very beginning of a program, press [PAUSE] then [◀◀] and select “START.”

Program erase

A complete program can be erased.


- Proceed after performing steps 1 to 3 on p. 70.

- 4 Select “Erase Program” using [▲] and [▼], and press [SELECT].



- 5 Select “Erase” using [◀], and press [SELECT].

- The part on the play list created from this program is also erased.



Notes:

- Once programs are erased, they can not be restored.
- If the erased program is a short one, the remaining disc space may not be increased.