



- When [SELECT] is pressed, the lock is engaged.




■ Changing the parental controls

3 After performing steps 1 and 2 on p. 108, select “8 Ratings” using [▲] and [▼], and press [SELECT].




4 Only if a level from 7 to 0 had been set: Enter the 4-digit password using the numeric buttons, and press [SELECT].


- Press [CANCEL] if the wrong number has been entered.



- Example where password “1234” has been input



5 Select “Change Password” and press [SELECT]. Enter new password and press [SELECT].



■ 1. Unlock Player

This is for releasing the viewing/listening restriction and returning to the setting to level 8.

- The “The player is now unlocked” message appears on the screen.

■ 2. Change Password

- This enables the password, which was input as described on the previous page, to be changed. Input the new 4-digit password using the numeric buttons, and press [SELECT].

■ 3. Change Level

- This enables the restriction level to be changed. Select the new level using [◀] and [▶], and press [SELECT].


■ 4. Temporary Unlock

- This maintains the lock release (level 8) until the power is turned off or the disc is removed.


2 Video Settings

1. TV Aspect

3 After performing steps 1 and 2 on p. 108, select “1 TV Aspect” using [▲] and [▼], and press [SELECT].



4 Select the item to be set using [▲] and [▼], and press [SELECT].



1 [4:3] (factory setting)

Select this when the unit has been connected to a conventional size TV set (4:3 aspect ratio).

- The disc is played in accordance with “2. TV Mode (4:3)” (see next page).
- Wide-screen disc programs with the pan & scan specification are played on the pan & scan screen (where the left and right edges are cut off).
- Wide-screen disc programs without the pan & scan specification are played on the letter-box screen (where black bands appear at the top and bottom).



2 [16:9]

Select this when the unit has been connected to a wide-screen TV set (16:9 aspect ratio).

- Wide-screen disc programs are played on the full screen. (Set the wide-screen TV screen mode to “full.”)

