

Changing the initial settings


Preparation

- Press [DVD].

1 During stop (TV reception):


Press [ACTION].

- If the  appears on the TV screen, first press [STOP] and then press [ACTION].



2 Select the item to be set using [▲] and [▼], and press [SELECT]. (Refer to page 109)

- Example where “3 Audio Settings” has been selected




■ To return to the previous menu

Press [RETURN].

Note:

Each menu can also be selected using the numeric buttons. Press the number on the left of the items to be selected.



Initial setting items


For further details, read the applicable pages.

① Set Up	110	③ Audio Settings	122
1. On-Screen Display	110	1. Digital Audio Output	122
1. On-Screen Messages	110	1. LPCM96k → 48k	122
2. Color and Position of Menu Bar	110	2. Dolby Digital	123
2. Off Timer	111	3. dts	123
3. Remote Control Code	111	2. D.Range Compression	123
4. FL Display	111	3. Sound Quality	123
5. Blue Background	112	4. Speaker Setting	124
6. Color Picture Recording	112	5. Audio during Search 1	125
7. Disc Languages	113	6. MTS/SAP	126
1. Audio	113	④ Re-initialize Setting (Restoring the factory setting)	127
2. Subtitle	113	⑤ Format Disc	128
3. Menus	113	⑥ Clock Settings	129
8. Ratings	114	1. Auto Clock Setting	129
1. Unlock Player	115	2. Manual Clock Setting	130
2. Change Password	115	3. Time Zone Adjust	131
3. Change Level	115	⑦ Channel Settings	18-20
4. Temporary Unlock	115	1. Antenna System	18
② Video Settings	116	2. Auto Channel Setting	18
1. TV Aspect	116	3. Manual Channel Setting	19
2. TV Mode (4:3)	117	4. Channel Captions	19
1. TV Mode of DVD-Video	117	5. VCR Plus+ CH Setting	20
2. TV Mode of DVD-RAM	117		
3. Component Video Output Setting	117		
4. Progressive Output Setting	118		
1. Transfer Mode	118		
2. Gamma Selection	118		
3. Sharpness (outline correction)	119		
4. 4:3 Output	119		
5. 3-D Y/C Separation	119		
6. Noise Reduction (NR)	120		
1. Block NR	120		
2. Mosquito NR	120		
3. 3-D NR	121		
7. Still Mode	121		
8. Hybrid VBR Resolution	121		



1 Set Up

1. On-Screen Display

3 After performing steps 1 and 2 on p. 108, select “1 On-Screen Display” using [▲] and [▼], and press [SELECT].



4 Select the item to be set using [▲] and [▼], and press [SELECT].



■ 1. On-Screen Messages

1. Automatic (factory setting)

Displayed for just 5 seconds immediately after operation, “PLAY”, the counter display, etc. appear on the TV screen.

2. On

“PLAY”, the counter display, etc. remain on the TV screen at all time.

3. Off

“PLAY”, the counter display, etc. do not appear on the TV screen at any time.

■ 2. Color and Position of Menu Bar

1. Blue (Upper) (factory setting)

2. Violet (Upper)

3. Green (Upper)



Upper: The menu bar is displayed at the top of the TV screen.

4. Blue (Middle)

5. Violet (Middle)

6. Green (Middle)



Middle: The menu bar is displayed slightly lower on the TV screen than with setting 1, 2 and 3.

● Select it if part of the top of the screen is missing when setting 1, 2 or 3 is selected.

Note:

It is useful to move the menu bar when it is blocking an important section of the video image being viewed.