

#### Notes:

- The direct navigator program list can contain up to 99 programs.
- The direct navigator program list is recorded on each disc.
- If a new recording is to be performed when 99 recordings have already been made, the “Maximum amount of programs exceeded” message appears on the TV screen, and the new recording will not be performed. Erase the programs that are no longer needed, and start recording when the number of recorded programs is 98 or less.

#### ■ Direct navigator program items

- ① Program number, recording date, channel, recording start time, program title (only after the title has been entered)**

In the example shown, program No.1 has been selected.

- ② Write-protect**

This appears when the program is write-protected. (p. 73)  
In the example shown, program No.2 is write-protected. Write-protected programs cannot be partially or entirely erased.

- ③ Copy prohibited**

This appears when attempting to record a program (such as a CATV program) whose copying (dubbing) is prohibited.

- ④ Scroll bar**

A general indication of the current position appears when a list containing more than 6 programs is scrolled down using [▼].

- ⑤ Sub menu**

This appears when [▶] is pressed. A number of operations can now be performed: program titles can be entered (or edited), program contents can be checked, write protection can be engaged or released, and programs can be partially or entirely erased.

# Direct navigator program functions

**RAM**

The following operations can be performed using the direct navigator:

1. Enter Title
2. Properties (Displaying information on programs)
3. Set Protection
4. Erase Partially
5. Erase Program

## Preparation


- Press [DVD].
- Insert a pre-recorded disc.

## Initial steps

**1 [Remote control]:** Press [NAVIGATOR].

**[Unit]:** Press [DIRECT NAVIGATOR].

- The program numbers, recording dates, channels and start times of the recorded programs are displayed.
- When the button has been pressed during stop, playback starts and the direct navigator screen appears.




**2** Select the program to be edited using [▲] and [▼].



**3** Press [▶].

- Playback is paused (still picture).



- Direct navigator program functions are displayed.

