

## Program playback

VCD

CD

A sequence of up to 100 tracks can be rearranged and played in the desired sequence.



### Preparation

- Press [DVD].

### 1 During stop:

Press [PLAY MODE] and the program playback screen is displayed.

- Each time this button is pressed, the selected mode changes in the following sequence:



### 2 Press [SELECT].

### 3 Select the track number using [▲] and [▼], and press [SELECT].

- The tracks can also be selected by pressing the numeric buttons.

Refer to the illustration on the left.

### 4 Repeat steps 2 and 3 to program additional tracks.

- Up to 100 tracks can be programmed.

### 5 Press [PLAY].

- Programmed playback starts.

### ■ When program playback ends

Playback stops, and the program playback screen appears.

### ■ Returning to normal playback

1. Press [STOP] twice during programmed playback.
2. Press [PLAY MODE] twice.

- The programming is retained. If play mode is pressed again, the current program input status is displayed.



### ■ Playing the program tracks through again from the start during program playback

1. Press [STOP] twice. (The program playback screen appears.)
2. Press [PLAY].

### ■ Changing the program

On the program playback screen, select the numbers of the tracks to be changed using [◀], [▶], [▲] and [▼], and press [SELECT]. Then perform step 3 in the previous section to select the tracks to be changed.

- When [◀◀] or [▶▶] is pressed, you can toggle through the screens quickly. This function is useful when you have more than 7 tracks programmed.



When "ALL" is selected, all the tracks will be added from here.

- 1 After selecting the track to be cleared using [▲] and [▼], select this using [▶], and press [SELECT].
  - The track can also be erased by pressing [CANCEL].
- 2 To clear all the programs, select this using [▲], [▼], [▶] and press [SELECT].
- 3 The total time for program playback is displayed.
  - The total time for the selected tracks may not correspond exactly with the "Total Time." "Total Time" more accurately reflects the actual play time.

Playback

# Random playback

VCD

CD

Tracks can be automatically played in a random sequence .


## Preparation

- Press [DVD].

## 1 During stop:

Press [PLAY MODE] twice.

- Each time this button is pressed, the selected mode changes in the following sequence:



## 2 Press [PLAY].


- Random play now starts.

## ■ When random playback ends

Playback stops, and the random playback screen is restored.

## ■ To release random playback

1. Press [STOP] twice during random playback.
2. Press [PLAY MODE].



## Operations using the menu bar (overview)

### Menu bar basic operations

RAM

DVD-V

VCD

CD

A number of different operations can be performed using the menu bar by changing the settings and checking the display information.

#### Preparation

- Press [DVD].

#### 1 During playback or stop:

Press [DISPLAY] several times to display the menu bar that is to be operated.

- Each time [DISPLAY] is pressed, the screens are changed as shown on the next page.

#### 2 Select the operation item using [◀] or [▶].

#### 3 Depending on the item that is to be set by [▲] and [▼], press the numeric buttons or [SELECT].

- For details on the operations of each item, refer to p. 40 to p. 51.

#### ■ To clear the menu bar

Press [DISPLAY] several times to clear the display. or press [RETURN].

#### Notes:

- When [DISPLAY] is pressed during stop, playback begins and the menu bar is displayed.
- Some items are not changed until [SELECT] is pressed.
- The Menu bar may not be displayed when playing some kinds of DVD software, or if the television's automatic picture zoom function is on. Change the position of the Menu bar in the initial settings if this occurs (p. 110).
- The color (blue, violet or green) of the Menu bar can be changed (p. 110).

