

Direct navigator disc functions

RAM

The following operations can be performed using the direct navigator:

1. Entering a title to the disc
2. Displaying information on the disc properties
3. Setting write protection on and off for the entire disc
4. Erasing all the recordings

Preparation

- Press [DVD].
- Insert a pre-recorded disc.


Initial steps

1 During playback or stop:

[Remote control]: Press [NAVIGATOR].


[Unit]: Press [DIRECT NAVIGATOR].

- When the button has been pressed during stop, playback starts and the direct navigator screen appears.






2 Press [◀].



- Disc information: The number of recorded programs, total recording time, remaining disc space, disc title (only if the title has been entered) are displayed.



3 Press [▶].

- The direct navigator disc functions are displayed.






1 Disc title

The name of your choice can be entered to a recorded disc.

- Proceed after performing steps 1 to 3 described on the previous page.


4 Select “Enter Title” using [▲] and [▼], and press [SELECT].

- The disc title enter screen displayed below now appears.



5 Enter the title of the disc using [◀], [▲], [▶] and [▼] to select characters and press [SELECT].

- Character input procedure (p. 87)



6 When all characters have been entered:

Select the “SET” icon using [◀], [▲], [▶] and [▼], and press [SELECT].

