

Timer Recording

This function lets you program the DVD Video Recorder for unattended automatic recording of desired TV programs. You can program timer recordings in two different ways:

- (1) By entering the VCR Plus+ PlusCode published alongside the TV program listings in newspapers and magazines (explained below); or
- (2) By entering the necessary information with the remote control while viewing the Menu Display on the TV screen (see p. 64).

This DVD Video Recorder lets you program up to 8 TV programs (including weekly and daily programs) for unattended recording up to one month in advance.

Programming with the VCR Plus+ Function


The VCR Plus+ PlusCodes (numbers) assigned to each TV program and published alongside the TV program listings in newspapers and magazines make it extremely easy to set the DVD Video Recorder for timer recording.

The duration of a timer recording programmed with VCR Plus+ PlusCode may be slightly longer than the actual duration of the TV program.

Preparation

- Press [DVD].
- Check that the time showing on the unit is the correct time.
- Insert a disc that can be recorded on. (Insert a disc which has more time remaining than the length of the timer recording.)


1 Press [PROG] to display the “Program Recording” screen.



2 Select “1 VCR Plus+ Program” using [▲] and [▼].

3 Press [SELECT].


- The “VCR Plus+ Program” screen appears.




4 Press the numeric buttons to enter the PlusCode.

- If you have entered a wrong digit, press [◀] and then enter the correct digit.
- If the message “Invalid entry. Please check number.” appears on the screen, check that the input code is correct and that the channel has been registered.

5 Press [SELECT] to display the program content.



2,3,5,6



4
Numeric
buttons

Pats. 5,307, 173; 5,335,079; 4,908,713; 4,751,578;
and 4,706,121