

Programming the remote control (continued)

Changing the remote control's code

Preparation

- Press [DVD].

■ Setting Remote Control Code 1

Press [DVD] and [1] simultaneously.

■ Setting Remote Control Code 2

Press [DVD] and [2] simultaneously.

■ Setting Remote Control Code 3

Press [DVD] and [3] simultaneously.


Note:

- When no operations can be performed and the display shown below appears in the unit display window, it means that different remote control codes have been set for the unit and for the remote control. Set the same code in the remote control as the code set in the unit.




Unit's remote control
code number

- The displays are shown for about 5 seconds, and then the original status is restored. (This has no adverse effect on the unit or what has been programmed, etc.)



Connecting an external component

This unit can record pictures and sound from a video cassette recorder or video camera connected externally.



Note:


Although the external component is connected to the unit's external input 1 (L1) connector in the example shown above, it can also be connected to its external input 2 (L2) connector on the front panel or its external input 3 (L3) connector on the rear panel.

■ When the external component has a monaural audio output connector

Use the Audio/video cable to connect the component to the external input 2 (L2) connector on the unit's front panel.

- Connect the audio cable to the AUDIO IN L/MONO connector.


- When both composite video (yellow) and S-video cables are connected to the same input connectors (L1 or L2 or L3), the S-video connector has higher priority.
(To view the composite video signal, unplug the S-video cable.)



Dubbing/Editing

Preparation

- Perform the necessary connections.
- Press [DVD].
- Insert a recordable disc into the recorder (this unit).
- Select the recording time (XP, SP or LP) using the recorder (this unit).



1 Press [INPUT SELECT] to select the external component input.

- When the external component has been connected to the unit's external input 1 connector (rear panel): Select "L1."
- When the external component has been connected to the unit's external input 2 connector (front panel): Select "L2."
- When the external component has been connected to the unit's external input 3 connector (rear panel): Select "L3."



When the external input L1 channel has been selected

2 Start playback.

3 At the scene where recording is to start, press [REC].

■ Skipping unnecessary scenes

Press [PAUSE] to skip unnecessary scenes.

- Recording resumes when [PAUSE] is pressed again.

■ Stopping recording

Press [STOP].

■ Recordings where the picture is disrupted and the color deteriorates

Some software on the market (including rental videos) imposes protective safeguards against copying in order to prevent illegal copying.

Signals subject to these protective safeguards cannot be recorded properly. Furthermore, their pictures will be disrupted and their coloring will deteriorate when an attempt is made to view them on a TV screen by passing the signals through the unit.

■ When using the unit as a player.

- Unnecessary characters or displays will no longer appear on the screen when the following selections are made: "1 Set Up" in the Initial Settings → "1 On-Screen Display" → "1 On-Screen Messages" → "3 Off".
- Make the following selections: "2 Video Settings" in the Initial Settings → "6 Noise Reduction (NR)" → "3 3-D NR" → "4 Off".

■ When performing operations near the TV set

When the unit is close to the TV set, noise in the form of black bands may be recorded. If this happens, move the unit as far away from the TV set as possible.

