



7 If there are other scenes to be entered, select “NEXT” and press [SELECT].

- Operation returns to the START point input screen. Now repeat steps 4 through 7.



8 Once all the scenes have been entered, select “EXIT” using [▼], and press [SELECT].



- After the scenes have been registered, the play list guide screen appears.



■ To stop the play list creation midway Press [RETURN].

Notes:

- Up to 99 play lists and up to 999 scenes can be created on one disc. In some cases, the actual numbers will be less than the figures given here.
- If another START (or END) point has been set after a START (or END) point has already been set, the point which was set last will take effect.
- If the START point comes after the END point, the two points are automatically changed around.
- If only the END point has been set without setting the START point, the start of the program concerned will serve as the START point.
- The START and END points will not be set if they are set at the same position.
- Still pictures on other equipment can not be set as scenes.
- When the end of the last program recorded on the disc is reached and the END point has not been designated, pause mode is established.

Playing back play lists

RAM

Preparation

- Press [DVD].
- Insert a disc on which play lists have been created.

1 During stop:

Press [PLAY LIST].

- The play list guide screen now appears.



2 Select the play list to be played back using [▲] and [▼].

- If there are five or more items, keep pressing [▼] to scroll down to the bottom half of the list.



3 Press [SELECT].

- Play list playback screen appears.




4 Select the scene to be played back using [◀], [▶], [▲], [▼].

- Play all is initially highlighted.
- The selected scene is framed.



5 Press [SELECT].

- The selected scene is played back.



■ To play back all the scenes on the play list

- Press [PLAY] after step 2. Alternatively, select “Play All” and press [SELECT] after step 3.

■ To stop playing the scenes midway

- Press [STOP].
- The playback scene selection screen resumes.

■ After scene playback is completed

- The playback scene selection screen resumes.

Note:

As with regular playback, forward (or reverse) skipping, still picture and slow playback operations can also be performed during scene playback.