



Direct navigator disc functions

(continued)


2 Displaying information on disc contents

- Proceed after performing steps 1 to 3 on p. 76.

4 Select “Properties” using [▲] and [▼] and press [SELECT].



- The name of the disc, if one has been entered, the number of programs recorded, total recording time, remaining time and number of markers will be displayed.




Press [SELECT] to clear the display.

3 Setting disc write protection

Disc contents can be write-protected so that they will not be erased by mistake. Write-protection can also be released.

● Proceed after performing steps 1 to 3 on p. 76.


4 Select “Set Protection” using [▲] and [▼] and press [SELECT].



5 Select “Set” using [◀] and press [SELECT].



● The Padlock icon is shown.



■ Releasing the protection which was set for a disc

Repeat above procedure and select “Cancel Protection” in step 5.

● The Padlock icon is now cleared.


Notes:

- Formatting the disc will erase all programs, even if they have been write-protected.
- Record function, marker settings, and Play List function cannot be performed when disc is write-protected.

4 Erasing all of the recordings on a disc


● Proceed after performing steps 1 to 3 on p. 76.

4 Select “Erase All” using [▲] and [▼] and press [SELECT].



5 Select “Erase” using [◀] and press [SELECT].

● All the play lists created are also erased.



Notes:

- Once the disc is erased the contents can not be restored.
- The following message appears if there is a program on a disc which is write-protected: “Cannot erase! Contents of this disc are protected.” To proceed with erasure, release the write protection set for the program or programs. (p. 73)