

Erasing all the programs at once

RAM


All the programs recorded on a disc can be erased at once.

*When all the programs are erased they cannot be restored.


Preparation

- Insert the disc with the recordings to be erased.


- 1 Press [ERASE].
 - The erase screen now appears.



- 2 Select "All" using [◀◀], and press [ERASE] again.



- 3 Press [ERASE] again.



- 4 Select "Yes" using [◀◀], and press [ERASE] again.

- The play list created from the programs will also be erased.




- After "Yes" has been selected and [ERASE] pressed in step 4, all contents on the disc will be erased.

Using the remote control to erase programs

Use the direct navigator. For details, refer to p. 79.

Notes:

- Programs cannot be erased when the write-protect tab is set to PROTECT (p. 7) or if the disc or program has been protected with the direct navigator. (p.73 and 79)
- Erasing programs is not possible during playback.



Erasing recorded programs

(continued)

When the disc becomes full (remaining time = 0:00), recording will no longer be possible. If the [REC] is pressed, the erase list screen will appear to enable you to erase any unnecessary programs among the previous recordings or the contents of the whole disc to be erased.



Erasing programs one at a time with the erase list

Preparation


- Press [DVD].

RAM


- 1 If the record button is pressed and the screen shown in the figure below appears, select "Yes" using [◀], and press [SELECT] to display the erase list



- The erase list screen now appears.




- 2 Select the program to be erased using [▲] and [▼], and press [SELECT].



- 3 Select "Yes" using [◀], and press [SELECT].

- The play list created from this program will also be erased.



Hint:

- If there are no programs on the list that can be erased, use a different disc to proceed with your recording.