



















Display (operation item)	What is selected or executed	Operation method																		
	<b>Title number</b> (DVD-Video) <b>Track number</b> (Video CD, CD)	 Use [▲] and [▼] to select, and press [SELECT].																		
	<b>Chapter number</b> (DVD-Video only)	 Use [▲] and [▼] to select, and press [SELECT].																		
 1:56.37	<b>Time</b> Play time direct access. (DVD-Video only)	 Press the numeric buttons, and press [SELECT]. Example: 1 hour 2 minutes 30 seconds 1 → 0 → 2 → 3 → 0 																		
	<b>Play time display mode</b> Elapsed time (DVD-Video only) Elapsed time of track → Track remaining time → Disc remaining time (Only for video CDs and CDs when menu play is OFF)	 Use [▲] and [▼] to make the selection.																		
(Example 1)  (Example 2) 	<b>Audio number</b> (DVD-Video only) <b>a Audio number</b> <b>b Audio attribute</b> LPCM (linear PCM) 2 channels □□ (Dolby Digital (AC-3) ) channels 1 to 3/2.1ch* dts (digital theater system) channels 1 to 3/2.1ch* Vocal (DVD karaoke, for solos) --- (OFF) → ON Vocal (DVD karaoke, for duets) --- (OFF) → V1+V2 (Duets) → V1 (vocal 1) → V2 (vocal 2) <b>c Signal data</b> 96k or 48k/16b, 20b or 24 b (where “k” denotes kHz and “b” bit) <b>d Number of audio signal channels</b> <b>e Audio language code</b> <table border="1"> <tr> <td>ENG: English</td> <td>SVE: Swedish</td> <td>CHI: Chinese</td> </tr> <tr> <td>FRA: French</td> <td>NOR: Norwegian</td> <td>KOR: Korean</td> </tr> <tr> <td>DEU: German</td> <td>DAN: Danish</td> <td>MAL: Malay</td> </tr> <tr> <td>ITA: Italian</td> <td>POR: Portuguese</td> <td>VIE: Vietnamese</td> </tr> <tr> <td>ESP: Spanish</td> <td>RUS: Russian</td> <td>THA: Thai</td> </tr> <tr> <td>NLD: Dutch</td> <td>JPN: Japanese</td> <td>*: Others</td> </tr> </table>	ENG: English	SVE: Swedish	CHI: Chinese	FRA: French	NOR: Norwegian	KOR: Korean	DEU: German	DAN: Danish	MAL: Malay	ITA: Italian	POR: Portuguese	VIE: Vietnamese	ESP: Spanish	RUS: Russian	THA: Thai	NLD: Dutch	JPN: Japanese	*: Others	 Use [▲] and [▼] to make the selection.
ENG: English	SVE: Swedish	CHI: Chinese																		
FRA: French	NOR: Norwegian	KOR: Korean																		
DEU: German	DAN: Danish	MAL: Malay																		
ITA: Italian	POR: Portuguese	VIE: Vietnamese																		
ESP: Spanish	RUS: Russian	THA: Thai																		
NLD: Dutch	JPN: Japanese	*: Others																		
	<b>Subtitles</b> (DVD-Video only) <b>a Subtitle language number</b> <b>b Subtitles OFF → ON</b> (Refer to the codes above for “ENG” and other languages.)	 Use [◀] and [▶] to select (a) or (b). Then use [▲] and [▼] to make the selection.																		
	<b>Angle number</b> (DVD-Video only)	 Use [▲] and [▼] to make the selection.																		
	<b>Audio mode</b> (Video CD only) LR (left & right) → L (left) → R (right)	 Use [▲] and [▼] to make the selection.																		
	<b>Menu play</b> (Video CD only) ON/OFF status display	No changes can be made here.																		

- The selection of numbers in the any of the above items can also be performed using the numeric buttons followed by [SELECT].
- With some discs, it may not be possible to implement some of the functions.