








SIGNAL LINES

	: MAIN SIGNAL LINE		: CD SIGNAL LINE		: AM SIGNAL LINE		: PLAYBACK SIGNAL LINE
	: FM OSC SIGNAL LINE		: AM OSC SIGNAL LINE		: FM & AM SIGNALS LINE		: RECORDING SIGNAL LINE
	: FM SIGNAL LINE		: CD-DA (AUDIO/VIDEO) SIGNAL LINE		: AUX SIGNAL LINE		

() Indicates the Pin No. of Right channel.

