

1. Turn the gear of feed screw (TB24) counter-clockwise in order to position the optical pickup in the center.
2. Remove the one screw (YN23) and take out leaf spring (FX67).
3. Lift the feed screw assy (75) and remove the optical pickup (PU1).
4. Remove the feed screw holder (FW52).
5. Remove the screw (JS20) and remove the feed screw assy (FX71).
6. Pull the feed screw assy out of the pickup.

