

(P) :TO POWER TRANSFORMER SECTION  
(R) :TO POWER SUPPLY/RF SECTION  
(S) :TO SYSTEM CONTROL & SERVO SECTION

F


E

D

C

B

A



NOTE:DO NOT USE PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR  
ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

1

2

3

4

5

6

7

8

9