



### CAUTION

THE  MARK INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT. PAY ATTENTION NOT TO RECEIVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE OF THE PRODUCTS.

**HOT**



NOTE : THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE1: WHEN MEASURE THE VOLTAGE OR WAVEFORM ON THE POWER TRANSFORMER CIRCUIT, SET THE GND TERMINAL OF MEASURING POINT AS FOLLOWS. PRIMARY SIDE... 1 SECONDARY SIDE... 2

NOTE2: THE DC VOLTAGE INDICATED IN PRIMARY SIDE IS SHOWN THE VOLTAGE WHEN INPUT AC IS 220V.

NOTE : DO NOT USE ANY PARTS NUMBER SHOWN ON THIS SCHEMATIC  
DIAGRAM FOR ORDERING.  
WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

**NV-FJ620A,NV-FJ620EA**  
**POWER SECTION IN MAIN SCHEMATIC DIAGRAM**