

INPUT CONDITION							VIDEO OUTPUT RESULT							AUDIO OUTPUT RESULT				
POWER	AV2 SELECT	TV/ VTR	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	AV2 PB(H)	RGB SW	VCR IN	VCR OUT	AV1 Out	AV2 Out	RF (C)	AV1 Out Selector	AV2 Out Selector
P.ON	DECODER	VTR	EE	L	NO.TU	L	VCR out	AV1 In	H	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	AV1 In
					C+.TU	L	VCR out	TUN IN	H	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN
						M/H	VCR out	TUN IN	M/H	L	ON	AV2	AV2	AV2 In	TUN	AV2 In	AV2 In	TUN
					AV1	L	VCR out	AV1 In	H	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In
						M/H	VCR out	AV1 In	M/H	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In
					AV2	L	VCR out	AV1 In	H	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In
						M/H	VCR out	AV1 In	M/H	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In
					AV3	L	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In
						M/H	VCR out	AV1 In	M/H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In
					SAT.NO	L	VCR out	AV1 In	H	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In
					SAT.C+	L	VCR out	SAT IN	H	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	SAT
						M/H	VCR out	SAT IN	M/H	L	ON	AV2	AV2	AV2 In	SAT	AV2 In	AV2 In	SAT
				H	NO.TU	L	VCR out	AV1 In	H	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	AV1 In
					C+.TU	L	VCR out	TUN IN	H	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN
						M/H	VCR out	TUN IN	H	L	OFF	AV2	AV2	AV2 In	TUN	AV2 In	AV2 In	TUN
					AV1	L	VCR out	AV1 In	H	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In
					AV2	L	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In
					AV3	L	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In
					SAT.NO	L	VCR out	AV1 In	H	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In
					SAT.C+	L	VCR out	SAT IN	H	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	SAT
						M/H	VCR out	SAT IN	H	L	OFF	AV2	AV2	AV2 In	SAT	AV2 In	AV2 In	SAT
			VV	---	NO.TU	L	VCR out	AV1 In	M/H	L	OFF	TUN	PB	PB	AV1 In	PB	TUN	AV1 In
						M/H	VCR out	AV1 In	M/H	L	OFF	TUN	PB	PB	AV1 In	PB	TUN	AV1 In
					C+.TU	L	VCR out	TUN IN	M/H	L	OFF	TUN	PB	PB	TUN	PB	TUN	TUN
						M/H	VCR out	TUN IN	M/H	L	OFF	AV2	PB	PB	TUN	PB	AV2 In	TUN
					AV1	L	VCR out	AV1 In	M/H	L	OFF	AV1	PB	PB	AV1 In	PB	AV1 In	AV1 In
						M/H	VCR out	AV1 In	M/H	L	OFF	AV2	PB	PB	AV1 In	PB	AV2 In	AV1 In
					AV2	L	VCR out	AV1 In	M/H	L	OFF	AV2	PB	PB	AV1 In	PB	AV2 In	AV1 In
						M/H	VCR out	AV1 In	M/H	L	OFF	AV2	PB	PB	AV1 In	PB	AV2 In	AV1 In
					AV3	L	VCR out	AV1 In	M/H	L	OFF	AV3	PB	PB	AV1 In	PB	AV3 In	AV1 In
						M/H	VCR out	AV1 In	M/H	L	OFF	AV3	PB	PB	AV1 In	PB	AV3 In	AV1 In
					SAT.NO	L	VCR out	AV1 In	M/H	L	OFF	SAT	PB	PB	AV1 In	PB	SAT	AV1 In
						M/H	VCR out	AV1 In	M/H	L	OFF	SAT	PB	PB	AV1 In	PB	SAT	AV1 In
					SAT.C+	L	VCR out	SAT IN	M/H	L	OFF	SAT	PB	PB	SAT	PB	SAT	SAT
						M/H	VCR out	SAT IN	M/H	L	OFF	AV2	PB	PB	SAT	PB	AV2 In	SAT

NOTE: NO.TU: Tuner position, DECODER OFF (e.g. ARD)  
C+.TU: Tuner position, DECODER ON (e.g. PREMI)  
\*[M/H] :In case of Personal Planner standby(not External Link), AV1 PB must not output 'M' or 'H'

RGB SW : OFF = HIGH, ON=LOW  
EE : Non-Playback signal  
VV:Playback signal