

INPUT CONDITION						VIDEO OUTPUT RESULT							AUDIO OUTPUT RESULT								
POWER	AV2 SELECT	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	AV2 PB(H)	RGB SW	VCR IN	VCR OUT	AV1 Out	AV2 Out	RF (C)	AV1 Out Selector	AV2 Out Selector				
P.ON	EXT or TIMER1 or TIMER2	EE	L	TUN	---	VCR out	VCR out	L	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	INSEL				
				AV1	---	VCR out	VCR out	L	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	INSEL				
				AV2	---	VCR out	VCR out	L	L	ON	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	INSEL				
				AV3	---	VCR out	VCR out	L	L	OFF	AV3	AV3	AV3 In	AV3 In	AV3 In	AV3 In	INSEL				
				SAT.TU	---	VCR out	VCR out	L	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL				
			H	TUN	---	VCR out	VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL			
				AV1	---	VCR out	VCR out	H	H	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In	INSEL			
				AV2	---	VCR out	VCR out	H	H	OFF	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	AV2 In	INSEL			
				AV3	---	VCR out	VCR out	H	H	OFF	AV3	AV3	AV3 In	AV3 In	AV3 In	AV3 In	AV3 In	INSEL			
				SAT.TU	---	VCR out	VCR out	H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL				
			VV	---	TUN	---	VCR out	VCR out	M/H	M/H	OFF	TUN	PB	PB	PB	PB	PB	TUN	INSEL		
					AV1	---	VCR out	VCR out	M/H	M/H	OFF	AV1	PB	PB	PB	PB	PB	AV1 In	INSEL		
					AV2	---	VCR out	VCR out	M/H	M/H	OFF	AV2	PB	PB	PB	PB	PB	AV2 In	INSEL		
					AV3	---	VCR out	VCR out	M/H	M/H	OFF	AV3	PB	PB	PB	PB	PB	AV3 In	INSEL		
					SAT.TU	---	VCR out	VCR out	M/H	M/H	OFF	SAT	PB	PB	PB	PB	PB	SAT	INSEL		
	DECODER	EE	L	TUN	L	VCR out	TUN IN	L	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	TUN			
					M/H	VCR out	TUN IN	L	L	ON	AV2	AV2	AV2 In	TUN	AV2 In	AV2 In	AV2 In	TUN			
				AV1	L	VCR out	AV1 In	L	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In			
					M/H	VCR out	AV1 In	L	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV2 In	AV1 In			
				AV2	L	VCR out	AV1 In	L	L	ON	AV2	AV2	AV2 In	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In			
					M/H	VCR out	AV1 In	L	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV2 In	AV1 In			
				AV3	L	VCR out	AV1 In	L	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV3 In	AV1 In			
					M/H	VCR out	AV1 In	L	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV3 In	AV1 In			
				SAT.TU	L	VCR out	SAT IN	L	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	SAT	SAT	SAT		
					M/H	VCR out	SAT IN	L	L	ON	AV2	AV2	AV2 In	SAT	AV2 In	AV2 In	AV2 In	SAT			
				H	TUN	L	VCR out	TUN IN	H	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	TUN	TUN	
						M/H	VCR out	TUN IN	H	L	OFF	AV2	AV2	AV2 In	TUN	AV2 In	AV2 In	AV2 In	TUN		
					AV1	L	VCR out	AV1 In	H	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In		
						M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV2 In	AV1 In		
					AV2	L	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV2 In	AV1 In		
			M/H			VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV2 In	AV1 In			
			AV3		L	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV3 In	AV1 In			
					M/H	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV3 In	AV1 In			
			SAT.TU		L	VCR out	SAT IN	H	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	SAT	SAT	SAT		
					M/H	VCR out	SAT IN	H	L	ON	AV2	AV2	AV2 In	SAT	AV2 In	AV2 In	AV2 In	SAT			
			VV		---	TUN	L	VCR out	TUN IN	M/H	L	OFF	TUN	PB	PB	TUN	PB	TUN	PB	TUN	TUN
							M/H	VCR out	TUN IN	M/H	L	OFF	AV2	PB	PB	TUN	PB	AV2 In	TUN		
						AV1	L	VCR out	AV1 In	M/H	L	OFF	AV1	PB	PB	AV1 In	PB	AV1 In	AV1 In	AV1 In	
							M/H	VCR out	AV1 In	M/H	L	OFF	AV2	PB	PB	AV1 In	PB	AV2 In	AV1 In		
						AV2	L	VCR out	AV1 In	M/H	L	OFF	AV2	PB	PB	AV1 In	PB	AV2 In	AV1 In		
				M/H			VCR out	AV1 In	M/H	L	OFF	AV2	PB	PB	AV1 In	PB	AV2 In	AV1 In			
				AV3		L	VCR out	AV1 In	M/H	L	OFF	AV3	PB	PB	AV1 In	PB	AV3 In	AV1 In			
						M/H	VCR out	AV1 In	M/H	L	OFF	AV3	PB	PB	AV1 In	PB	AV3 In	AV1 In			
				SAT.TU		L	VCR out	SAT IN	M/H	L	OFF	SAT	PB	PB	SAT	PB	SAT	SAT	SAT		
						M/H	VCR out	SAT IN	M/H	L	OFF	AV2	PB	PB	SAT	PB	AV2 In	SAT			

NOTE: RGB SW : OFF = HIGH, ON=LOW

EE : Non-Playback signal

VV:Playback signal

***[M/H] :In case of Personal Planner standby(not External Link), AV1 PB must not output 'M' or 'H'**