


G  
F  
E  
D  
C  
B  
A

TO SYSTEM CONTROL & SERVO  
SECTION 1800(F-20)

TO SYSTEM CONTROL & SERVO  
SECTION 1800(F-22)



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-HS825EG/B/EC  
OSD/SECAM SCHEMATIC DIAGRAM