


← VIDEO SIGNAL PATH ← AUDIO SIGNAL PATH



PK0701

DU7601-19	SW1	1
DU7601-20	SW2	2
DU7601-21		3
DU7601-22	SIF/QPSK	4
DU7601-23	AFC S-CURVE	5
DU7601-24	TUNER VIDEO	6
DU7601-25	TUNER 5V	7
DU7601-26		8
DU7601-27	GND	9

PP0701
(TO TUNER UNIT)

4MHz	1
AGC	2
IF	3
GND	4

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NV-HS830EG/B/EC/EE
TV DEMODULATOR PACK SCHEMATIC DIAGRAM

F
E
D
C
B
A

1 2 3 4 5 6 7 8