


H  
G  
F  
E  
D  
C  
B  
A

VIDEO MAIN SIGNAL PATH IN REC MODE

VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE



P8801	
1	RF CHROMA
2	SECAM DET (H)
3	SECAM REC C
4	V.EE (H)
5	SECAM PB C
6	VIDEO 5V
7	REC CHROMA
8	C SYNC
9	GND (V)
10	FSC
11	GND (V)
12	BW (H)

TO LUMINANCE & CHROMINANCE/  
AUDIO SECTION P3003B-23)

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS ( ) ON THIS DIAGRAM IS RECORD MODE WITH SECAM COLOUR SIGNAL. (SP MODE)  
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH SECAM COLOUR SIGNAL. (SP MODE)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NV-HS830F  
OSD/SECAM SCHEMATIC DIAGRAM

1 2 3 4 5 6 7 8 9 10 11