

G
F
E
D
C
B
A


VIDEO MAIN SIGNAL PATH IN REC MODE
VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

TO LUMINANCE & CHROMINANCE/
AUDIO SECTION (P-P301) (E-23)

PS3301	EE C OUT	1	(A1)
	Y/C C OUT	2	(A2)
	CNR OFF	3	(A3)
	CORR SIGNAL	4	(A4)
	GND (DNR)	5	
	SEP IN	6	
	V BLANK	7	
	C SYNC	8	
	GND (DNR)	9	
	SEP C OUT	10	(A5)
	GND (DNR)	11	
	SEP Y OUT	12	(A6)
	GND (DNR)	13	
	FSC	14	(A7)
	GND (DNR)	15	
	DIGITAL 5V	16	
	MAIN IIC DATA	17	
	MAIN IIC CLOCK	18	

TO LUMINANCE & CHROMINANCE/
AUDIO SECTION (P-P302) (E-23)

PS3302	GND (DNR)	1	(B1)
	VV C OUT	2	
	GND (DNR)	3	
	VV Y OUT	4	(B2)



NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKET () ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL (SP MODE)

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL (SP MODE)

NV-HS870EG/B/EC DNR PACK SCHEMATIC DIAGRAM

1 2 3 4 5 6 7 8 9 10 11