

INPUT CONDITION					VIDEO OUTPUT RESULT									AUDIO OUTPUT RESULT								
POWER	AV2 SELECT	TV/ VTR	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	AV2 PB(H)	RGB SW	VCR IN	VCR OUT	AV1 Out	AV2 Out	RF (C)	AV1 Out Selector	AV2 Out Selector				
P.ON	EXT or TIMER1 or TIMER2	TV	EE	L	NO.TU	---	VCR out	VCR out	L	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL			
					C+.TU	---	VCR out	VCR out	L	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL			
					AV1	---	VCR out	VCR out	L	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	INSEL				
					AV2	---	VCR out	VCR out	L	L	ON	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	INSEL				
					AV3	---	VCR out	VCR out	L	L	OFF	AV3	AV3	AV3 In	AV3 In	AV3 In	AV3 In	INSEL				
					SAT.NO	---	VCR out	VCR out	L	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL				
					SAT.C+	---	VCR out	VCR out	L	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL				
					H	NO.TU	---	VCR out	VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL		
						C+.TU	---	VCR out	VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL		
				AV1		---	VCR out	VCR out	H	H	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	INSEL				
				AV2		---	VCR out	VCR out	H	H	OFF	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	INSEL				
				AV3		---	VCR out	VCR out	H	H	OFF	AV3	AV3	AV3 In	AV3 In	AV3 In	AV3 In	INSEL				
				SAT.NO		---	VCR out	VCR out	H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL				
				SAT.C+		---	VCR out	VCR out	H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL				
				VTR		EE	L	NO.TU	---	VCR out	VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL
								C+.TU	---	VCR out	VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	INSEL	
					AV1			---	VCR out	VCR out	H	H	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	INSEL		
					AV2			L	VCR out	VCR out	H	H	ON	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	INSEL		
	M/H	VCR out	VCR out		M/H			M/H	ON	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	INSEL						
	AV3	---	VCR out		VCR out			H	H	OFF	AV3	AV3	AV3 In	AV3 In	AV3 In	AV3 In	INSEL					
	SAT.NO	---	VCR out		VCR out			H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL					
	SAT.C+	---	VCR out		VCR out			H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL					
	H	NO.TU	---		VCR out			VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL			
		C+.TU	---	VCR out	VCR out	H	H	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN	INSEL						
P.ON		EXT	VTR	EE	H	AV1	---	VCR out	VCR out	H	H	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	INSEL			
						AV2	---	VCR out	VCR out	H	H	OFF	AV2	AV2	AV2 In	AV2 In	AV2 In	AV2 In	INSEL			
						AV3	---	VCR out	VCR out	H	H	OFF	AV3	AV3	AV3 In	AV3 In	AV3 In	AV3 In	INSEL			
						SAT.NO	---	VCR out	VCR out	H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL			
						SAT.C+	---	VCR out	VCR out	H	H	OFF	SAT	SAT	SAT	SAT	SAT	SAT	INSEL			
					VV	---	NO.TU	---	VCR out	VCR out	M/H	M/H	OFF	TUN	PB	PB	PB	PB	PB	TUN	INSEL	
							C+.TU	---	VCR out	VCR out	M/H	M/H	OFF	TUN	PB	PB	PB	PB	PB	TUN	INSEL	
	AV1						---	VCR out	VCR out	M/H	M/H	OFF	AV1	PB	PB	PB	PB	PB	AV1 In	INSEL		
	AV2						---	VCR out	VCR out	M/H	M/H	OFF	AV2	PB	PB	PB	PB	PB	AV2 In	INSEL		
	AV3						---	VCR out	VCR out	M/H	M/H	OFF	AV3	PB	PB	PB	PB	PB	AV3 In	INSEL		
	SAT.NO						---	VCR out	VCR out	M/H	M/H	OFF	SAT	PB	PB	PB	PB	PB	SAT	INSEL		
	SAT.C+						---	VCR out	VCR out	M/H	M/H	OFF	SAT	PB	PB	PB	PB	PB	SAT	INSEL		
DECODER	TV	EE	L	NO.TU	L	VCR out	AV1 In	L	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	AV1 In					
					M/H	AV2 In	AV1 In	M/H	L	ON	TUN	TUN	AV2 In	AV1 In	TUN	AV2 In	AV1 In					
				C+.TU	L	VCR out	TUN IN	L	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN					
					M/H	VCR out	TUN IN	L	L	OFF	AV2	AV2	AV2 In	TUN	AV2 In	AV2 In	TUN					
				AV1	L	VCR out	AV1 In	L	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In					
					M/H	AV2 In	AV1 In	M/H	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In					
				AV2	L	VCR out	AV1 In	L	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In					
					M/H	AV2 In	AV1 In	M/H	L	ON	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In					
				AV3	L	VCR out	AV1 In	L	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In					
					M/H	AV2 In	AV1 In	M/H	L	ON	AV3	AV3	AV2 In	AV1 In	AV3 In	AV2 In	AV1 In					
				SAT.NO	L	VCR out	AV1 In	L	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In					
					M/H	AV2 In	AV1 In	M/H	L	ON	SAT	SAT	AV2 In	AV1 In	SAT	AV2 In	AV1 In					
				SAT.C+	L	VCR out	SAT IN	L	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	TUN					
					M/H	VCR out	SAT IN	L	L	OFF	AV2	AV2	AV2 In	SAT	AV2 In	AV2 In	TUN					
			H	NO.TU	L	VCR out	AV1 In	H	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	TUN	AV1 In				
					M/H	VCR out	AV1 In	H	L	OFF	TUN	TUN	TUN	AV1 In	TUN	TUN	AV1 In					
				C+.TU	L	VCR out	TUN IN	H	L	OFF	TUN	TUN	TUN	TUN	TUN	TUN	TUN					
					M/H	VCR out	TUN IN	H	L	OFF	AV2	AV2	AV2 In	TUN	AV2 In	AV2 In	TUN					
				AV1	L	VCR out	AV1 In	H	L	OFF	AV1	AV1	AV1 In	AV1 In	AV1 In	AV1 In	AV1 In					
					M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In					
				AV2	L	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In					
					M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	AV2 In	AV1 In	AV2 In	AV2 In	AV1 In					
				AV3	L	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In					
					M/H	VCR out	AV1 In	H	L	OFF	AV3	AV3	AV3 In	AV1 In	AV3 In	AV3 In	AV1 In					
				SAT.NO	L	VCR out	AV1 In	H	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In					
					M/H	VCR out	AV1 In	H	L	OFF	SAT	SAT	SAT	AV1 In	SAT	SAT	AV1 In					
				SAT.C+	L	VCR out	SAT IN	H	L	OFF	SAT	SAT	SAT	SAT	SAT	SAT	SAT					
					M/H	VCR out	SAT IN	H	L	ON	AV2	AV2	AV2 In	SAT	AV2 In	AV2 In	SAT					