

INPUT CONDITION						VIDEO OUTPUT RESULT							AUDIO OUTPUT RESULT					
POWER	AV2 SELECT	TV/ VTR	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	AV2 PB(H)	RGB SW	VCR IN	VCR OUT	AV1 Out	AV2 Out	RF (C)	AV1 Out Selector	AV2 Out Selector
OFF	---	---	---	---	---	L	AV2 In	AV1 In	L	L	OFF	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
VPS STAND BY	EXT	---	---	L	NO.TU	L	AV2 In	AV1 In	L	L	OFF	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	or	---	---	L	C+.TU	L	AV2 In	AV1 In	L	L	OFF	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	TIMER1	---	---	L	AV1	L	AV2 In	AV1 In	L	L	OFF	AV1	AV1	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	AV1	AV1	AV2 In	AV1 In	Mute	AV2 In	AV1 In
Personal Planner Standby	or	---	---	L	AV2	L	AV2 In	AV1 In	L	L	OFF	AV2	AV2	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	AV2	AV2	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	TIMER2	---	---	L	AV3	L	AV2 In	AV1 In	L	L	OFF	AV3	AV3	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	AV3	AV3	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	SAT.NO	L	AV2 In	AV1 In	L	L	OFF	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	SAT.C+	L	AV2 In	AV1 In	L	L	OFF	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	*[M/H]	L	ON	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	H	NO.TU	L	VCR out	AV1 In	H	H	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
or	---	---	---	H	C+.TU	L	VCR out	AV1 In	H	H	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
or	---	---	---	H	AV1	L	VCR out	AV1 In	H	H	OFF	AV1	AV1	Mute	Mute	Mute	AV1 In	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	AV1	AV1	Mute	Mute	Mute	AV1 In	AV1 In
or	---	---	---	H	AV2	L	VCR out	AV1 In	H	H	OFF	AV2	AV2	Mute	Mute	Mute	AV2 In	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	AV2	AV2	Mute	Mute	Mute	AV2 In	AV1 In
or	---	---	---	H	AV3	L	VCR out	AV1 In	H	H	OFF	AV3	AV3	Mute	Mute	Mute	AV3 In	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	AV3	AV3	Mute	Mute	Mute	AV3 In	AV1 In
or	---	---	---	H	SAT.NO	L	VCR out	AV1 In	H	H	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
or	---	---	---	H	SAT.C+	L	VCR out	AV1 In	H	H	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
						M/H	VCR out	AV1 In	H	H	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
DECODER	---	---	---	L	NO.TU	L	AV2 In	AV1 In	L	L	OFF	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	C+.TU	L	AV2 In	AV1 In	L	L	OFF	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	TUN	TUN	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	AV1	L	AV2 In	AV1 In	L	L	OFF	AV1	AV1	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	AV2	AV2	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	AV2	L	AV2 In	AV1 In	L	L	OFF	AV2	AV2	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	AV2	AV2	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	AV3	L	AV2 In	AV1 In	L	L	OFF	AV3	AV3	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	AV3	AV3	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	SAT.NO	L	AV2 In	AV1 In	L	L	OFF	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	L	SAT.C+	L	AV2 In	AV1 In	L	L	OFF	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
						M/H	AV2 In	AV1 In	M/H	L	ON	SAT	SAT	AV2 In	AV1 In	Mute	AV2 In	AV1 In
or	---	---	---	H	NO.TU	L	VCR out	AV1 In	H	L	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
or	---	---	---	H	C+.TU	L	VCR out	AV1 In	H	L	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	TUN	TUN	Mute	Mute	Mute	TUN	AV1 In
or	---	---	---	H	AV1	L	VCR out	AV1 In	H	L	OFF	AV1	AV1	Mute	Mute	Mute	AV1 In	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	Mute	Mute	Mute	AV2 In	AV1 In
or	---	---	---	H	AV2	L	VCR out	AV1 In	H	L	OFF	AV2	AV2	Mute	Mute	Mute	AV2 In	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	AV2	AV2	Mute	Mute	Mute	AV2 In	AV1 In
or	---	---	---	H	AV3	L	VCR out	AV1 In	H	L	OFF	AV3	AV3	Mute	Mute	Mute	AV3 In	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	AV3	AV3	Mute	Mute	Mute	AV3 In	AV1 In
or	---	---	---	H	SAT.NO	L	VCR out	AV1 In	H	L	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
or	---	---	---	H	SAT.C+	L	VCR out	AV1 In	H	L	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In
						M/H	VCR out	AV1 In	H	L	OFF	SAT	SAT	Mute	Mute	Mute	SAT	AV1 In