


← VIDEO SIGNAL PATH

← AUDIO SIGNAL PATH

G
F
E
D
C
B
A



PP0701 (TO TUNER)

1
2
3
4

PK0701

DU7801-19	SECAM VL (H)	1
DU7801-20	SECAM (H)	2
DU7801-21	TUNER AUDIO(N)	3
DU7801-22	SIF/OPSK	4
DU7801-23	AFC S-CURVE	5
DU7801-24	TUNER VIDEO	6
DU7801-25	UNREG 5.6V	7
DU7801-26	SW 12V	8
DU7801-27	GND	9

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NV-HS820F
TV DEMODULATOR PACK
SCHEMATIC DIAGRAM

1 2 3 4 5 6 7 8 9