

G

F

E

D

C

B

A

TO SYSTEM CONTROL & SERVO
SECTION P801F(20)TO SYSTEM CONTROL & SERVO
SECTION P804F(20)

1 2 3 4 5 6 7 8 9 10 11

NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR
ORDERING.WHEN YOU ORDER A PART,PLeSE REFER TO PARTS LIST.NV-HS825EE
OSD/SECAM SCHEMATIC DIAGRAM