


Ⓡ : TO POWER SUPPLY/RF SECTION
 Ⓢ : TO SYSTEM CONTROL & SERVO SECTION



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-SJ30AF
 KEY SWITCH & LED DRIVE
 SECTION IN MAIN SCHEMATIC DIAGRAM