


(R) :TO POWER SUPPLY/RF SECTION
(S) :TO SYSTEM CONTROL & SERVO SECTION



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-SJ30AM/EU/PMP,
NV-SJ50AM/AU/EU
KEY SWITCH & LED DRIVE
SECTION IN MAIN SCHEMATIC DIAGRAM