


(P) :TO POWER TRANSFORMER SECTION
(R) :TO POWER SUPPLY/RF SECTION
(S) :TO SYSTEM CONTROL & SERVO SECTION



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.