



The functions of these buttons can be operated by the Remote Control or directly on the unit. In this description, the remote control symbols are used in most cases.

TV Operations

To set the Remote Control code to operate the TV.

	Switch the TV on and off.
	Select TV or AV channel.
	Switch the screen format between the wide screen and other formats.
	Select the TV channel.
	Operate the TV volume.

General Operations

	Standby/on switch Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.
	Menu Operation (indicated by =) These buttons are also used as cursors in order to select items on the menu. next line = , next page =
	Select or Store Operation
	EXIT a menu
	Direct input (indicated by = 1 2 3 ... 10) by pressing numeric buttons
	Clear settings
	Operate REPLAY Function. Press this button while playback.
	Switch the Remote Control to VCR, DVD or TV
	To select the input press this button repeatedly: VCR channel, A1, A2, A3 (front input) or dc (DVD)
	Switch the common output from VCR to DVD or vice versa.

