

VCR Operations

VCR display

	Playback (indicated by = ▷)	
	Stop (indicated by = □) • To stop winding a tape, recording or playback.	
	Still Playback (indicated by = II/▷) • Press this button during playback. • Resume normal playback by pressing this button again or the Playback button ▷ . Slow Playback • Keep this button pressed down for more than 2 seconds during playback. • Resume normal playback by pressing the Playback button ▷ .	
	Fast Forward and Forward Search	
	Fast Rewind and Backward Search • To select Fast Forward or Fast Rewind, press these buttons when the video has stopped. • To briefly watch the picture during Fast Forward or Fast Rewind, hold down the corresponding button. • To search press these buttons briefly during playback, and the search will continue until the Playback button ▷ is pressed. Two times pressing increases search speed (JET SEARCH). • If you keep this button pressed, the search function will continue until you release the button.	
	VHS Index Search Function	
	Remove the cassette. Press the EJECT button on the VCR or press the button □ for more than 3 seconds on the remote control.	
	Change the Sound mode. Press this button repeatedly. Stereosound: OSD Display L R Left channel: OSD Display L Right channel: OSD Display R Mono sound: OSD Display - -	
	Display time, Tape counter or Remaining tape time. Press this button repeatedly.	
	Select the VCR channel and adjust the tracking.	
	Reset the Tape counter. Press this button. When inserting a cassette, the counter is reset to 0:00.00 .	
	Select the channel or the VIDEO Plus+ number Use the numeric buttons. Sample: 18 = 1 8	
	Display the Main menu	
	VCR Timer Recording Function	
	VCR Recording Functions	
	VCR Timer Recording Functions	
	VCR Timer Recording and Tape Speed Functions	
	VCR Programme List and Intro Jet Scan Function	

DVD Operations

DVD display

	Playback (indicated by = ▷)	
	Restart from the memorized position	
	Playback Stop (indicated by = □)	
	Playback Pause (indicated by = II/▷)	
	Slow-motion play • Keep this button pressed down while paused. • Slow Playback forward • Slow Playback backward • Resume normal playback by pressing the Playback button ▷ .	
	Forward Search	
	Backward Search	
	ADVANCED SURROUND: Playback if you are using 2 front speakers BASS PLUS: If you connected a subwoofer PICTURE: Enhances detail in dark scenes DIALOGUE ENHANCER: Increase the volume of the dialogue sound Reselect or store this settings	
	Skipping chapters or tracks	
	Remove the disc. Press the OPEN/CLOSE button on the DVD or press the button □ for more than 3 seconds on the remote control.	
	To change audio soundtrack / language. Press AUDIO during play . The soundtrack changes each time you press the button.	
	Call up OSD-screens	
	Call up the top menu of a DVD	
	Call up the menu of a DVD	
	Return from DVD SETUP menu to playback	
	Language of subtitles	
	Call up the PLAYLIST menu	
	Call up the DVD SETUP menu	
	Check the VCR recording status. For a moment the Timer recording menu or an Info box appears on the OSD.	
	Repeat play	
	A-B Repeat Playback	

Notes: To preserve the video heads, the following functions are switched off automatically after 5 - 10 minutes (Distorted pictures and tape transport noises during these functions are not functional faults): Forward Search (Cue), Backward Search (Review), Jet Search, Still Playback, Slow Playback.