


← VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE
← AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE

TO FRONT SWITCH
P7152(A-3)

PS31005	1
IR	2
PA3	3
PA2	4
PA1	5
PA0	6
GND	



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-VHD1B/EC/EE/F
DVD DISPLAY SECTION IN DVD INTERFACE SCHEMATIC DIAGRAM

REF.NO.30000 SERIES