


Troubleshooting Hints



How to confirm which of DVD circuit or other circuits is defective.

1) Confirm DVD operation and VCR operation




Troubleshooting Hints of DVD circuit


Error Code: 01 (Cause: Decoder Error)



TP8005




TP8007




TP8001



Error Code: 02 (Cause: SDRAM Error)




Error Code: 03 (Cause: NTSC Encoder Error)




Error Code: 04 (Cause: Audio DAC Error)



TP8006




TP8207




TP8416

Error Code: 05 (Cause: EEPROM Error)



Error Code: 06 (Cause: Flash ROM Error)



Error Code: 10, 20, 30 , 40, 50, 60, 70 (Cause: Other Error)

DVD unit is defective.
Replace DVD unit.