



# Panasonic®

**Omnivision VHS**

**Video Cassette Recorder  
Operating Instructions**

**Model No. PV-V4622-K/PV-V4662-K**



**Connections and Initial Setup Procedures are on pages 8 to 11.**



*VCR Plus+, AllSet and PlusCode are trademarks of Gemstar Development Corporation. The VCR Plus+ system is manufactured under license from Gemstar Development Corporation.*



*As an ENERGY STAR Partner, Panasonic has determined that this product or product model meets the ENERGY STAR guidelines for energy efficiency.*

**Please read these instructions carefully before attempting to connect, operate or adjust this product. Please save this manual.**

LSQT0540A

**Initial Setup  
(Connection)**

**Basic  
Operation**

**Timer  
Recording**

**Advanced  
Operation**

**For Your  
Information**



# Important Safeguards and Precautions

**FOR YOUR SAFETY, READ AND RETAIN ALL SAFETY AND OPERATING INSTRUCTIONS. HEED ALL WARNINGS IN THE MANUAL AND ON THE UNIT**

## INSTALLATION

### 1 POWER SOURCE CAUTION

Operate only from the power source indicated on the unit or in this manual. If necessary, have your Electric Utility Service Company or Video Products Dealer verify the power source in your home.

### 2 POLARIZED OR GROUNDING PLUG

As a safety feature, this Video product comes with either a polarized power cord plug (one blade is wider than the other), or a three-wire grounding type plug.

#### POLARIZED PLUG CAUTION:

This plug will only fit into an outlet one way. If you cannot fully insert the plug, try reversing it. If it still will not fit, have an electrician install the proper wall outlet. Do not defeat the safety feature by tampering with the plug.

#### GROUNDING PLUG CAUTION:

This plug will only fit into a three-hole grounding outlet. If necessary, have an electrician install the proper outlet. Do not defeat the safety feature by tampering with the plug.

### 3 POWER CORD

Make sure power cords are routed so that they are not likely to have anything rest on them, roll over them, or be in the way of walking traffic. If an extension cord is used, make sure it also has either a polarized or grounded plug and that the cords can be securely connected. Frayed cords, damaged plugs, and damaged or cracked wire insulation are hazardous and should be replaced by a qualified service technician. Overloaded outlets and extension cords are fire hazards and should be avoided.

### 4 DO NOT BLOCK VENTILATION HOLES

Ventilation openings in the cabinet release heat generated during operation. If they are blocked, heat build-up inside the unit can cause failures that may result in a fire hazard or heat damage to cassettes. For protection, follow these rules:

- Never cover ventilation slots or the unit while in use, or operate the unit when placed on a bed, sofa, rug, or other soft surface.
- Avoid built-in installation, such as a book case or rack, unless proper ventilation is provided.

### 5 AVOID EXTREMELY HOT LOCATIONS OR SUDDEN TEMPERATURE CHANGES

Do not place the unit over or near any kind of heater or radiator, in direct sunlight, inside a closed vehicle, etc.. Do not move the unit suddenly between areas of extreme temperature variation. If the unit is suddenly moved from a cold place to a warm place, moisture may condense in the unit and on the tape.

### 6 TO AVOID PERSONAL INJURY


- Do not place unsecured equipment on a sloping surface.
- Do not place this unit on any support that is not firm, level, and adequately strong. The unit could fall causing serious injury to a child or adult and damage to the unit.
- An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
- Carefully follow all operating instructions and use the manufacturer's recommended accessories when operating this unit or connecting it to any other equipment.



## OUTDOOR ANTENNA INSTALLATION

### 1 SAFE ANTENNA AND CABLE CONNECTION

If an outside antenna or cable system is connected to the equipment, be sure the antenna or cable system is grounded so as to provide some protection against built up static charges and voltage surges. Part 1 of the Canadian



Electrical Code, in USA Section 810 of the National Electrical Code, ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes and requirements for the grounding electrode.

### 2 KEEP ANTENNA CLEAR OF HIGH VOLTAGE POWER LINES OR CIRCUITS

An outside antenna system should be located well away from power lines, electric light or power circuits and where it will never come into contact with these power sources if it should happen to fall. When installing an outside antenna, extreme care should be taken to avoid touching power lines, circuits or other power sources as this could be fatal. Because of the hazards involved, antenna installation should be left to a professional.

## USING THE VIDEO UNIT

If the unit has been in storage or moved to a new location, refer first to the INSTALLATION section of these safeguards.

### 1 KEEP THIS VIDEO UNIT AWAY FROM WATER OR MOISTURE OF ANY KIND.

### 2 IF EQUIPMENT IS EXPOSED TO RAIN, MOISTURE, OR STRONG IMPACT, unplug the unit and have it inspected by a qualified service technician before use.

### 3 DURING AN ELECTRICAL STORM

During a lightning storm, whether indoors or outdoors, or before leaving the unit unused for extended periods of time, disconnect all equipment from the power source as well as the antenna and cable system.

### 4 WHEN THE UNIT IS PLUGGED IN

- Never expose the unit to rain or water. DO NOT OPERATE if liquid has been spilled into the unit. Immediately unplug the unit, and have it inspected by a service technician. Fire and shock hazards can result from electrical shorts caused by liquid contact inside.
- Never drop or push any object through openings in the unit. Some internal parts carry hazardous voltages and contact can cause electric shock or fire hazard.
- Avoid placing the unit directly above or below your TV set as this may cause electrical interference. Keep all magnets away from electronic equipment.

### 5 USING ACCESSORIES

Use only accessories recommended by the manufacturer to avoid risk of fire, shock, or other hazards.

### 6 CLEANING THE UNIT

Unplug the unit. Then, use a clean, dry, chemically untreated cloth to gently remove dust or debris. DO NOT USE cleaning fluids, aerosols, or forced air that could over-spray, or seep into the unit and cause electrical shock. Any substance such as wax, adhesive tape, etc. may mar the cabinet surface. Exposure to greasy, humid, or dusty areas may adversely affect internal parts.

## SERVICE

### 1 DO NOT SERVICE THIS PRODUCT YOURSELF

If, after carefully following the detailed operating instructions, this Video product does not operate properly, do not attempt to open or remove covers, or make any adjustments not described in the manual. Unplug the unit and contact a qualified service technician.

### 2 IF REPLACEMENT PARTS ARE REQUIRED

Make sure the service technician uses only parts specified by the manufacturer, or those having the same safety characteristics as the original parts. The use of unauthorized substitutes may result in fire, electric shock, or other hazards.

### 3 HAVE THE SERVICE TECHNICIAN PERFORM A SAFETY CHECK



After any service or repairs to the unit, request the service technician to conduct a thorough safety check as described in the manufacturer's service literature to ensure that the video unit is in safe operating condition.



# Safety Precautions

**WARNING:** To prevent fire or shock hazard, do not expose this equipment to rain or moisture.

**CAUTION:** To prevent electric shock, match wide blade of plug to wide slot, fully insert.



This symbol warns the user that uninsulated voltage within the unit may have sufficient magnitude to cause electric shock. Therefore, it is dangerous to make any kind of contact with any inside part of this unit.



This symbol alerts the user that important literature concerning the operation and maintenance of this unit has been included. Therefore, it should be read carefully in order to avoid any problems.

Note to CABLE system installer:

This reminder is provided to call the CABLE system installer's attention to Article 820-40 of the NEC in USA (and to the Canadian Electrical Code in Canada) that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

FCC Warning: Any unauthorized changes or modifications to this equipment would void the user's authority to operate.



# Before Using


## Congratulations

on your purchase of one of the most sophisticated and reliable products on the market today. Used properly, it will bring you years of enjoyment. Please fill in the information below. The serial number is on the tag located on the back of your VCR.

- Date of Purchase \_\_\_\_\_
- Dealer Purchased From \_\_\_\_\_
- Dealer Address \_\_\_\_\_
- Dealer Phone No. \_\_\_\_\_
- Model No. \_\_\_\_\_
- Serial No. \_\_\_\_\_

## Accessories

- ☐ Remote Control LSSQ0314




- ☐ Batteries 2 "AA"



- ☐ RF Coaxial Cable VJAS0196



## Loading the Batteries




### ☐ Battery replacement caution


- Do not mix old and new batteries.
- Do not mix alkaline with manganese batteries.

## Prevent Accidental Tape Erasure

Break off the tab to prevent recording.



To record again



## Record/ Playback Time

Only use tapes with the **VHS** mark in this unit.

| Tape Speed Setting  | Type of Video Cassette |         |                    |
|---------------------|------------------------|---------|--------------------|
|                     | T60                    | T120    | T160               |
| SP (Standard Play)  | 1 Hour                 | 2 Hours | 2 Hours 40 Minutes |
| LP (Long Play)      | 2 Hours                | 4 Hours | 5 Hours 20 Minutes |
| SLP (SuperLongPlay) | 3 Hours                | 6 Hours | 8 Hours            |



# Table of Contents

|   |        |
|---|--------|
| Important Safeguards and Precautions .....              | 2, 3   |
| Accessories .....                                       | 4      |
| Loading the Batteries .....                             | 4      |
| Prevent Accidental Tape Erasure .....                   | 4      |
| Record/ Playback Time .....                             | 4      |
| Location of Controls .....                              | 6, 7   |
| Initial Setup for ANT./ Cable→VCR→TV Connection .....   | 8, 9   |
| Initial Setup for DSS/ Cable Box→VCR→TV Connection .... | 10, 11 |

## Initial Setup (Connection)

|   |        |
|---|--------|
| Reset Language, Channels, Clock, VCR's Output Channel ... | 12, 13 |
| Playback a Tape .....                                     | 14     |
| Record on a Tape .....                                    | 15     |

## Basic Operation

|   |         |
|---|---------|
| Timer Recording .....                         | 16, 17  |
| Timer Recording Using VCR Plus+® System ..... | 18 ~ 21 |

## Timer Recording

|  |         |
|--|---------|
| Multi-Brand Control Feature .....  | 22, 23  |
| Advanced Connections (Cable/DSS) .....                                       | 24      |
| MTS Broadcast/ VHS Hi-Fi Stereo System .....                                 | 25      |
| Tape Operation (COMMERCIAL→ <b>ADVANCE</b> ® and MOVIE→ <b>ADVANCE</b> ®) .. | 26 ~ 31 |
| Special VCR Features .....   | 32 ~ 35 |
| Copying Your Tapes (Dubbing) .....   | 36      |

## Advanced Operation


|                                  |            |
|----------------------------------|------------|
| VCR & Cassette Information ..... | 37         |
| On-Screen Displays (OSD) .....   | 38         |
| Before Requesting Service .....  | 39         |
| Limited Warranty .....           | 40         |
| Servicentre List .....           | 41         |
| Index .....                      | Back Cover |

## For Your Information



# Location of Controls

## Remote control Buttons




## Light Tower Universal shuttle Remote Control

**LIGHT button:** When pressed, available buttons light and selected mode button (TV, VCR, or DSS CABLE) flashes 5 seconds. If no button is pressed, light goes out in 5 seconds. Also, hold down a button to confirm the selected mode (mode button flashes) in the dark.

**EJECT button:** Press to eject tape. EJECT is not available during recording.

## Front View of the VCR






## Multi Function Display

### Power Indicator

Lights up when power is on.

### Timer Indicator

Lights up when the VCR is set for Timer Recording, or when One Touch Recording (OTR) is used. Flashes when Timer Recording is set, but tape has not been inserted into the VCR.



### VCR Indicator

Lights up when the VCR/TV selector is set to VCR.


### Clock/ Status/ Channel/ Speed Display

Displays the current time. Briefly displays VCR status when a function button is pressed. Briefly displays the channel number, or "L1" or "L2" when a channel or line input is selected. Briefly displays the recording speed when SPEED is pressed.

### Hi-Fi Indicator

Lights up when Hi-Fi audio is monitored in Playback Mode.

## Rear View of the VCR



### Note

- While plugged into an AC outlet, the VCR consumes 3.0 W of electrical power in off mode.




# Initial Setup for ANT/Cable → VCR → TV Connection

Please make all cable or antenna connections before plugging into the AC outlet. Plugging the VCR Power Cord into an AC wall outlet starts auto channel and clock set.

## How to Connect

- 1 Connect cable from Antenna/Cable to VCR's IN FROM ANT. jack.
- 2 Connect VCR's OUT TO TV jack to TV's ANT. IN jack with (included) RF Cable accessory.




## Doing Initial Setup (Ready to Play)



- 1 Turn TV on and tune to channel 3.
- 2 Plug VCR Power Cord into AC wall outlet. VCR comes on and auto channel and clock set starts.
  - If screen at right does not appear, check VCR - TV connection and, if TV is tuned to channel 3, try switching it to channel 4.
  - To change VCR's output channel, please refer to "VCR's Output Channel" on page 13.

### WARNING

When using "Nut type" RF coaxial cables, tighten with fingers only. Overtightening may damage terminals.




Plugging the AC Power Plug into an AC outlet






**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.

### 3 Settings are made automatically. When setup is done, this screen appears.





### 4 SELECT CONNECTION screen is displayed.

Press **▲▼\*** to select connection "VCR►TV" or "VCR►CABLE/DSS BOX►TV", and press **►** to set.



If "AUTO CLOCK SET IS INCOMPLETE" appears, manually set clock. See below right.




**Initial Setup  
(Connection)**


### Manual Clock Set

If Auto Clock Set was incomplete.

**a** Press **ACTION** on remote to display **CLOCK** screen.



**b** Press **▲▼** to select the month and **►** to set. In the same manner, select and set the date, year, time, and DST (Daylight Saving Time).



**c** Press **ACTION** to start clock, and go to step 4 above left.




# Initial Setup for DSS/Cable Box → VCR → TV Connection

Please make all cable or antenna connections before plugging into the AC outlet. Plugging the VCR Power Cord into an AC wall outlet starts auto channel and clock set.

## How to Connect

- 1 Connect the OUT Jack on your cable box to the IN FROM ANT. terminal on the VCR with the RF Cable.
- 2 Connect the OUT TO TV terminal on the rear of VCR to the ANT. IN terminal on TV using the RF Cable (included accessory).




### WARNING



When using "Nut type" RF coaxial cables, tighten with fingers only. Overtightening may damage terminals.

## Doing Initial Setup (Ready to Play)

- 1 Turn TV on and tune to channel 3.
  - Turn on your cable box and set it to your Public Broadcasting Station (PBS) channel in your time zone. If you use a DSS receiver, it must be turned off.
- 2 Plug VCR Power Cord into AC wall outlet. VCR comes on and auto channel and clock set starts.
  - If screen right does not appear, check VCR - TV connection and, if TV is tuned to channel 3, try switching it to channel 4.
  - To change VCR's output channel, please refer to "VCR's Output Channel" on page 13.




Plugging the AC Power Plug into an AC outlet






**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.


### 3 Settings are made automatically. When setup is done, this screen appears.





### 4 SELECT CONNECTION screen is displayed. Press ▲▼\* to select connection “CABLE/DSS BOX ► VCR ► TV” and press ► to set.



Confirm the output channel of your cable box or DSS receiver. Press ▲▼ to select the same channel as the cable box or DSS receiver output channel. Press ► to enter.



If “AUTO CLOCK SET IS INCOMPLETE” appears, manually set clock. See right.




**Initial Setup  
(Connection)**

### Manual Clock Set

If Auto Clock Set was incomplete.

**a** Press **ACTION** on remote to display **CLOCK** screen.



**b** Press ▲▼ to select the month and ► to set. In the same manner, select and set the date, year, time, and DST (Daylight Saving Time).




**c** Press **ACTION** to start clock, and go to step 4 above left.



# Reset Language, Channels, Clock,

# 1



**Press ACTION\***  
to display menu.


# 2

## Language

- 1) Press **▲▼** to select language item.




- 2) Press **►** repeatedly.



For English



For Spanish




For French


- 3) Press **ACTION** to exit.

## Channels

- 1) Press **◀▶** to select CHANNEL.




- 2) Press **▲▼** to select "ANTENNA," then press **►** to set your antenna system ("TV" or "CABLE").



- 3) Press **▲▼** to select "AUTO SET," then press **►**.


- If you use a Cable Box, set it to the PBS channel in your time zone.




- After Channel Auto Set is finished, Auto Clock Set will be performed.

## Clock


- 1) Press **◀▶** to select CLOCK.



- 2) Press **▲▼** to select "MANUAL," and press **►**. (For Auto Clock Set, select "AUTO CLOCK SET.")



("TIME ZONE ADJUST" appears only when auto clock is set.)



- 3) Press **▲▼** and **◀▶** to select and set the date, time, and DST (Daylight Saving Time).

- 4) Press **ACTION** to start the clock and exit this mode.




# VCR's Output Channel

**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.


## Time Zone Adjust ■ VCR's Output Channel

(Only when Auto Clock is set.)

- 1) Press ◀▶ to select **CLOCK**.



- 2) Press ▲▼ to select **"TIME ZONE ADJUST."**




and press ▶ to subtract or add hour(s) as necessary.


- 3) Press **ACTION**.

- "TIME ZONE ADJUST" returns to "0" if clock is set manually.


- 1) Press ▲▼ to select **VCR'S OUTPUT CH.**




- 2) Press ▶.




- 3) Press **ACTION**.



After 3 seconds



- To Make Corrections, repeat steps 1) ~ 3).



Basic  
Operation

## Add or Delete a Channel

To add channel:

Select channel with **NUMBER** keys and press **ADD/HLT**.

CHANNEL 08 ADDED

To delete channel:

Select channel with **CH ▲/▼** or **NUMBER** keys and press **ADD/HLT**.

CHANNEL 08 DELETED

## DST (Daylight Saving Time)

VCR auto adjusts clock for DST.  
(p. 9.)

### Spring (First Sunday in April)

DST:ON → Sets clock ahead one hour.

### Autumn (Last Sunday in October)

DST:ON → Turns clock back one hour.

- If your area does not observe Daylight Saving Time, select DST:OFF.
- Keep these time changes in mind when programming VCR for timer recordings.




# Playback a Tape



## Ready Checklist

- ☐ All connections are made (p. 8, 10, 24).
- ☐ TV and VCR are plugged in.
- ☐ TV is on and tuned to CH 3, 4, or VIDEO.
- ☐ Remote is in VCR mode. (Press VCR)



## Playback using VCR controls

- 1 Insert a tape.
- 2 Press PLAY.




Multi Function Display

- Press STOP/EJECT to stop and/or eject tape.

### Note

Remove loose or peeling labels from tapes to prevent tape jam.



## 1 Insert a tape,

- VCR power comes on. "VCR" lights on Multi Function Display. If Auto VCR/TV (p. 35) is set to "OFF," press VCR/TV until "VCR" lights on the Multi Function Display.

## 2

Press PLAY to play tape.

- If tape has no rec. tab (p. 4), auto play begins.

### Special Features During Play

#### ■ Forward/ Reverse scene search

→ Press FF or REW.

→ Press PLAY to release.

After search has begun, each additional press of FF or REW changes speed as shown below.

[SLP] : Approx. 21X ↔ Approx. 43X

[LP] : Approx. 9X ↔ Approx. 15X

[SP] : Approx. 7X ↔ Approx. 13X

- If picture is interrupted at 43X, 15X, or 13X speed, speed changes to 21X, 9X, or 7X.
- It may take a moment for 43X, 15X, or 13X search to start while tape condition is being determined.
- 43X, 15X, or 13X search may not be possible with some tapes.

### Notes

- Picture interruption may occur with some TVs.
- FF and REW search speed may vary depending on current tape position.

#### ■ Still (Freeze) picture

→ Press PAUSE/SLOW.

→ Press PLAY to release.

#### ■ Frame by Frame picture

→ Press PAUSE/SLOW in Still mode.

→ Press PLAY to release.

#### ■ Slow Motion picture

→ Hold down PAUSE/SLOW in Still mode.

→ Press PLAY to release.

### Notes

- These features work best in SP or SLP mode.
- The sound will be muted.
- To reduce picture noise, see "Manual Tracking Control" on page 37.
- After the VCR is in Still or Slow mode for 3 minutes, it will switch to Stop mode automatically to protect the tape and the video head.

## 3

Press STOP to stop tape.

#### ■ Rapid Rewind/ Fast Forward

(E.g., T-120 tape rewinds in approx. 1 minute.)

Press REW or FF in Stop mode.

### Notes

- Rewind or FF starts after VCR detects tape length. This may take a moment.
- Rew/ FF speed slows down at start and end portions of the tape.

- Press EJECT on remote, or STOP/EJECT on VCR to eject tape.



# Record on a Tape


## Important:

If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.




## Ready Checklist

- ☐ All connections are made (p. 8, 10, 24).
- ☐ TV and VCR are plugged in.
- ☐ TV is on and tuned to CH3, 4, or VIDEO.
- ☐ Remote is in VCR mode. (Press VCR)



## Record using VCR controls

- 2 Select Channel.
- 1 Insert a tape.
- 4 Press REC to start Recording.



- 5 Press STOP/EJECT to stop.

This video recorder, equipped with HQ (High Quality) system, is compatible with existing VHS equipment. Only use tapes with the **VHS** mark. Only tapes tested and inspected for use in 2, 4, 6, and 8 hour machines are recommended.

## 1 Insert a tape with a record tab (p. 4).

- VCR power comes on.
- "VCR" lights on Multi Function Display. If Auto VCR/TV (p. 35) is set to "OFF," press VCR/TV until "VCR" lights on the Multi Function Display.

## 2 Press CH ▲▼\* or NUMBER keys

to select the channel.

- For "LINE" input, see p. 36.
- For channel over 100, first press 100 key then the other 2 digits.

## 3 Press SPEED

to select the record speed (p. 4).

- SP = Standard Play      LP = Long Play
- SLP = Super Long Play
- Speed appears on-screen and on Multi Function Display.

## 4 Press REC

to start recording.

- To edit, press PAUSE/SLOW to pause, and again to resume recording.

## 5 Press STOP

to stop recording.

## One Touch Recording (recording in progress),

- VCR shuts off after the preset record length.
- each press of REC adds 30 min. to the recording length up to 4 hours.

## Record one station, watch another,

- press VCR/TV ("VCR" goes out on Multi Function Display),
- select channels on TV (recording continues).

## Note

- Watching one channel and recording another is NOT possible when using a Cable Box or a Satellite Receiver.

## Select channels on VCR,


- Other channels cannot be viewed during recording.
- press VCR/TV ("VCR" lights up on Multi Function Display),
- select channels on VCR.

## Note

- After 5 min. in Pause mode, VCR stops to protect the tape and the video head.



# Timer Recording




## Ready Checklist

- ☐ All connections are made (p. 8, 10, 24).
- ☐ TV and VCR plugged in and turned on.
- ☐ VCR/TV selector set to "VCR."
- ☐ Clock set correctly.
- ☐ Tape has rec. tab (p. 4).
- ☐ Remote is in VCR mode. (Press VCR)

**1** Press **PROG/VCR+** button to display PROGRAM.

**2** Press **▼** to display Program screen.



**3** **1) Set record DATE, press ▲▼ to select:**  
1~31= one time, or DAILY= MON~ FRI, or WEEKLY= same time each week and press **▶** to set.

- See selection order below left.

**2) To set remaining items, press ▲▼ to select and press ▶ to set START/STOP times, CH (channel) or LINE input (p. 36), Category\*\* and tape speed (SP, LP, SLP).**

**Press PROG/VCR+ button to end the program.**

### Example


Today — 13 SELECT ▲/▼ Selection Order DAILY  
 WEEKLY (SAT) ..... WEEKLY (MON) ..... WEEKLY (SUN)

\*\*Category Items  
 N/A (not applicable),  
 SPORTS, MOVIE, COMEDY,  
 MUSIC, DRAMA

### Notes

- If you are using a Cable Box, VCR Timer Programming Channel (Step 3) must be set to the Cable Box output channel and your Cable Box must be manually set to the desired channel. The Cable Box must be left on.
- If a power interruption occurs while programming the timer, the timer program(s) may be cancelled. If "TIMER PROGRAMS WERE LOST DUE TO POWER INTERRUPTION" appears on-screen, please re-enter the timer programs.

**4**



**To Enter More Programs, press ▲▼ to select and press ▶ to set an unused program number and repeat step 3.**

Or

**Press PROG/VCR+ button again to exit.**

**5**

**Press POWER off to set the Timer Recording.**  
 ("TIMER" lights up on Multi Function Display.)



**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.

## Review, Replace or Clear Program Contents:

(Recording is not in progress)

**1**

| VCR Plus+ | PROG.  | LIST         |
|-----------|--------|--------------|
| DT        | START  | STOP CH SPD  |
| 7         | 9:00A  | 12:00A 08 SP |
| 8         | 10:00P | 12:00P 02 SP |
| 10        | 8:00P  | 9:00P 10 SP  |
| SU        | 9:00P  | 10:00P L1 LP |

SELECT : ▲▼◀▶  
EXIT : PROG

- 1) Press **PROG/VCR+** button.
- 2) Press **◀▶** to select LIST.

### To cancel a Timer Recording in progress...

Press **POWER** and then press **STOP** within 10 seconds to cancel the Timer Recording. (The **TIMER** indicator goes out on Multi Function Display.)

**2**

| VCR Plus+ | PROG.  | LIST         |
|-----------|--------|--------------|
| DT        | START  | STOP CH SPD  |
| 7         | 9:00A  | 12:00A 03 SP |
| 8         | 10:00P | 12:00P 02 SP |
| 10        | 8:00P  | 9:00P 10 SP  |
| SU        | 9:00P  | 10:00P L1 LP |

CANCEL : ADD/DLT  
SELECT : ▲▼ SET : ▶  
EXIT : PROG

- Press **▲▼**  
to select number.

### 3 To Replace program...

| VCR Plus+         | PROG.        | LIST      |
|-------------------|--------------|-----------|
| DATE              | START        | STOP CH   |
| 7 SUN             | 9:00A        | 12:00A 08 |
| TODAY             |              |           |
| CATEGORY          | N/A SP       |           |
| SELECT START DATE |              |           |
| SELECT            | : ▲▼ SET : ▶ |           |
| END               | : PROG       |           |

- 1) Press **▶** to display.
- 2) Repeat Step 3 (p.16) to set new programs.

or

### To Clear program...


| VCR Plus+ | PROG.  | LIST         |
|-----------|--------|--------------|
| DT        | START  | STOP CH SPD  |
| 8         | 10:00P | 12:00P 02 SP |
| 10        | 8:00P  | 9:00P 10 SP  |
| SU        | 9:00P  | 10:00P L1 LP |

CANCEL : ADD/DLT  
SELECT : ▲▼ SET : ▶  
EXIT : PROG

- Press **ADD/DLT**.

### 4 Press **PROG/VCR+** button

- to end the programming.
- If there are set programs, press **POWER** off to set timer.



SELECT/  
SET  
▲:PLAY  
▼:STOP  
◀:REW  
▶:FF

PROG/  
VCR+

ADD/DLT

**Timer  
Recording**

### Important notes when using a DSS receiver

- When recording programs via a DSS receiver, the DSS receiver must be left on.
- When recording programs via antenna or cable, the DSS receiver must be turned off.



# Timer Recording Using VCR Plus+® System


## Auto VCR Plus+ System Channel Setup (Part 1)

For [VCR→TV] or [VCR→cable box→TV] connection only.

In order for VCR to read PlusCode numbers, some set-up is required. Guide channel numbers are assigned to each local broadcast and cable station. Because this number sometimes differs from the channel your TV receives the station on, it is necessary to program the VCR with local channel information. To receive VCR Plus+ channels automatically, perform the steps below.


Or, see "Manual VCR Plus+ System Channel Setup" section on page 20.

1




Press **ACTION\*** to display menu.

2




Press **◀▶** to select CHANNEL.

3




Press **▲▼** to select VCR Plus+ CH SET UP and press **▶** to display.

4




Press **▲▼** to select AUTO SET and press **▶** to set.

5




Press **▲▼▶◀** to enter POSTAL Code and enter each number. Press **▶** or **ACTION** to set.

6



Press **▲▼** to select When to Update and press **▶** to set.

7



Press **ACTION** to return to normal screen.


- Make sure to leave VCR off (overnight).

### VCR Plus+ System is ...

a feature that allows you to set **most items** for timer recording by simply entering a special code number (PlusCode programming number) found in TV GUIDE and selected newspaper TV listings.

### Important Note

- "Initial Setup" on pages 8 ~ 11 must be completed before "Auto VCR Plus+ System Channel Setup" can be done. If any part of setup is incomplete, a warning screen appears.



### Notes

- When Auto Set is performed, channels set in initial setup (pp. 8 ~ 11) will be replaced by automatically downloaded data.
- Make each entry within 1 minute or VCR will leave this mode.
- Once local channels have been programmed, they will stay in memory, even in the case of a power failure.
- If the start time for a timer recording comes up during Auto VCR Plus+ System Setup, the timer recording will have priority.




**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.

## Auto VCR Plus+ System Channel Setup (Part 2)


Before you perform the following steps, you should have:

- completed “Auto VCR Plus+ System Channel Setup (Part 1)” on page 18.
- left VCR off overnight, and turned it back on after 9:00 AM the next day.


- 1** If channel updating was successful... If VCR could not distinguish channel map...




Press **ACTION** to exit this mode.




Press **ACTION** to display SELECT VCR Plus+ CH screen. Continue with step 2.



- 2** Press **▲▼◀▶** to select channel map for your area and press **ADD/HLT** to set.



- 3** Press **ACTION** to return to normal screen.



- Make sure to leave VCR off (overnight).


Channel map will be updated (overnight). If it was successful, “VCR Plus+ CH SET COMPLETED” appears on screen. Press **ACTION** to exit.

Repeat these steps as necessary.

If Auto Setup fails, do “Manual VCR Plus+ System Channel Setup” on page 20.

### To Change or Update Auto VCR Plus+ System Channel Setup (E.g. you selected wrong channel map or POSTAL code.)

- a** Do “Auto VCR Plus+ System Channel Setup (Part 1)” steps 1~4 on page 18.



- b** Press **▲▼** to select UPDATE VCR Plus+ CH or SELECT VCR Plus+ CH, then press **▶**.
- c** If you selected UPDATE VCR Plus+ CH, perform steps 5~7 in the “Auto VCR Plus+ System Channel Setup (Part 1)” section on page 18.

If you selected SELECT VCR Plus+ CH, perform steps 2~3 in the “Auto VCR Plus+ System Channel Setup (Part 2)” section on this page.

Timer  
Recording



# Timer Recording Using VCR Plus+® System (continued)

## Initial Setup.....

In order to use Timer Recording Using VCR Plus+ System, the Initial Setup on page 8 to 11 must be completed for setting Clock and Channel.

## Channel Setup.....

Since numbers assigned to channels found in TV Guide and selected newspapers may differ from channels in your viewing area, you'll need to enter your local TV channel number for each corresponding Guide Channel.

If you perform the VCR Plus+ Channel set up procedures shown below, you will be able to perform timer recordings using the PlusCode programming number listed in your local TV listing.

## Manual VCR Plus+ Channel Setup

For [VCR→TV] or [VCR→cable box→TV] connection only.

To complete step 5 of setup, do the following:


- Prepare a TV/Cable station line-up and channels they are received on. Also, the Guide channel numbers assigned to your stations (found in TV Guide and selected newspapers.)

- Make a 3-column chart (see sample).  
Left column → all stations you receive.  
Middle column → each station's assigned Guide channel number from TV Guide, etc.


Right column → channel number on which your TV receives the station.

### SAMPLE ONLY


| Broadcast or Cable station name | Assigned Guide channel No. | Channel No. on which my TV receives the station. |
|---------------------------------|----------------------------|--|
| HBO                             | 33                         | 15   |
| Nickelodeon                     | 38                         | 20   |
| CBS                             | 04                         | 04   |
| FOX                             | 11                         |  |




Press **ACTION\*** to display menu.




Press **◀▶** to select CHANNEL.




Press **▲▼** to select VCR Plus+ CH SET UP, and press **▶** to set.



Press **▲▼** to select MANUAL, and press **▶** to set.



To enter VCR Plus+ channels, press **▶** to move cursor to right, press **▲▼** to enter number, press **▶** to set, and press **▲▼** to scroll up/down.



- Repeat step 5 until list is complete.

To Make Corrections, press **▲▼** and **▶** to move to error, then **▲▼** to change, or **ADD/DLT** to erase number.

**6** Press **ACTION** twice to return to normal screen.



**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.

## VCR Plus+ System Programming

### ☒ Ready Checklist

- ☐ Clock is set.
- ☐ VCR Plus+ Setup is complete (see pp. 18 - 20).

**1**

|              |               |       |
|--------------|---------------|-------|
| VCR Plus+    | PROG.         | LIST  |
| DATE         | START         | STOP  |
| 13 SAT       | --:--         | --:-- |
| TODAY        | CATEGORY: N/A | SLP   |
| SELECT: ▲▼◀▶ |               |       |
| EXIT : PROG  |               |       |

**Press PROG/VCR+** button to display PROGRAM.

**2**

|                       |       |      |
|-----------------------|-------|------|
| VCR Plus+             | PROG. | LIST |
| ENTER PLUSCODE NUMBER |       |      |
| -                     |       |      |
| USING 0-9 KEYS        |       |      |
| SELECT : ▲▼◀▶         |       |      |
| EXIT : PROG           |       |      |

**Press ◀▶** to select display VCR Plus+ screen.

**3**

|                       |       |      |
|-----------------------|-------|------|
| VCR Plus+             | PROG. | LIST |
| ENTER PLUSCODE NUMBER |       |      |
| 1                     |       |      |
| USING 0-9 KEYS        |       |      |
| BACKSPACE ◀           |       |      |
| END : PROG            |       |      |

**Press NUMBER keys** to enter PlusCode number and **press PROG/VCR+** button to set.

**To Make Corrections,** press ◀ repeatedly to delete number, then repeat step 3.

- If the PlusCode number entered begins with "0," skip to step 5. Display in step 4 will not appear.

**4**

|                |       |      |
|----------------|-------|------|
| VCR Plus+      | PROG. | LIST |
| ONCE           |       |      |
| DAILY(MON~FRI) |       |      |
| WEEKLY         |       |      |
| SELECT : ▲▼    |       |      |
| END : PROG     |       |      |

**Press ▲▼** to select ONCE, DAILY(MON~FRI), or WEEKLY recording frequency and **press PROG/VCR+** button to set.

**5**

|                    |                     |          |
|--------------------|---------------------|----------|
| VCR Plus+          | PROG.               | LIST     |
| DATE               | START               | STOP     |
| 13 SAT             | 2:20P               | 3:20P 02 |
| TODAY              | ✓/✓                 | ABC      |
| CATEGORY: N/A      | SELECT RECORD SPEED |          |
| SELECT : ▲▼ SET: ▶ |                     |          |
| END : PROG         |                     |          |

**Press ▲▼** to select category and recording speed. **Press ▶** to set.


**Press PROG/VCR+** button to end program.

**6**

|                    |       |          |
|--------------------|-------|----------|
| VCR Plus+          | PROG. | LIST     |
| DT                 | START | STOP     |
| 13                 | 2:00P | 3:20P 02 |
| SLP                |       |          |
| CANCEL : ADD/HLT   |       |          |
| SELECT : ▲▼ SET: ▶ |       |          |
| EXIT : PROG        |       |          |

**Press PROG/VCR+** button again to exit.

- **Press ADD/HLT** to delete the program.



### Do normal Timer Record if...

- PlusCode number is not listed for program.
- the program (e.g. sports event) may run over set stop time.

### See page 17 to:

- cancel a timer recording in progress.
- review, replace, or clear program contents.

### Important for DSS/Cable Box Users

- When recording via DSS, the receiver must be left on. When recording via cable or antenna, DSS receiver must be off.
- When recording via a cable box, leave box on and tuned to channel to be recorded.

### Notes

- Do not overlap program times.
- PlusCode numbers cannot be used to program VCR to record DSS and cable box channels.
- Make each entry within 1 minute or the VCR will exit setup mode.
- Once VCR Plus+ channel setup is done, channels stay in memory. If a power interruption occurs, VCR Plus+ channel setup may be lost. Please do VCR Plus+ channel setup again.

Timer  
Recording

**7 Press POWER off** to set the timer.  
(“TIMER” lights up on Multi Function Display.)



# Multi-Brand Control Feature

## Multi-Brand Control Setup

The Remote Control can be set to control some TV and Cable box/DSS functions.

### 1 Find your TV and Cable Box/DSS Receiver Brand Code Number on the following page.

### 2 ■ Setup for TV control, → hold down TV button, → enter code with NUMBER keys.

### ■ Setup for Cable or DSS control, → hold down DSS/CABLE button, → enter code with NUMBER keys.

- If code number is 100 or greater,  
→ **press 100 key**, then other digits.  
e.g., press 100 - 0 - 2 for 102.

### 3 Confirm code entry, → **press POWER** to turn selected unit on or off. • See table below for controllable functions in each mode.

#### Notes

- Repeat setup after remote battery replacement.
- Remote will not control every TV, cable box, or DSS made by the manufacturer listed. If you get no response, your particular unit cannot be controlled. There are NO additional codes for the products listed. If your product is not listed, then the remote is not compatible with that product.

## Using Multi-Brand Control

After remote is set up, you can select VCR, TV, or DSS/CABLE for the desired function.


**Press VCR, or TV, or DSS/CABLE** on the remote.

(Table below shows available unit buttons for each mode.)

| Mode \ Unit | VCR  | TV   | CABLE/ DSS   |
|-------------|--|--|--|
| VCR         | All  | VOL UP/DOWN  | _____  |
| TV          | VCR/TV, PLAY, STOP EJECT, SAP/ Hi-Fi, DISPLAY, FF, REW, PAUSE/ SLOW, REC, SPEED, CA/ZERO, COUNTER RESET, TAPE POSITION | POWER, INPUT, number keys, ENTER, CH UP/ DOWN, VOL UP/DOWN | _____  |
| CABLE/ DSS  |  | VOL UP/ DOWN   | POWER, ENTER, number keys (except 100key), CH UP/ DOWN |

#### Notes

- Not all functions listed may be controllable.
- In TV or DSS/CABLE mode, it may be necessary to press ENTER after pressing NUMBER keys for channel selection.





### TV Brand Code Numbers

|                 |        |                |        |                  |            |
|-----------------|--------|----------------|--------|------------------|------------|
| Panasonic ..... | 01, 02 | Sylvania ..... | 05     | JVC .....        | 11         |
| Quasar .....    | 01, 02 | Sharp .....    | 06, 07 | Hitachi .....    | 12         |
| RCA .....       | 03     | Sony .....     | 08     | Mitsubishi ..... | 07, 13     |
| GE .....        | 03     | Toshiba .....  | 09     | Samsung .....    | 14         |
| Zenith .....    | 04     | Sanyo .....    | 10     | Gold Star .....  | 15, 16, 17 |
| Magnavox .....  | 05     | Fisher .....   | 10     |                  |            |

### Cable Box Brand Code Numbers

|                           |  |                           |  |
|---------------------------|--|---------------------------|--|
| Archer .....              | 44, 06, 01, 120, 05, 63, 126   | Oak Sigma .....           | 46, 11, 129, 101                               |
| Cableview .....           | 29, 09, 01, 63, 120, 44, 42, 30<br>52, 04, 124, 126                                      | Panasonic .....           | 17, 16, 08, 87, 109                            |
| Citizen .....             | 44, 52, 30, 63, 42, 04, 124, 126   | Philips .....             | 23, 24, 20, 13, 07, 50, 128, 129               |
| Curtis .....              | 08, 09, 25, 61, 53, 87   | Pioneer .....             | 06, 05, 12                                     |
| Century .....             | 44, 51, 75, 59, 126  | Pulsar .....              | 04, 42, 63, 44, 30, 52, 124, 126               |
| Cabletenna .....          | 29, 09, 01, 63, 120, 44, 126   | Quest .....               | 06, 05, 12                                     |
| Cable Cinema .....        | 29, 09, 01, 63, 120, 44, 126   | Radio Shack .....         | 44, 51, 75, 59, 126                            |
| Diamond .....             | 29, 09, 01, 63, 120, 44, 126   | RCA .....                 | 17, 16, 08, 87, 109                            |
| Eagle .....               | 62, 40, 22, 13, 58, 20, 26, 107  | Realistic .....           | 44, 51, 75, 59, 126                            |
| Eastern .....             | 28, 29, 130  | Recoton .....             | 44, 51, 75, 59, 126                            |
| Explorer .....            | 08, 09, 25, 61, 53, 87   | Regal .....               | 41, 14, 15, 28, 102, 104, 103, 130             |
| Genini .....              | 30, 04, 124  | Regency .....             | 28, 29, 130                                    |
| General Electric .....    | 01, 57, 120  | Rembrandt .....           | 44, 42, 63, 29, 01, 32, 39, 120, 126           |
| General Instruments ..... | 01, 84, 83, 34, 03, 02, 04, 55<br>65, 66, 67, 68, 120, 106, 121, 122, 115, 117, 118, 124 | Samsung .....             | 42, 06, 32, 05, 40                             |
| Gerrard .....             | 44, 51, 75, 59   | Scientific Atlanta .....  | 08, 09, 25, 61, 53, 87                         |
| GC Electronics .....      | 44, 42, 63, 29, 30, 52, 04<br>124, 126   | Sheritech .....           | 27   |
| Hamlin .....              | 41, 14, 15, 28, 102, 104, 103, 130   | Signal .....              | 26, 112  |
| Hitachi .....             | 31   | SL Marx .....             | 42, 06, 32, 40, 43, 44, 52, 63, 126            |
| Jerrold .....             | 01, 84, 83, 34, 03, 02, 04, 55, 65, 66<br>67, 68, 120, 106, 121, 122, 115, 117, 118, 124 | Sprucer .....             | 17, 16, 08, 87, 109                            |
| Jasco .....               | 30, 04, 124  | Standard Components ..... | 32, 39, 42, 44, 126                            |
| Macom .....               | 31   | Stargate .....            | 04, 42, 32, 40, 63, 44, 30, 52, 06<br>124, 126 |
| Magnavox .....            | 26, 112  | Sylvania .....            | 19, 18   |
| Matsushita .....          | 17, 16, 08, 87, 109  | Teknika .....             | 74, 35   |
| Movietime .....           | 32, 39, 42, 44, 126, 38, 40  | Telecaption .....         | 77, 127  |
| Maestro .....             | 74, 35   | Televue .....             | 40, 19, 38, 32, 42, 06                         |
| NEC .....                 | 40, 19, 38, 32   | Texscan .....             | 19, 18   |
| NSC .....                 | 40, 19, 38, 32   | Tocom .....               | 34, 33, 01, 42, 66, 120                        |
| Novavision .....          | 08, 09, 25, 61, 53, 87   | Toshiba .....             | 36   |
| Next Level .....          | 01, 84, 83, 34, 03, 02, 04, 55, 65<br>66, 67, 68, 120, 106, 121, 122                     | Unika .....               | 44, 42, 63, 29, 01, 126, 120                   |
| Oak .....                 | 46, 11, 129, 101   | Universal .....           | 52, 43, 44, 63, 42, 126                        |
|                           |  | Viewstar .....            | 62, 40, 22, 13, 58, 20, 26, 107                |
|                           |  | Videoway .....            | 07, 23, 50, 129                                |
|                           |  | Vidtek .....              | 64   |
|                           |  | Zenith .....              | 07, 23, 50, 129                                |

### DSS Brand Code Numbers

|                       |        |                 |         |
|-----------------------|--------|-----------------|---------|
| Toshiba .....         | 90     | Optimus .....   | 94, 95  |
| Hitachi/ Hughes ..... | 91, 99 | Panasonic ..... | 96      |
| Primestar .....       | 92     | ProScan .....   | 97      |
| Drake .....           | 93     | RCA .....       | 97      |
| Magnavox .....        | 94, 95 | SONY .....      | 98, 105 |
| Uniden .....          | 94, 95 |                 |         |

### Important Notes


- Due to changes in infra-red commands used by manufacturers, some brands have several codes. If your unit does not respond to the first code, please try the next one.
- Some TV, Cable Box and DSS Box brands require you to turn on the power manually.



# Advanced Connections


## Audio/Video Connection

If your TV has AUDIO IN and VIDEO IN terminals, you can connect your VCR to them to receive higher quality picture and sound.



- 1 Connect the VIDEO OUT terminal on the VCR to the VIDEO IN terminal of your TV.
- 2 Connect the "L" and "R" AUDIO OUT terminals on the VCR to the "L" and "R" AUDIO IN terminals of your TV.
- 3 Set the VIDEO/TV selector of your TV (Monitor/Receiver) to "VIDEO."

### ■ With a Cable Box (VCR → Cable Box)




#### You Can

- view any (including scrambled) channel.
- use VCR Remote Control to select channels without using Multi-brand control feature.

#### You Cannot

- record scrambled channels.

### ■ Connect With Two Cable Boxes



#### You Can

- record and view both scrambled and unscrambled channels if additional equipment is added. This connection requires: two converter boxes, an A/B switch, and a 2-way splitter.

#### You Cannot

- view channel other than the one selected for any type of recording.
- do a Timer recording of a channel unless you select it at the cable box.




# MTS Broadcast/ VHS Hi-Fi Stereo System

## Connection

Make the Audio/Video Connection as shown on the previous page.

- You can use a TV connected to a Stereo amp and speakers instead of a Stereo TV.



## Receivable Broadcast Types

The following are possible audio broadcast types and on-screen displays. The signal being received is indicated with an "⦿" mark while the selected audio mode is indicated with an arrow.

To display the broadcast signal being received, → **press DISPLAY**.

### MTS Stereo and SAP broadcast

Multi-channel Television Sound Stereo (main language) and Secondary Audio Program (sub language) broadcasts are being received simultaneously. Select STEREO or SAP audio mode.

### MTS Stereo broadcast

Multi-channel Television Sound Stereo broadcast. Select STEREO audio mode.






- If stereo broadcast is weak and display flickers, select MONO audio mode for possible better results.

### SAP broadcast

Secondary Audio Program (sub language) broadcast. Select SAP audio mode for the sub language.

### MONO broadcast


Normal monaural sound broadcast.



Equipped with **dbx**®-TV Noise Reduction for true MTS reproduction. **dbx**®-TV Noise Reduction is required for good stereo separation and audio fidelity. **dbx**® is a registered trademark, and is licensed by **dbx**® Technology Licensing.

## Audio Mode for Recording

- Press SAP/ Hi-Fi** to display audio mode. (Display disappears after 5 seconds.)



- Arrow indicates selection.


**Press SAP/ Hi-Fi repeatedly** to select desired mode.

- Refer to "Receivable Broadcast Types" above.

- Do a recording.** See page 15.

## Audio Mode for Playback

- Start playback.** See page 14.
- Press SAP/ Hi-Fi** to display audio mode. (Display disappears after 5 seconds.)



- Arrow indicates selection.

**Press SAP/ Hi-Fi repeatedly** to select desired mode.

- Select "HIFI(L/R)" or "HIFI(L)" or "HIFI(R)" to listen to stereo recordings in stereo sound. Select "NORMAL" for monaural sound.

Advanced  
Operation

## Notes

- Only tapes recorded in Hi-Fi stereo will playback with true stereo sound. Standard stereo tapes will playback in monaural sound.
- To listen to Hi-Fi stereo playback, the VCR AUDIO (L/R) jacks must be connected to a stereo TV or an external stereo amp and speakers. (See top of this page.)
- If tracking is adjusted during playback, Hi-Fi audio may revert to normal audio.
- Hi-Fi and normal audio playback volume level may differ.



# Tape Operation

## COMMERCIAL ▶▶ **ADVANCE**®

COMMERCIAL ▶▶ **ADVANCE**® detects and marks the beginning and end points of commercials on your tape for recordings over 15 minutes in length. When COMMERCIAL ▶▶ **ADVANCE**® marked tape is played back, the VCR automatically advances through the commercial segments at high speed. You can also set this feature to Manual so as to have more control over the advance process. The effectiveness of this system can vary due to differences in the way television stations broadcast. See page 28 for answers to the most commonly asked questions about this feature.

## COMMERCIAL ▶▶ **ADVANCE**® Marking

When C/A RECORD: ON, VCR automatically rewinds the tape after a recording has been made and marks the beginning and end of any detected commercial blocks. After marking is done, the tape is returned to the end of the recording. Commercials are not erased from the tape.

1

| VCR             | C/A      | CLOCK | CH |
|-----------------|----------|-------|----|
| REPEAT PLAY     | :OFF     |       |    |
| TIME STAMP      | :ON      |       |    |
| REMOTE WARNING  | :ON      |       |    |
| AUTO SHUT-OFF   | :OFF     |       |    |
| AUTO VCR/TV     | :ON      |       |    |
| IDIOM/LANGUE    | :ENGLISH |       |    |
| VCR'S OUTPUT CH | :3       |       |    |
| SELECT          | :▲▼◀▶    |       |    |
| EXIT            | :ACTION  |       |    |

Press **ACTION**\* to display menu.

2

| VCR                    | C/A     | CLOCK | CH |
|------------------------|---------|-------|----|
| SET UP COMMERCIAL ADV. |         |       |    |
| C/A RECORD             | :ON     |       |    |
| C/A PLAYBACK           | :AUTO   |       |    |
| SELECT                 | :▲▼◀▶   |       |    |
| EXIT                   | :ACTION |       |    |

Press **◀▶** to select C/A and display SET UP COMMERCIAL ADV.

3

| VCR                    | C/A     | CLOCK | CH |
|------------------------|---------|-------|----|
| SET UP COMMERCIAL ADV. |         |       |    |
| C/A RECORD             | :ON     |       |    |
| C/A PLAYBACK           | :AUTO   |       |    |
| SELECT                 | :▲▼◀▶   | SET   | :▶ |
| EXIT                   | :ACTION |       |    |

Press **▲▼** to select C/A RECORD and press **▶** to set.

**ON** Timer Recording, VCR Plus+ System, and One Touch recordings are marked automatically.

THE VCR IS WAITING TO MARK COMMERCIALS IN THE PROGRAM YOU RECORDED.

|         |               |
|---------|---------------|
| MARKING |               |
| NOW     | :PRESS 1      |
| LATER   | :PRESS 2      |
| CANCEL  | :PRESS ACTION |


**OFF** The VCR will not mark commercials.

When you are editing or dubbing a tape, or when you do not wish to use this feature, OFF should be selected.



## Ready Checklist

- ☐ All connections are made.
- ☐ One time Setup completed.
- ☐ VCR is plugged in.
- ☐ TV is turned on and set to CH3, 4 or Video on TV.



SELECT/SET

▲:PLAY  
▼:STOP  
▶:FF  
◀:REW

NUMBER keys

ACTION

## Note

- When using the timer to record two adjacent shows on the same channel, better accuracy can be obtained by programming each show separately.

When STOP is pressed during normal recording, Select One of a) or b) or c).

- a) Press 1 key to mark the recording now. "NOW MARKING COMMERCIALS" appears.
- b) Press 2 key to mark the recording later (after the power has been turned off).
- If the tape is rewound and another recording started before the power is turned off, commercials may not be marked correctly.
- c) Press ACTION to cancel the marking of this recording.


**4** Press **ACTION** again to return to normal screen.




**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.

## COMMERCIAL▶▶**ADVANCE**® Playback


When playing back a recording which has been marked using the **COMMERCIAL▶▶ADVANCE**® feature, you can either set VCR to automatically advance through marked commercial blocks, or set it so that commercials are only skipped on your command.



**Press ACTION**  
to display menu.



**Press ◀▶**  
to select C/A and  
display SET UP  
COMMERCIAL ADV.



**Press ▲▼**  
to select C/A PLAYBACK  
and **press ▶** to set  
"AUTO" or "MANUAL".



**AUTO** : VCR will automatically advance through marked commercial blocks recorded on the tape and then resume playback.

**MANUAL** : VCR will advance through commercials only when CA/ZERO is pressed. Playback will resume when the end mark of a commercial block is found, or a new recording or blank portion is detected, or after 8 minutes.

**4 Press ACTION again**  
to return to normal screen.

### Notes

- The selection mode in step 3 remains set unless there is a power outage in which case the original factory setting will be restored.
- If playback is started in the middle of a commercial, only a single commercial is shown, or an individual commercial is longer than 1 minute, the commercial may not be skipped. Press FF to quickly advance through the commercial.
- Part of a recorded program may be skipped over if the program portion between commercials is less than 1 minute or there are frequent dark and quiet scenes during the program. To view the portion of tape being incorrectly skipped, press PLAY while the VCR is skipping, reverse the tape to a point just prior to where the skipping began and press PLAY again. This time the group will not be automatically skipped. Automatic skipping will be re-enabled when the end of the marked group is detected.



**COMMERCIAL▶▶ADVANCE**® and **MOVIE▶▶ADVANCE**® are registered trademarks of SRT, Inc. A Jerry Iggulden invention licensed in association with Arthur D. Little Enterprises, Inc.  
U.S.Pat. No. 5,333,091;  
5,692,093; 5,696,866  
other patents pending

**Advanced  
Operation**



# Tape Operation (continued)

The most commonly asked questions about **COMMERCIAL**••**ADVANCE**® are answered below.

| Question  | Answer   |
|---|--|
| How fast does the VCR advance through commercials?  | The VCR advances through a 3-minute commercial block in about 8 to 12 seconds if the tape speed is SLP. In SP, it takes about 25 to 35 seconds.                              |
| Are commercials advanced through only when I playback a recording?  | Yes. The commercials are not marked until after the recording is finished.   |
| Are commercials still recorded on the tape in case I choose to view them sometime?  | Yes. By setting the C/A PLAYBACK to MANUAL (see page 27), you can view or advance through commercials as desired.  |
| Does <b>COMMERCIAL</b> •• <b>ADVANCE</b> ® work in all recording speeds?  | Yes. <b>COMMERCIAL</b> •• <b>ADVANCE</b> ® works in SP, LP, and SLP.   |
| Does the VCR advance through commercials each time I playback tapes which were recorded using <b>COMMERCIAL</b> •• <b>ADVANCE</b> ®?  | Yes. As long as C/A PLAYBACK is set to AUTO (see page 27), the VCR should advance through commercials each time the tape is played back.                                     |
| After marking commercials, does the VCR stop at the end of the tape, or rewind to the beginning?  | The tape stops at the end of the recording so that any additional timer recordings can be performed.   |
| Can I play my <b>COMMERCIAL</b> •• <b>ADVANCE</b> ® recordings in non- <b>COMMERCIAL</b> •• <b>ADVANCE</b> ® VCRs?  | Yes. <b>COMMERCIAL</b> •• <b>ADVANCE</b> ® marked recordings will play in non- <b>COMMERCIAL</b> •• <b>ADVANCE</b> ® VCRs, but commercials will not be advanced through.     |
| Does the marking process interfere with other programmed recordings?  | No. If the interval between 2 or more timer programs is not sufficient to mark the recording, marking will be done after all recordings are complete and the power goes off. |
| What happens if I cancel the marking in progress so I can use the VCR?  | Marking will be resumed when the VCR's power is turned off as long as the tape has not been ejected.   |
| What if part of my program is advanced through along with the commercials?  | Please see the 3rd note on page 27.  |
| Additional Notes: <ul style="list-style-type: none"> <li>• Because of the various ways in which commercials are broadcast, the VCR may not be able to recognize all commercials.</li> <li>• If a timer recording is scheduled for the middle of the night, please be aware that the VCR will make some noise as it rewinds and fast forwards the tape while marking commercials.</li> </ul> |  |

**COMMERCIAL**••**ADVANCE**® and **MOVIE**••**ADVANCE**® are registered trademarks of SRT, Inc.  
A Jerry Iggulden invention licensed in association with Arthur D. Little Enterprises, Inc.

U.S.Pat. No. 5,333,091;  
5,692,093; 5,696,866  
other patents pending



**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.


## MOVIE ▶ ADVANCE®

MOVIE ▶ ADVANCE® helps you locate certain parts of prerecorded movies (rented or purchased). The feature works in two ways.

- You can go to the beginning of the movie.
- You can skip from one preview to the next.


MOVIE ▶ ADVANCE® works only on tapes recorded in SP speed with the record tab removed.

### 1 Insert a tape without record tab.



Press **SEARCH/ M/A SKIP\*** to display **SEARCH**.

- If you inserted a cassette with the record tab or if you selected "INDEX SEARCH" go to page 30.




Press **SEARCH/ M/A SKIP** twice to select **MOVIE** and press **▲▼** to select **GO TO START MOVIE** or **GO TO PREVIEW**.

Select "**GO TO START MOVIE**," if you want to advance directly to beginning of the movie.

→ continue with step 4.

Select "**GO TO PREVIEW**," if you want to view the first (next) preview.


→ see "To Search for Preview" at right.



Press **FF** to start searching.

- To cancel, press **STOP**.

**When the movie is found...**




Press **PLAY** to start playback.

- To cancel, press **STOP**.

### ✓ Ready Checklist

- ☐ All connections are made.
- ☐ One time Setup completed.
- ☐ VCR is plugged in.
- ☐ TV is turned on and set to CH3, 4 or Video on TV.



### To Search for Preview.

You can override the operation of MOVIE ▶ ADVANCE® SEARCH FOR PREVIEWS mode by pressing **SEARCH/ M/A SKIP** during tape searching.

MOVIE ▶ ADVANCE® works by searching the tape past each preview and then reversing back to the start of the detected preview. While the tape is reversing back, if **SEARCH/ M/A SKIP** is pressed, MOVIE ▶ ADVANCE® will begin searching for the next preview. While searching for the next preview, if you see the start of a preview which you wish to watch, press **SEARCH/ M/A SKIP** and MOVIE ▶ ADVANCE® will immediately reverse back to the start of that preview, instead of searching further past the preview start point. Once the VCR is playing a preview, press **SEARCH/ M/A SKIP** to advance to the next preview, long commercial or the start of the movie (whichever is next).

### 1 Start preview searching.

- 1) In step 3 at left, select **GO TO PREVIEW**.
- 2) Press **FF**.

- If you want to playback, press **PLAY**.

**When a preview is detected, VCR will start playback.**

### 2 Start next preview searching.

- Press **SEARCH/ M/A SKIP**.
- To cancel, press **STOP**.

Advanced  
Operation




# Tape Operation (continued)

## Search System

For each recording, an invisible index mark is placed on the tape. A program index and information are also included for timer recordings. These marks are used to access or scan recordings.

### Index Search

1




Press **SEARCH/ M/A SKIP\*** to display **SEARCH** in Stop or Play mode, and then press **NUMBER** keys to select recording number.

- To calculate number, see below.

Press **FF** or **REW** on the remote to start search.

2




Play begins at end of search. To search forward or back 1 index, press **FF** or **REW** on the remote or VCR while screen left is displayed (10 sec.).

- To cancel, press **PLAY** or **STOP**.

### To Calculate Index Number


#### Example 1:

To go to rec. 2 from rec. 4, enter 3 and press **REW**.



#### Example 2:

To go to rec. 6 from rec. 2, enter 4 and press **FF**.



NOTE: ↓ indicates start points of each recording.

#### Note

- If Index Search is started very close to an index mark, that index mark may not be counted in the search.


### Program End Search

Locates end point of recording for continuity.

1

Press **SEARCH/ M/A SKIP** twice to display **SEARCH** in Stop or Play mode.

2



Press **FF** on the remote to start **PROGRAM END SEARCH**.

- To cancel, press **PLAY** or **STOP**.

Examples of Program End Search.

Fig. 1




Fig. 2





Fig. 3



Upon locating end point,


- search continues 7 sec. past end point,
- tape rewinds to 10 sec. before end point,
- tape plays to end point and stops.

#### Note

- If Program End Search is started very close to an index mark, that mark may be skipped over.



**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.



## Zero Search

To quickly return to a specified tape location.

**1 Press DISPLAY during play** to display Counter.

**2 Press COUNTER RESET** at desired position to reset to "0:00:00".

**3 Continue to record, playback etc.**

**4 Press STOP.**

**5 Press CA/ZERO in Stop mode** to start ZERO SEARCH.


• Unit will go into FF or REW mode and stop at the last point the Counter was set to 0:00:00.



## Repeat Play

Set to playback a recording over and over.

**1 Press ACTION** to display menu.



**Press ▲▼** to select REPEAT PLAY and **press ►** to set ON or OFF.

ON: Play repeats at tape end or if unrecorded portion over 30 sec. is detected.

**3 Press ACTION** to return to normal screen.

## Auto Operation Functions

### Auto Play

Insert a tape → Power comes on, → Play starts if there is no record tab (see p. 4).

### Auto Rewind

Play  
Fast Forward } → Tape end, → Rewind

### Play Auto Eject

(Repeat Play must be off)



Play, → Tape end, → Rewind,  
→ Tape ejects if there is no record tab



**5** Press **ACTION** twice to return to normal screen.




**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.



## Remote Warning ON/OFF Feature

If Multi-brand feature is used (p. 22), and this feature is set to on, a warning appears whenever an invalid key is pressed in TV, DSS, or Cable mode.

**1 Press ACTION**  
to display menu.



Press **▲▼**  
to select REMOTE  
WARNING and  
**press ►** to set ON  
or OFF.

- If "OFF," remote warning will not appear if invalid key is pressed.

**3 Press ACTION**  
to return to normal screen.

## VCR Lock Feature

When set to ON, all operations except for timer record and tape eject are prohibited. Useful for households with small children.

VCR LOCK ACTIVATED

**To turn on,**  
hold down REC on  
the VCR in Stop mode  
with no tape inserted  
for 7 sec.  
(Please ignore the NO  
CASSETTE warning.)

VCR LOCK OFF

**To turn off,**  
repeat above.

- VCR Lock cancels in 24 hours if clock is set.

Advanced  
Operation



# Special VCR Features (continued)

## Time Stamp Feature

The VCR writes program data (see example below) about the first 10 seconds of every recording. The information is then displayed the first 10 seconds of playback.

1

| VCR             | C/A     | CLOCK | CH |
|-----------------|---------|-------|----|
| REPEAT PLAY     | OFF     |       |    |
| TIME STAMP      | ON      |       |    |
| REMOTE WARNING  | ON      |       |    |
| AUTO SHUT-OFF   | OFF     |       |    |
| AUTO VCR/TV     | ON      |       |    |
| IDIOMA/LANGUE   | ENGLISH |       |    |
| VCR'S OUTPUT CH | :3      |       |    |
| SELECT          | ▲▼◀▶    |       |    |
| EXIT            | :ACTION |       |    |

Press **ACTION\*** to display menu.

2

| VCR             | C/A     | CLOCK | CH |
|-----------------|---------|-------|----|
| REPEAT PLAY     | OFF     |       |    |
| TIME STAMP      | ON      |       |    |
| REMOTE WARNING  | ON      |       |    |
| AUTO SHUT-OFF   | ON      |       |    |
| AUTO VCR/TV     | ON      |       |    |
| IDIOMA/LANGUE   | ENGLISH |       |    |
| VCR'S OUTPUT CH | :3      |       |    |
| SELECT          | ▲▼◀▶    | SET   |    |
| EXIT            | :ACTION |       |    |

Press **▲▼** to select **TIME STAMP** and press **▶** to set.

- When "OFF" is selected, the program data is written on the tape, but will not be displayed.

3

Press **ACTION** again to return to normal screen.

### <Time Stamp Example>

One Touch Recording

11/11/2001 SUN  
12:00PM  
CH 08 ABC

Timer Recording

11/11/2001 SUN  
12:00PM 1:00PM  
CH 08 ABC MOVIE


When Clock is not set...

--/--/--  
CH 08 ABC



## Ready Checklist

- ☐ Clock is set to correct time.
- ☐ Record tab in place. (See p. 4.)




## Tape Position and Tape Status Feature

To find out the present tape position and amount of tape remaining. Tape position is displayed for VHS-C type Cassettes, tapes under 30 minute long, and some other tapes, but the position is not correct.

1

Press **TAPE POSITION** to detect current tape position.



- "DETECTING TAPE POSITION" is displayed only when a cassette is first inserted, and it takes several seconds for correct tape position to appear.
- The present tape position indication and amount of tape remaining (according to tape speed) is displayed.
- Tape remaining time display may not be precise.

### Note

This function cannot display exact amount of tape remaining for tapes 30 minutes or less, or for tapes over 120 minutes in length.

2

Press **TAPE POSITION** to return to normal screen.




**\*Important:** If a remote control button does not work when pressed, press the VCR button on the remote and try the button again.

## Auto Shut-Off Feature


The power shuts off at a preset time.

**1 Press ACTION**  
to display menu.



**Press ▲▼**  
to select **AUTO SHUT-OFF**.

**Press ► repeatedly**  
to change shut-off time as shown below.




**3 Press ACTION**  
to return to normal screen.

### Note


The shut-off countdown will not function during Play or Record.

## VCR/TV Selector Feature

The VCR VCR/TV selection can be set to auto or manual.



**Press ACTION**  
to display menu.



**Press ▲▼**  
to select **AUTO VCR/TV**.

**Press ► to set**  
**ON or OFF.**

- **OFF(Manual):** You select "VCR" or "TV" mode using the VCR/TV button on the unit or remote.
- **ON(Auto):** "VCR" mode is automatically set when VCR is turned on, or in Play mode.


**3 Press ACTION**  
to return to normal screen.

### Note


For more on VCR/TV selection, see "Record one station, watch another" and "Select channels on VCR" sections (p.15).

## Weak Signal Display ON/OFF Feature

When set to "ON," picture is displayed regardless of signal strength.



**Press ACTION**  
to display menu.



**Press ◀▶**  
to select and display **CHANNEL**.  
**Press ▲▼** to select **WEAK SIGNAL DISPLAY**, and **press ►** to set **ON or OFF**.

- **ON:** Picture is displayed despite signal condition and may be of poor quality.
- **OFF:** Screen turns solid blue when signal is weak or non-existent.
- Selecting **ON** has no effect on connected equipment with blue back feature.

**3 Press ACTION**  
to return to normal screen.

## Shuttle Variable Speed Search

The SHUTTLE Ring allows you to smoothly control the tape speed during special effects playback in both forward or reverse.

**Begin the forward or reverse search.**

Turn SHUTTLE Ring while in Play or Still mode.

- The more you turn the Ring, the faster the search speed will be.

**Release the Shuttle mode.**

Press a function button such as : PLAY, STOP, etc.

- The VCR performs the function of the button pressed.

### Notes


- When the SHUTTLE Ring is turned more than half in Stop mode, normal Fast Forward or Rewind will begin.
- Some noise bars are normal during Shuttle operation.
- After 3 minutes in Still or Slow, the VCR will go into Stop mode.
- When the SHUTTLE Ring is released, the VCR goes into Still mode.




# Copying Your Tapes (Dubbing)

## Connection

(Rear Connection shown.)



### Front of VCR



(Audio/Video In Terminals on the front of VCR are available)

- ① Connect VIDEO OUT terminal on Playing VCR to VIDEO IN terminal on Recording VCR. To monitor the dubbing, also connect a TV as shown.
- ② Connect "L" and "R" AUDIO OUT terminals on Playing VCR to "L" and "R" AUDIO IN terminals on Recording VCR.

In place of a Playing VCR, you can use other equipment, such as a Camcorder. Simply connect the unit's Audio/Video outputs to the Recording VCR.

### Playing (Source) VCR

### Recording (Editing) VCR

**1** Insert pre-recorded tape.

Insert blank tape with record tab.

**2** \_\_\_\_\_

Press INPUT to set VCR Input mode to LINE1 for Video Input (Rear) or to LINE2 for Video Input (Front). (See "Selecting the Input Mode" below.)

**3** Press PLAY, then PAUSE/SLOW immediately to enter PLAY/PAUSE mode.

Press REC, then PAUSE/SLOW immediately to enter REC/PAUSE mode.

**The operation of steps 4 and 5 must be done on the playing and recording VCRs at the same time.**

**4** Press PLAY to start dubbing. Playing VCR starts playback.

Press PAUSE/SLOW to start dubbing. Recording VCR starts recording.

**5** Press STOP to stop dubbing.


Press STOP to stop dubbing.

### ■ To Monitor Dubbing on Your TV

- 1** Turn your TV on and tune to the Recording VCR channel (CH3 or CH4).
- 2** Set the VCR/ TV Selector on the Recording VCR to "VCR."

### ■ Selecting the Input Mode

- Method 1: Press INPUT repeatedly.  
Channel Number ↔ LINE1 ↔ LINE2
- Method 2: Press CH ▲ / ▼.  
Display will change as below.



**Note** Dubbing tapes protected with Copy Guard will result in poor quality recording.

- "L1" or "L2" lights on Multi-Function Display (about 4 sec.) when LINE1 or LINE2 is selected.
- LINE1: For rear audio/video connection.
- LINE2: For front audio/video connection.

**Caution:** Unauthorized exchanging and/or copying of copyrighted recordings may be copyright infringement.



# VCR & Cassette Information


## Head Cleaning

Playing older or damaged tapes may eventually cause video heads to become clogged.

## Video Head Clog Sensor

During playback, this screen appears if clogging is detected. To remove screen, press PLAY on the remote or VCR.

VIDEO HEADS MAY  
NEED CLEANING  
PLEASE INSERT HEAD  
CLEANING CASSETTE  
OR REFER TO MANUAL  
END :PLAY



- Use “dry” type head cleaning cassette only. (Part No. NV-TCL30PT is recommended.)
- Follow cleaning tape instructions carefully. Excessive use of tape can shorten head life.
- If head clog symptoms persist, contact your nearest Factory Servicentre or authorized Servicentre. (See page 41.)

## Cleaning the VCR

Use a soft cloth or dusting attachment of a vacuum cleaner to remove dust from the ventilation holes on the back sides and bottom of the cabinet.

Plastic surfaces are easily scratched and can be marred by alcohol and various solvents. Avoid excessive use of oil-based furniture polishes since the materials used in the cabinet will accumulate more dust.

We recommend using a non-abrasive, antistatic cleaner and polisher.

## Specifications

|                                |   |
|--------------------------------|---|
| <b>Power Source:</b>           | 120 V AC, 60 Hz   |
| <b>Power Consumption:</b>      | <u>Power On</u><br>Approx. 23 watts<br><u>Power Off</u><br>Approx. 3.0 watts  |
| <b>Video Signal:</b>           | EIA Standard NTSC colour  |
| <b>Video Recording System:</b> | 4 rotary heads helical scanning system  |
| <b>Audio Track:</b>            | 1 track (Normal)<br>2 channel (Hi-Fi Audio Sound)   |
| <b>Tuner:</b>                  |   |
| <b>Broadcast Channels:</b>     | VHF 2 ~ 13, UHF 14 ~ 69   |
| <b>CABLE Channels:</b>         | Midband A through I (14 ~ 22)<br>Superband J through W (23 ~ 36)<br>Hyperband AA ~ EEE (37 ~ 64)<br>Lowband A-5 ~ A-1 (95 ~ 99)<br>Special CABLE channel 5 A (01)<br>Ultraband 65 ~ 94, 100 ~ 125 |
| <b>Operating Temperature:</b>  | 5 °C ~ 40 °C (41 °F ~ 104 °F)   |
| <b>Operating Humidity:</b>     | 10 % ~ 75 %   |
| <b>Weight:</b>                 | 2.7 kg (6.0 lbs).   |
| <b>Dimensions:</b>             | 430 (W) x 98 (H) x 242 (D) mm<br>16-15/16" (W) x 3-7/8" (H)<br>x 9-9/16" (D) inch   |

Note: Designs and specifications are subject to change without notice.

## Features for a Quality Picture

### Digital Auto Picture

Automatically controls the video output signal for less noise depending on the tape condition.

### Digital Auto Tracking


Continuously analyzes the signal and adjusts for optimum picture quality.

### Manual Tracking Control (to reduce picture noise)

Use during Playback and Slow Motion mode to reduce picture noise.

**Press CH (TRACKING) ▲/▼** on the remote control or VCR until the picture clears up.

To return to Auto Tracking, **press POWER** off, then on again a few seconds later.



### V-Lock Control (to reduce picture jitter)

In Still mode, **CH (TRACKING) ▲/▼** operate as a V-Lock control.

### CNR (Color Noise Reduction)


(PV-V4662-K Only)

Colour Noise Reduction reduces the colour noise.



# On-Screen Displays (OSD)

## Function & Channel Displays



When a function button is pressed, e.g. PLAY, or you change channels, a 5-second display appears. (Some Station names may also appear if Channel Caption is set. See page 32.)


## Blank Tape/ No Video Signal Indications

Whenever a blank section of a tape comes up in Play mode, or when the selected channel has no broadcast signal with the Weak Signal Display Feature (p. 35) set to OFF, the TV screen will turn solid blue.

## VCR Status & Clock Displays

To display or remove overlay at right,

→ press DISPLAY.



## Warning and Instruction Displays

These displays will alert you to a missed operation or provide further instructions.

| OSD   | Caution   | Page     | OSD   | Caution   | Page           |
|---|---|----------|---|---|----------------|
| PLEASE SET CLOCK BY PRESSING ACTION KEY       | If you attempt to set or review a Timer Recording and the Clock is not set...                   | 16       | VIDEO HEADS MAY NEED CLEANING<br>PLEASE INSERT HEAD CLEANING CASSETTE OR REFER TO MANUAL<br>END :PLAY | If head cleaning becomes necessary while playing back a tape...                                     | 37             |
| TURN VCR OFF FOR TIMER RECORDING              | After a Timer Program has been set...   | 16       | VCR LOCK ACTIVATED  | If you press a function buttons other than STOP/EJECT or POWER while the VCR is in VCR Lock mode... | 33             |
| CHECK CASSETTE RECORD TAB                     | If you press REC on the remote control or VCR, and a cassette is inserted with no record tab... | 4        | REMOTE CONTROL IS SET TO CABLE/DSS MODE<br>USE VCR : VCR KEY  | If you press an invalid key on the remote while in CABLE/DSS mode...                                | 22<br>23<br>35 |
| NO CASSETTE                                   | If you press PLAY, FF, REW, or REC on the remote control or VCR without a cassette inserted...  | 14<br>15 | REMOTE CONTROL IS SET TO TV MODE<br>USE VCR : VCR KEY   | If you press an invalid key on the remote while in TV mode...                                       | 22<br>23<br>35 |
| TO CANCEL TIMER REC PRESS POWER THEN STOP KEY | If you press POWER or STOP during a Timer Recording... (visible in VCR mode only)               | 16       |   |   |                |



# Before Requesting Service

Check the following points once again if you are having trouble with your VCR.

| Power  | Correction  |
|--|---|
| No power...  | <ul style="list-style-type: none"> <li>• Completely insert Power Plug into an AC outlet.</li> <li>• Set POWER button to on.</li> <li>• Make sure power source is active.</li> </ul>   |
| Recording & Playback   | Correction  |
| TV program cannot be recorded...   | <ul style="list-style-type: none"> <li>• Check connections between VCR, external antenna, and TV.</li> <li>• Check channel selections.</li> <li>• Make sure your antenna system (CABLE or TV) is correctly set. (Channels [P. 12])</li> <li>• Make sure cassette record tab is intact. (P. 4)</li> </ul>  |
| Timer recording cannot be performed...   | <ul style="list-style-type: none"> <li>• Confirm that clock is set to current time and date.</li> <li>• Make sure Cable/DSS box (if used) is left on and tuned to channel to be recorded.</li> <li>• Set recording start/stop times correctly. (P. 16)</li> <li>• Make sure VCR POWER button is pressed off. (P. 16)</li> <li>• Timer recording may not be performed or continued if a power interruption occurs before or during a Timer Recording, even after power is restored.</li> </ul> |
| There is no playback picture, or the playback picture is noisy or contains streaks...  | <ul style="list-style-type: none"> <li>• Select channel 3 or 4 on TV to match VCR output channel (3 or 4) (P. 8) or select LINE.</li> <li>• Set VCR/TV selector to "VCR."</li> <li>• Adjust TRACKING control in either direction. (P. 37)</li> <li>• Try Head Cleaning. (P. 37)</li> </ul>  |
| During special effects playback, picture may contain some vertical jitter when using a TV with an Automatic Vertical Hold Control... | <ul style="list-style-type: none"> <li>• Set TV's Vertical Hold Control to MANUAL, then adjust.</li> </ul>  |
| VCR cannot be controlled...  | <ul style="list-style-type: none"> <li>• Make sure VCR power is on.</li> <li>• Check Remote batteries.</li> <li>• Make sure VCR LOCK is set to off. (P. 33)</li> <li>• Make sure Remote is in proper mode. (P. 22)</li> <li>• Make sure Timer Recording is not in progress.</li> </ul>  |
| Remote Control   | Correction  |
| VCR cannot be remote controlled...   | <ul style="list-style-type: none"> <li>• Make sure VCR power is on.</li> <li>• Make sure Remote is in VCR mode.</li> <li>• Aim Remote Control directly at remote sensor on VCR. (P. 6)</li> <li>• Avoid any object blocking signal path.</li> <li>• Check Remote batteries. (P. 4)</li> <li>• Make sure VCR LOCK is set to off. (P. 33)</li> <li>• Exposing VCR remote sensor to direct fluorescent or outdoor light may cause signal interference.</li> </ul>                                |
| ACTION and PROG/VCR+ buttons do not respond...   | <ul style="list-style-type: none"> <li>• Check connections between VCR, external antenna, and TV.</li> <li>• Press VCR button for VCR mode. (P. 22)</li> <li>• Check Remote batteries. (P. 4)</li> </ul>  |
| Miscellaneous  | Correction  |
| Programs cannot be viewed on TV...   | <ul style="list-style-type: none"> <li>• Make sure TV power is on.</li> <li>• Make sure TV is set to output of VCR.</li> <li>• Check connections between VCR, external antenna, and TV.</li> <li>• Set VCR/TV selector to "TV." (P. 15)</li> <li>• Make sure proper signal source is selected.</li> </ul>   |
| Video cassette cannot be inserted...   | <ul style="list-style-type: none"> <li>• Insert the cassette with window side up; record tab facing you.</li> <li>• Check if a tape is already in the unit.</li> </ul>  |
| Video cassette cannot be removed...  | <ul style="list-style-type: none"> <li>• Completely insert Power Plug into an AC outlet.</li> </ul>   |
| Video cassette ejects when a recording is started or the power is turned off for timer recording...                                  | <ul style="list-style-type: none"> <li>• Make sure cassette record tab is intact. (P. 4)</li> </ul>   |
| In Stop mode, the motor (CYLINDER) continues to rotate...  | <ul style="list-style-type: none"> <li>• To enable Quick play mechanism, the cylinder will rotate for about 3 minutes. This reduces response time from Stop to Play mode and from Play to Rewind Search mode.</li> </ul>  |



# Limited Warranty

**Panasonic Canada Inc.**

5770 Ambler Drive, Mississauga, Ontario L4W 2T3

## **PANASONIC PRODUCT – LIMITED WARRANTY**

Panasonic Canada Inc. warrants this product to be free from defects in material and workmanship and agrees to remedy any such defect for a period as stated below from the date of original purchase.

**VHS Video Cassette Recorder – One (1) year, parts and labour**

### **LIMITATIONS AND EXCLUSIONS**

This warranty does not apply to products purchased outside Canada or to any product which has been improperly installed, subjected to usage for which the product was not designed, misused or abused, damaged during shipping, or which has been altered or repaired in any way that affects the reliability or detracts from the performance, nor does it cover any product which is used commercially. Dry cell batteries are also excluded from coverage under this warranty.

This warranty is extended to the original end user purchaser only. A purchase receipt or other proof of date of original purchase is required before warranty service is performed.

**THIS EXPRESS, LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, EXCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

**IN NO EVENT WILL PANASONIC CANADA INC. BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES.**

In certain instances, some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or the exclusion of implied warranties, so the above limitations and exclusions may not be applicable.



# Servicentre List

## WARRANTY SERVICE

**For product operation and information assistance**, please contact your Dealer or our Customer Care Centre at:

Telephone #:

(905) 624-5505

Fax #:

(905) 238-2360

Web:

[www.panasonic.ca](http://www.panasonic.ca)

**For product repairs**, please contact one of the following:

- Your Dealer who will inform you of an authorized Servicentre nearest you.
- Our Customer Care Centre at (905) 624-5505 or [www.panasonic.ca](http://www.panasonic.ca)
- A Panasonic Factory Servicentre listed below:

### Richmond, British Columbia

Panasonic Canada Inc.  
12111 Riverside Way  
Richmond, BC V6W 1K8  
Tel: (604) 278-4211  
Fax: (604) 278-5627

### Calgary, Alberta

Panasonic Canada Inc.  
6835-8<sup>th</sup> St. N. E.  
Calgary, AB T2E 7H7  
Tel: (403) 295-3955  
Fax: (403) 274-5493

### Mississauga, Ontario

Panasonic Canada Inc.  
5770 Ambler Dr.  
Mississauga, ON L4W 2T3  
Tel: (905) 624-8447  
Fax: (905) 238-2418

### Lachine, Québec

Panasonic Canada Inc.  
3075, rue Louis A. Amos  
Lachine, QC H8T 1C4  
Tel: (514) 633-8684  
Fax: (514) 633-8020

---

## CUSTOMER'S RECORD:

**Customer Name:** \_\_\_\_\_

**Model Number:** \_\_\_\_\_ **Serial Number:** \_\_\_\_\_

**Date of Purchase:** \_\_\_\_\_

**Dealer's Name:** \_\_\_\_\_

**Address:** \_\_\_\_\_ **Phone Number:** \_\_\_\_\_

### IF YOU SHIP THE PRODUCT TO A SERVICENTRE

Carefully pack and send prepaid, adequately insured and preferably in the original carton. Include details of the defect claimed, and proof of date of original purchase.

For Your  
Information



# Index

## A

|                                    |        |
|------------------------------------|--------|
| Accessories .....                  | 4      |
| AC Power Plug .....                | 7      |
| Add or Delete a Channel .....      | 13     |
| Audio Input Connector (L/R) .....  | 7      |
| Audio Output Connector (L/R) ..... | 7      |
| Audio/Video Connection .....       | 24     |
| Auto Operation Functions .....     | 31     |
| Auto Shut-Off .....                | 35     |
| Auto VCR Plus+ System              |        |
| Channel Setup .....                | 18, 19 |

## B

|                                 |    |
|---------------------------------|----|
| Batteries .....                 | 4  |
| Before Requesting Service ..... | 39 |
| Blank Tape/ No Video Signal     |    |
| Indications .....               | 38 |

## C

|  |           |
|--|-----------|
| Cable Box Setup .....                    | 10        |
| Cassette Compartment .....               | 6         |
| Channel Caption .....                    | 32        |
| Channel Up/Down Tracking/                |           |
| V-Lock Button .....                      | 6         |
| Cleaning the VCR .....                   | 37        |
| Clock/Status/Channel/Speed Display ..... | 7         |
| CNR (Color Noise Reduction) .....        | 37        |
| Commercial Advance .....                 | 26 ~ 28   |
| Connections .....                        | 8, 10, 24 |
| Copying Your Tapes .....                 | 36        |

## D

|                                  |    |
|----------------------------------|----|
| DST (Daylight Saving Time) ..... | 13 |
|----------------------------------|----|

## F

|                                      |    |
|--------------------------------------|----|
| Fast Forward/Search Button .....     | 6  |
| Features for a Quality Picture ..... | 37 |
| Function & Channel Displays .....    | 38 |

## H

|                       |    |
|-----------------------|----|
| Head Cleaning .....   | 37 |
| Hi-Fi Indicator ..... | 7  |

## I

|  |        |
|--|--------|
| Important Safeguards and Precautions ..... | 2      |
| Index Search .....                         | 30     |
| Initial Setup .....                        | 8 ~ 11 |

## L

|                        |    |
|------------------------|----|
| Limited Warranty ..... | 40 |
|------------------------|----|

## M

|                           |        |
|---------------------------|--------|
| Manual VCR Plus+ System   |        |
| Channel Setup .....       | 20     |
| Movie Advance .....       | 29     |
| MTS Broadcast .....       | 25     |
| Multi-Brand Control ..... | 22, 23 |

## O

|                         |    |
|-------------------------|----|
| On-Screen Display ..... | 38 |
|-------------------------|----|

## P

|                          |    |
|--------------------------|----|
| Playback .....           | 14 |
| Play Button .....        | 6  |
| Power Button .....       | 6  |
| Power Indicator .....    | 7  |
| Program End Search ..... | 30 |

## R

|                                  |        |
|----------------------------------|--------|
| Record .....                     | 15     |
| Record Button .....              | 6      |
| Remote Control Buttons .....     | 6      |
| Remote Sensor .....              | 6      |
| Remote Warning ON/OFF .....      | 33     |
| Repeat Play .....                | 31     |
| Reset Language, Channels, Clock, |        |
| VCR's Output Channel .....       | 12, 13 |
| Review, Replace or Clear         |        |
| Program Contents .....           | 17     |
| Rewind/Search Button .....       | 6      |

## S

|                                     |    |
|-------------------------------------|----|
| Select Audio Mode .....             | 25 |
| Servicentree List .....             | 41 |
| Shuttle Variable Speed Search ..... | 35 |
| Specifications .....                | 37 |
| Stereo/SAP/Mono Broadcast .....     | 25 |
| Stop/Eject Button .....             | 6  |

## T

|                                     |         |
|-------------------------------------|---------|
| Table of Contents .....             | 5       |
| Tape Position and Tape Status ..... | 34      |
| Time Stamp .....                    | 34      |
| Timer Indicator .....               | 7       |
| Timer Recording .....               | 16, 17  |
| Timer Recording                     |         |
| Using VCR Plus+ System .....        | 18 ~ 21 |

## V

|                                       |       |
|---------------------------------------|-------|
| VCR Indicator .....                   | 7     |
| VCR Lock .....                        | 33    |
| VCR Plus+ System Programming .....    | 21    |
| VCR Status & Clock Displays .....     | 38    |
| VCR/TV Selector .....                 | 6, 35 |
| VHF/UHF Antenna Input Terminal .....  | 7     |
| VHF/UHF Antenna Output Terminal ..... | 7     |
| Video Input Connector (L/R) .....     | 7     |
| Video Output Connector (L/R) .....    | 7     |

## W

|  |    |
|--|----|
| Warning and Instruction Displays ..... | 38 |
| Weak Signal Display ON/OFF .....       | 35 |

## Z

|                   |    |
|-------------------|----|
| Zero Search ..... | 31 |
|-------------------|----|

**Panasonic**<sup>®</sup>

**Panasonic Canada Inc.**

5770 Ambler Drive,  
Mississauga, Ontario L4W 2T3  
(905) 624-5010

[www.panasonic.ca](http://www.panasonic.ca)

**Montréal:** 3075 Louis A. Amos, Lachine, Québec H8T 1C4 (514) 633-8684

**Toronto:** 5770 Ambler Drive, Mississauga, Ontario L4W 2T3 (905) 238-2181

**Calgary:** 6835 8th Street N.E., Calgary, Alberta T2E 7H7 (403) 295-3922

**Vancouver:** 12111 Riverside Way, Richmond, BC V6W 1K8 (604) 278-4211

Printed in Indonesia

LSQT0540

S0102-0

