


F
E
D
C
B
A

VIDEO MAIN SIGNAL PATH IN REC MODE

VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

TO LUMINANCE & CHROMINANCE/
AUDIO SECTION P5501(E-23)

FSC	1
GND	2
C SYNC	3
Y/C VIDEO OUT	4
VIDEO 5V	5
PB SECAM	6
V.EE	7
REC C SECAM	8
SECAM	9
RF CHROMA	10



1 2 3 4 5 6 7 8 9