


# SCHEMATIC DIAGRAM



## Notes:

- S1: Record/Playback switch in "PLAYBACK" position.
- S2: Fast Play/Pause switch in "OFF" position.
- S3: Playback switch in "OFF" position.
- S4: FF/REW switch in "OFF" position.
- S5: Tape speed select switch in "2.4 cm/s" position. (1.2...1.2 cm/s, 2.4...2.4 cm/s)
- VR101: Volume control/VAS LEVEL VR.
- VR301: Tape speed adjustment VR. (2.4 cm/s)

- DC voltage measurement are taken with electronic voltmeter from negative terminal of battery.
- No mark ..... Playback
- (.....) Record
- Battery current: No signal..... 121 mA
- Playback (VR max) ..... 330 mA
- Record..... 118 mA

- This schematic diagram may be modified at any time with the development of new technology.

- : Playback Signal Line
- : +B Line
- : Record Signal Line