


 : Playback Signal Line     : +B Line  
 : Record Signal Line



# Notes:

- S1: Record/Playback switch in "PLAYBACK" position.
- S2: VAS/Fast Play/Pause switch in "OFF" position.
- S3: Playback switch in "OFF" position.
- S4: FF/REW switch in "OFF" position.
- S5: Tape speed select switch in "2.4 cm/s" position.  
(1.2...1.2 cm/s, 2.4...2.4 cm/s)
- VR101: Volume control/VAS LEVEL VR.
- VR301: Tape speed adjustment VR. (2.4 cm/s)

- DC voltage measurement are taken with electronic voltmeter from negative terminal of battery.  
No mark ..... Playback  
( ) ..... Record  
Battery current: No signal ..... 118 mA  
Playback (VR max) ..... 290 mA  
Record ..... 120 mA
- This schematic diagram may be modified at any time with the development of new technology.