



- ❶ Card window
- ❷ SD Memory Card cover
- ❸ Clip
- ❹ Play speed switch [**PLAYBACK SPEED**]
- ❺ Battery cover
- ❻ Hand strap hole
- ❼ Microphone jack [**MIC (PLUG IN POWER)**]
- ❽ Built-in microphone [**MIC**]
- ❾ Earphone jack [🎧]
- ❿ Display screen
- ⓫ Volume [**VOLUME (+, -)**]
- ⓬ Shuttle key [**SELECT, ENTER**]
- ⓭ Erase [**ERASE**]
- ⓮ Hold [**HOLD**]
- ⓯ Recording, pause [**REC, PAUSE**]
- ⓰ Stop [**STOP**]
- ⓱ Speaker
- Ⓜ Recording indicator
- Ⓨ Mode [**MODE**]
- Ⓩ Divide [**DIVIDE**]
- ⓫ Folder [**FOLDER**]

Note

Ensure the battery cover can close completely if you fit a hand strap. Fitting a thick strap can cause the cover to close incompletely and lead to incorrect operation.