

System requirements

Operating System: Microsoft® Windows 98 or Windows Me

RealJukebox for Panasonic cannot be used on Microsoft Windows 3.1, Microsoft Windows NT, Microsoft Windows 2000 or Macintosh operating systems. Correct operation cannot be guaranteed when used on Microsoft Windows 95 or Microsoft Windows 98 that has been upgraded from Windows 95/3.1.

Minimum System:	Recommended System:
Intel Pentium®233 MHz MMX, or equivalent CPU	Intel Pentium®II 333 MHz MMX, or equivalent CPU
64 MB RAM	64 MB RAM
Hard drive space: 30 MB for Software 200 MB for Music	Hard drive space: 30 MB for Software 1 GB for Music
CD-ROM drive 16 bit Sound card and speakers	CD-ROM drive that supports digital audio extraction Full Duplex Sound card and speakers
16-bit color video card	16-bit color video card
Internet connection and web browser (Microsoft®Internet Explorer®4.72 or later)	Internet connection and web browser (Microsoft®Internet Explorer®4.72 or later)


Installation


The driver for the USB Reader/Writer and RealJukebox for Panasonic are included on the supplied CD-ROM. Follow these steps to install them.

Checking drive ID

You may have to specify the drive ID during installation. Turn on the computer and start Windows. Refer to the following to check the ID of the drive.

1 Double click on the "My Computer" icon at the top left of the screen.





2 Confirm the CD-ROM drive ID (E: in this case). If you have more than one CD-ROM drive, select the one into which you have inserted the CD-ROM.

Installation

Do not connect the USB Reader/Writer until installation is complete.

- 1 Turn on the computer and start Windows.
- 2 Insert the included CD-ROM into the CD-ROM drive.
 - The installer program starts automatically.
 - If the installer program doesn't start, run the program by specifying the file name (see page 8).
- 3 Choose the language you would prefer to use when using this software and click on [OK].



4

Installation

- 4 Click on [Next].
Select all two applications under normal circumstances.
Make changes if your computer-operating environment requires then click on [Next].
- 5 Read the user agreement, check "Accept" and click on [Next].
The USB Reader/Writer driver is installed.
- 6 Read the user agreement and click on [Accept].
- 7 Click on [Next].
Make changes to the destination if necessary before clicking on [Next].



5

- 8 Select whether to create icons on the desktop and toolbar, and click on [Finish].
Recommendation: create both icons.
The setup program starts.
- 9 Check "Yes" and click on [Finish].
The computer restarts and installation is complete.



Note


If you decided not to install the USB Reader/Writer driver in step 4, the computer will not restart automatically.

6

7

If the installation program doesn't start automatically

- 1 Click on [Start] and, click on "Run..."



- 2 Type in "#:\setup.exe" and click on [OK].

- The installation program starts.
- Continue from step 4 on page 5.
- #: Enter the CD-ROM ID here.
(page 5, Checking drive ID)
- Letters you enter here can be either upper or lower case.




Online help for RealJukebox

These instructions describe basic operations such as installation and transferring tracks. For more detailed instructions, refer to the online help included on the CD-ROM.


To show the online help

- Do one of the following.
- Click on [Start] and select "Programs" → "Real" → "RealJukebox" → "RealJukebox Help".
 - After starting RealJukebox for Panasonic, select [Contents] from the "Help" menu.



To search using the table of contents

- Double click on [?] to display its contents.
- Double click on [?] to see an explanation.



Searching by keyword

The table of contents is replaced by a list of keywords when you click on the "Index" tab. You can find a keyword by either entering it or scrolling through the list. Double click on the keyword to see an explanation.

Using the online help

SD Audio HELP


The SD Audio Help includes explanations about the sections of RealJukebox for Panasonic specific to Panasonic that have not been explained in these operating instructions or in the Online Help for RealJukebox.

- AAC settings and explanations
 - Data conversion
 - Transferring tracks to and deleting tracks from SD Memory Cards
- And more

To show the online help for SD Audio

After starting RealJukebox for Panasonic. (page 12)

- 1 Connect the USB Reader/Writer (page 11).
- 2 Insert an SD Memory Card into the USB Reader/Writer.
- 3 Click on [Devices].
- 4 Double click on "Panasonic Device" and then double click on "SD Card".
- 5 Click on the [SD Audio Help] button.



Connecting an SD Memory Card


Connect the included USB Reader/Writer to transfer (record) tracks to your SD Memory Card.

- Note**
- Connect to an AC power supply when using a portable computer. Data can be lost or errors can occur if the computer turns off during operation.
 - Operation cannot be guaranteed under the following circumstances:
 - When you have connected two or more USB Reader/Writer to your computer or are using another USB device.
 - When you have connected another SD Memory Card adapter.
 - When you are using a USB hub or extension cord.

- 1 Turn on the computer and start Windows.


- 2 Connect the USB Reader/Writer to the computer's USB port.

The "New Hardware Found" screen appears. The driver for the USB Reader/Writer is enabled automatically. Check that it appears in Windows Explorer as a removable drive.



- 3 Taking care that the card is facing the right way, insert the SD Memory Card into the USB Reader/Writer.

Note
You can damage the card and USB Reader/Writer's slot if you insert the card incorrectly. Ensure the USB Reader/Writer's ACCESS lamp is off before inserting or ejecting SD Memory Cards.



Do not remove the SD Memory Card while transferring tracks even if the ACCESS lamp is off.

The USB Reader/Writer

- Do not wet, drop, or expose the USB Reader/Writer to impacts.
- Do not use or store in locations directly exposed to sunlight, a heat vent, or a heating appliance.
- Do not disassemble or modify.
- Do not insert foreign objects into the slot.

Protecting the data on your SD Memory Card

Performing the following actions before RealJukebox for Panasonic has started completely, while the USB Reader/Writer's ACCESS lamp is on, and while transferring tracks can damage your SD Memory Card and corrupt the data it contains.

- Inserting or ejecting the SD Memory Card
- Connecting or disconnecting the USB Reader/Writer
- Shutting down RealJukebox for Panasonic or Windows forcefully
- Turning the computer off forcefully (for example, unplugging the AC power supply cord)

Startup

1 Double-click on the desktop icon.
RealJukebox for Panasonic starts and the registration wizard begins.
Note
If the icon is not on the desktop, from the [Start] menu, select "Programs" → "Real" → "RealJukebox" → "RealJukebox".

2 Fill out the form and Click on [Next].

3 Click on [Next].

4 Click on [Next].
Select "Express Setup (Recommended)" under normal circumstances. Select "Custom Setup" if necessary before clicking on [Next].

5 Click on [Finish].
You are connected to <http://www.Real.com/central/> and your registration information is sent. A screen appears asking if you want to use RealJukebox as the default player.


6 Click on [Yes].
Setup of RealJukebox for Panasonic finishes and the operation window appears.

After doing this once, the RealJukebox for Panasonic operation window will be displayed by simply clicking on the desktop icon.
Note
Turn off the power-saving functions on your computer while using RealJukebox for Panasonic.

Exiting
Click on the [x] box at the top of the main window.

Main features of the display

Use the Navigation Bar to display track lists and other RealJukebox for Panasonic feature areas, and the Control Panel to play and record tracks. The Command Bar contains commands you can use on tracks or track lists, Playlists, devices, and more. RealJukebox for Panasonic menus contain many additional options, including Preferences, Navigation options, and Help.



Quick Start

This section will help you get started using some of RealJukebox for Panasonic's basic features. As you become more experienced using RealJukebox for Panasonic, be sure to explore both the program and this Help system to learn about the many additional tools and options available to you.

Note
The following instructions assume that all default automatic playback options are **on**.

Feature	Description
Record/Play CDs	To Record and Play a CD, insert it into your CD ROM drive. To toggle recording on/off, click the Record button on the Control Panel. To toggle playback on/off, click the Play button.
Play Tracks	To view and play your recorded music, click a Group button (Genre, Artist, Album), then double-click items in the display window to open or play them, or select a track and click the Play button in the control panel.
Create Playlists	To create a custom Playlist, click New Playlist in the Command Bar and follow the on-screen instructions.
Download Music	To download music from the Internet, click the Music Guide button in the Navigation Bar and follow the links.

RealJukebox Homepage

RealJukebox Homepage gives you an easy way to get started using RealJukebox. Each item in the window provides a brief description of a RealJukebox feature, and you can click a link to display track lists, create Playlists, download music, and more.


Note
To see an overview of all options, click the organizer button to see RealJukebox for Panasonic in organizer view. To go back to the previous location, use the Back or Forward buttons or the Location Bar.

If play starts automatically when you insert a CD into the CD-ROM drive, you will need to shutdown any CD playing applications before you can use RealJukebox for Panasonic.

RealJukebox for Panasonic Controls and Navigation

The Navigation Bar

The Navigation Bar gives you instant access to every RealJukebox for Panasonic feature area. Just click a button to display the track list or feature you want to use, then use the Control Panel and Command Bar to play tracks, create Playlists, and more.



Note
You can customize the Navigation Bar: right-click the Navigation Bar and choose the buttons you wish to display by checking/unchecking the boxes.

	Feature	Description
1	Home	Go to the RealJukebox homepage.
2	CD	Record or play a CD.
3	Music Guide	Go to Music Guide and download music from the Internet.
4	All Tracks	View all tracks in your music library.
5	Genre	Click a Group button to go to the desired Track Group.
6	Artist/Album	View the Artist and Album Track Groups.
7	Search	Search your music library using keywords. If you don't see this button in the Navigation Bar, click the >> on the right end.
8	Playlists	View your Playlists. If you don't see this button in the Navigation Bar, click the >> on the right end.
9	AutoPlaylists	View your AutoPlaylists. If you don't see this button in the Navigation Bar, click the >> on the right end.
10	Radio	Go to Real.com and play live streamed radio broadcasts using the RealPlayer.
11	Devices	View your installed portable devices. If you don't see this button in the Navigation Bar, click the >> on the right end.
12	>>	Shows hidden buttons.


The Command Bar

The Command Bar displays context-sensitive options based on the current track list or feature area. Many of these options are only available under the certain circumstances, such as when an appropriate item is selected.

Feature	Description
New Playlist	Launch a new window to help you create a new Playlist.
New AutoPlaylist	Launch a new window to help you create and design a new AutoPlaylist.
Edit AutoPlaylist	Lets you change the criteria for the selected AutoPlaylist.
Copy to Playlist	Send selected tracks to an existing Playlist.
Copy to Device	Send selected tracks to a portable device queue.
Add Tracks	Add selected tracks to a Playlist, AutoPlaylist, or portable device.
Check All	Select all tracks for recording from CD or transfer to a portable device.
Check None	Skip all tracks when recording from CD or transferring to a portable device.
Remix Now	Remix a selected AutoPlaylist: Automatically generates a new compilation of tracks using the same criteria.
Update Now	Updates the Music Guide display.
Begin Transfer	Transfer queued tracks to a portable device. (Changes to "Cancel Transfer" when tracks are being transferred)
Configure	Configure a portable device in preparation for transferring tracks. (Available only when a portable device is selected)
View Track Info	View Track Info associated with the selected track.
Edit View Track Info	Change artist name, album title, and genre for multiple tracks. Add lyrics, album art, and more.
Clear History	Erase the list of recently played tracks. Available only in the Recent window.
New Stations	Appears only when new radio stations are available. Click the New Stations button to display the Radio window.
New Music Guide	Appears only when Music Guide has been updated. Click New Music Guide to display the latest version of the Music Guide.

The Control Panel

The Control Panel provides recording and playback control as well as skip, seek (search), shuffle (random), continuous play (repeat) options. The Control Panel also offers Visualization settings, quick access to your RealPlayer, and Skin mode.



	Feature	Description
1	Record	Click to begin recording the CD in your CD drive. Click again to stop recording.
2	Play	Click to play the selected track. Click again to stop playing.
3	Pause	Click to pause playback. Click again to resume playback.
4	Stop	Click to stop both playback and recording.
5	Previous	Click to jump to previous track on the current CD or track list.
6	Next	Click to jump to next track on the current CD or track list.
7	Continuous	Play current CD or track list repeatedly.
8	Shuffle	Play current CD or track list randomly.
9	Return	Click the return button to return to the currently playing track list. For example, if you're playing a track from a Playlist, and you're browsing your Groups (Genre, Artist, Album), clicking the return button takes you back to the Playlist your track is playing from.
10	Volume Control	Click and drag the slider to pump up the volume (right) or tone it down (left). Use the arrow keys to "fine tune" your settings.
11	Progress Bar	The Progress Bar displays the current track's playback progress. You can skip forward and backward in the currently playing track by dragging the slider left (back) or right (forward).
12	Launch RealPlayer	Launches the RealPlayer.

The Status Bars

- **Play Status Bar**
This bar provides up-to-date information on the currently playing track, including the name of the track and artist and the time elapsed/length of the track. Other information includes icons that tell you whether the track is playing from a CD (CD) or a recorded music file (an icon will tell you the format), and whether the track is playing in stereo ((((. . .)))
- **Record Status Bar**
This bar provides up-to-date information on the currently recording track, including the name of the track and artist, the track number, and the recording progress. The Record Status bar only appears while a track is recording.


The Menu Bar

The menu bar offers dozens of options including navigation, preferences, playlists, plus online sites and Help. Click to open a menu, then click again to select an option.



The Header Bar

The Header Bar is the bar just above any track list. With a Group, Playlist, or All Tracks open, it contains the headers Track Name, Album, Artist, etc. You can specify which headers and columns appear in **Tools > Preferences > Display**.




Note
Tracks on CD cannot be sorted, and Playlist tracks cannot be sorted using the Header Bar.

Select tracks you have recorded on your computer and transfer them an SD Memory Card. The tracks are converted as they are transferred, so ensure you have made the correct conversion settings.



- 1
- Connect the SD Memory Card.
- 2
- Select tracks.
- 3
- Click on “Copy to” → “Device”.



- 4
- Click on “OK”.



- 5
- Click on “Begin Transfer”.
- “On Device” is shown when transfer is finished.



Note

Do not insert or remove SD Memory Cards while the “Transfer to SD card” window is being displayed.



Formatting an SD Memory Card

Format your SD Memory Card to use SD Audio data. Some or all of the data on the card will be lost when you format it. Select “Format only for SD Audio (Erase all Audio data)” under normal circumstances. Select “Format entire card (Erase all data)” only when necessary.

Note

Tracks you have transferred using software other than RealJukebox for Panasonic are also deleted when you format the card. Check the data on the card before commencing formatting. Use only the method described below to format your card. Using other methods can render the card unable to transfer or play tracks.

- 1
- Click on “Devices”.
- 2
- Double-click on “Panasonic Device”.
- 3
- Right Click on “SD Card”.
- 4
- Click on “Configure”.
- 5
- Click on “Initialize (Format)”.
- Recommended: “Format only for SD Audio (Erase all Audio data)”
- 6
- Click on [Start].
- The SD Memory Card is formatted.



Troubleshooting

Before requesting service, make the below checks and refer to the online Help. If you are in doubt about some of the check points, or if the remedies indicated in the chart do not solve the problem, refer to the directory of Authorized Service Centers (enclosed with this unit) to locate a convenient service center, consult your dealer for instructions or click on the [Service & Support] button.

Installation and startup


Problems	Check points or causes
Cannot install.	●Insert the CD-ROM. ●Ensure you have specified the correct CD-ROM drive.
Cannot start.	●Ensure the program is installed on the hard disc. The program cannot be run from the CD-ROM. ●Ensure the computer has at least 64 MB of RAM.
I want to install just the USB Reader/Writer driver.	Install the driver from the included CD-ROM. In step ④ of the installation procedure, remove the checks from RealJukebox [with Panasonic plug-in].

Copyright protection limitations

- This software includes copyright limitations decided upon by the Secure Digital Music Initiative (SDMI).
- You may be unable to use music data with this software if the data is copyright-protected or if you have recorded from a DVD-Audio player.
- Where the owner of the copyright or music data providers have set conditions with regard to the use of the data, you are obliged to abide by those conditions.
- Your attention is drawn to the fact that recording pre-recorded SD Memory Card may infringe copyright laws.
- Upgrading RealJukebox for Panasonic
RealJukebox for Panasonic follows the guidelines set by the SDMI. Future changes to these guidelines may render some functions of RealJukebox for Panasonic inoperable. Upgraded versions of RealJukebox for Panasonic will be offered in such circumstances. A charge may be applied to these upgrades.

Limitations in Windows Explorer

- SD Memory Cards are shown as external drives (for example, “D”) in Windows Explorer when they are connected to the computer.
Do not use Explorer to move SD Memory Card music data or folders, change their names, or delete them. This can render the music data unplayable. Use only RealJukebox for Panasonic for editing.
- Similarly, do not use Explorer to move, change the names of, or delete music data and folders you have saved to your computer.

- SD logo is a trademark. 
- Portions of this product are protected under copyright law and are provided under license by ARIS / SOLANA 4C.
- Microsoft and its logo as well as Windows and Windows NT are registered trademarks of Microsoft Corporation of the U.S. in both the United States and other countries.
- Pentium and MMX are registered trademarks of Intel Corporation of the U.S.
- Sound Blaster 16 is a trademark of Creative Technology, Ltd. of the U.S.
- IBM and PC/AT are registered trademarks of International Business Machines Corporation of the U.S.
- Macintosh is a registered trademark of Apple Computer, Inc. of the U.S. in both the United States and other countries.
- The Real logo, RealAudio, RealNetworks and RealPlayer are registered trademarks of RealNetworks Inc.
- RealJukebox, RealDownload, Real.com and Take 5 are trademarks of RealNetworks, Inc.
- Other names of systems and products mentioned in these instructions are usually the registered trademarks or trademarks of the manufacturers who developed the system or product concerned.
The ™ and ® marks are not used to identify registered trademarks and trademarks in these instructions.
- Licensed AAC Patents (U.S. patent numbers);

08/937,950	5,394,473	5,579,430	5,481,614	5,299,238	5,581,654
5848391	5,583,962	08/678,666	5,592,584	5,299,239	05-183,988
5,291,557	5,274,740	98/03037	5,781,888	5,299,240	5,548,574
5,451,954	5,633,981	97/02875	08/039,478	5,197,087	08/506,729
5,400,433	5,297,236	97/02874	08/211,547	5,490,170	08/576,495
5,222,189	4,914,701	98/03036	5,703,999	5,264,846	5,717,821
5,357,594	5,235,671	5,227,788	08/657,046	5,268,685	08/392,756
5,752,225	07/640,550	5,285,498	08/894,844	5,375,189	