



- 1 **Display panel**
- 2 **▶/II, CD**: to play or pause a CD
- 3 **▶, SD**: to play an SD card
- 4 **■, OPR OFF, FUNCTION**: to turn the unit off, stop play, and switch between CD and SD mode
- 5 **S-XBS**: to emphasize the bass
- 6 **MODE, DEL**: to change the play mode and delete characters
- 7 **◀ CD OPEN**: to open the CD lid
- 8 **SD OPEN ▶**: to open the SD card lid
- 9 **SD memory card lid**
- 10 **CD lid**
- 11 **REC PAUSE**: to put the unit into recording standby mode
- 12 **VOLUME buttons**
- 13 **◀◀, ▶▶**: to skip or search and to select menu items
- 14 **ENTER/MEMORY**: to enter menu items and program CD tracks
- 15 **Character/numbered buttons**
- 16 **MENU**: to enter and exit menus
- 17 **DISPLAY, CHARA**: to change the display and type of character
- 18 **📶**: earphone/remote control jack
- 19 **MIC**: microphone jack
- 20 **HOLD**: to prevent accidental operation on the main unit

- 21 **DC IN 4.5 V** : terminal for AC adaptor
- 22 **LINE IN**: to connect other equipment for recording
- 23 **◀◀, ▶▶**: to skip or search
- 24 **■/▶**: to start and stop play and to turn the unit off
- 25 **VOLUME buttons**
- 26 **Earphone jack**
- 27 **Clip**
- 28 **HOLD**: to prevent accidental operation on the remote control
- 29 **CD/SD**: to switch between CD and SD mode
- 30 **Plug**

■ Display panel

- 31 **Current mode**
- 32 **Recording mode**
- 33 **Play mode**
- 34 **S-XBS indicator**
- 35 **Battery indicator**
- 36 **Synchronized recording indicator**
- 37 **General display**: shows source, track numbers, recording level and other text information
- 38 **CD program play indicator**
- 39 **Recording indicator**
- 40 **Recording time meter**