


# Titling SD cards



## 4 Press [ENTER/MEMORY].

Steps 5 and 6 are unnecessary when titling the card. Proceed to "Entering characters" in step 6.

## 5 Press [◀◀] or [▶▶] to select the track you want to title.

## 6 Press [ENTER/MEMORY].

You can now enter characters, **Entering characters**

### 1 Press [DISPLAY, CHARG] to select the type.

Each time you press the button:

Capitals  
Lower case  
Numbers

### 2 Press the character/numbered buttons to select.

The characters change each time you press a button.

Step 3 is unnecessary when entering numbers.

### 3 Press [ENTER/MEMORY].

The character moves to the title section and the unit is ready to accept the next character.

## 7 Press [ENTER/MEMORY].

Editing is complete when "CARD Writing" goes out. When entering track titles or artist names, you can continue to enter other titles or names as necessary. Repeat the steps from step 5 and press [MENU] when you are finished.

When entering the card title, editing ends automatically.

| Button  | Alphabet   | Number     |
|---------|--|------------|
|         | CAPITALS   | lower case |
| [1]     |  |            |
| [2]     | ABC  | abc        |
| [3]     | DEF  | def        |
| [4]     | GHI  | ghi        |
| [5]     | JKL  | jkl        |
| [6]     | MNO  | mno        |
| [7]     | PQRS   | pqrs       |
| [8]     | TUV  | tuv        |
| [9]     | WXYZ   | wxyz       |
| [0]     |  |            |
| [Erase] | ␣ (space) ! " # \$ % & ' ( ) * + , - . / : ; < = > ? @ [ \ ] ^ _ ` {   } ~ |            |

You can enter up to 60 characters for card and track titles and artist names.

### Preparation:

- Press [■, OPR OFF, FUNCTION] to select SD.
- Release the write-protect switch.

### 1 Press [MENU].


"EDIT?" is displayed.

### 2 Press [ENTER/MEMORY].

### 3 Press [◀◀] or [▶▶] to select the item you want to enter.

"TRACK TITLE?"  
"TRACK ARTIST INFO?"  
"CARD TITLE?"

# Erasing tracks



### Preparation:

- Press [■, OPR OFF, FUNCTION] to select SD.
- Release the write-protect switch.

### 1 Press [MENU].

"EDIT?" is displayed.

### 2 Press [ENTER/MEMORY].

### 3 Press [◀◀] or [▶▶] to select how to erase tracks.

■ **TRACK ERASE:** Erase one track at a time

- Select "TRACK ERASE?".
- Press [ENTER/MEMORY].
- Press [◀◀] or [▶▶] to select the track you want to delete.
- Press [ENTER/MEMORY].

If you selected the wrong track

Press [◀◀] or [▶▶] to select "CANCEL?" and press [ENTER/MEMORY].

■ **ALL TRACK ERASE:** Erase all tracks on the card

- Select "ALL ERASE?".
- Press [ENTER/MEMORY].

### 4 After confirming the item to be erased, press [ENTER/MEMORY].

Erasing is complete when "CARD Writing" goes out. After erasing one track, you can continue to erase other tracks. Repeat the steps from step 3 and press [MENU] when you are finished.

After erasing all tracks, editing ends automatically.

### To stop partway

Press [MENU] before step 4.

### Note:

- ALL ERASE can take several minutes (10 or more in some cases) if there are a number of tracks on the card or if it has a large volume.
- You cannot erase tracks that are in play lists created on computer software (e.g., Panasonic Media Manager).

# Formatting SD cards

All data is erased when you format a card, including data recorded with other equipment.

### Preparation:

- Press [■, OPR OFF, FUNCTION] to select SD.
- Release the write-protect switch.

### 1 Press [MENU].

"EDIT?" is displayed.

### 2 Press [ENTER/MEMORY].

### 3 Press [◀◀] or [▶▶] to select "CARD FORMAT?".

### 4 Press [ENTER/MEMORY].

### 5 Press [ENTER/MEMORY].

Formatting is complete when "CARD Writing" goes out.

### To stop partway

Press [MENU] before step 5.