


1. CONTROLS AND COMPONENTS



- 1 Connect the Power Supply Cable from the DC Output Socket on the AC Adaptor to the DC Input Socket on the Movie Camera.
- 2 Connect to the Mains.

Note:
When a Battery Pack is attached to the AC Adaptor, the Movie Camera cannot be supplied with power.

2. DISASSEMBLY PROCEDURES

1. DISASSEMBLY FLOW CHART

This flow chart indicates the disassembly steps of the cabinet parts and the P.C. Boards in order to gain access to item(s) to be serviced.
When re-assembling, perform the step(s) in the reverse order.

Note:
When removing the Top Case Unit, work with care so as not to break the locking portions of the Top Case Unit.




Fig. A1

2. DISASSEMBLY METHOD

Step /Loc No.	Part	REMOVAL		
		Fig. No.	Remove *UNLOCK/RELEASE/ UNPLUG/UNCLAMP	Note
①	Top Case	A2 A4	3 (S-1) 2 (L-1)	BOTTOM SIDE
②	Main C.B.A.	A3	-----	---
③	Switch C.B.A.	A4	2 (S-2)	---

List of Abbreviations:
3 (S-1) =3 Screws (S-1)
2 (L-1) =2 Locking Tabs (L-1)




Fig. A2




Fig. A3




Fig. A4