


TO  
MAIN CONNECTION  
FP801

FP603-1	BLD	19
FP603-2	NOREG GND	18
FP603-3	NOREG GND	17
FP603-4	BL 6V	16
FP603-5	BL 6V	15
FP603-6	EVF 12V	14
FP603-7	GND	13
FP603-8	GND	12
FP603-9	VST	11
FP603-10	VCK	10
FP603-11	EN	9
FP603-12	EVF ON (H)	8
FP603-13	HST	7
FP603-14	HCK2	6
FP603-15	HCK1	5
FP603-16	E B OUT	4
FP603-17	E R OUT	3
FP603-18	E G OUT	2
FP603-19	E COM	1

➔ :VIDEO MAIN SIGNAL PATH

TO  
EVF LCD PANEL  
FP802

1	VDD
2	VSS
3	VST
4	VCK
5	TEST2
6	EN
7	TEST1
8	RGT
9	HST
10	HCK2
11	HCK1
12	BLK
13	BLUE
14	RED
15	GREEN
16	COM



NOTE:  
DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC  
DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE  
REFER TO PARTS LIST.

NOTE:  
THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS  
DIAGRAM IS STOP MODE.(EVF:ON)