

TO
GRIP FLEX.CARD
FP6103

| | |
|--------------|----|
| D GND | 33 |
| D GND | 32 |
| PWR RST | 31 |
| S/S | 30 |
| SCAN2 | 29 |
| POWER SW | 28 |
| SCAN1 | 27 |
| MODE | 26 |
| CAM LED | 25 |
| DSC LED | 24 |
| VTR LED | 23 |
| MEM/PHOTO SW | 22 |
| SCAN2 | 21 |
| DEW | 20 |
| Z SW2 | 19 |
| Z SW1 | 18 |
| A V REF | 17 |
| ZOOM AD | 16 |
| PHOTO SHOT | 15 |
| SCAN3 | 14 |
| SP OUT2 | 13 |
| SP OUT2 | 12 |
| SP OUT1 | 11 |
| SP OUT1 | 10 |
| MMC LED | 9 |
| | 8 |
| | 7 |
| | 6 |
| LI BATT(+) | 5 |
| | 4 |
| | 3 |
| | 2 |
| D GND | 1 |

R6101
330
B6101
VSB0407

LITHIUM
BATTERY

D6103 B3ADB0000029
CARD P.B.


D6101 B3AAB0000067
D6102 SML-310MTT86
S6104 KOD112B00074
TAPE/CARD

CAMERA

VCR

ACCESS

RESET



TO
POWER S/S FLEX.
FP6102

| | |
|---|----------|
| 8 | S/S |
| 7 | SCAN2 |
| 6 | |
| 5 | POWER SW |
| 4 | |
| 3 | D GND |
| 2 | SCAN1 |
| 1 | MODE |

TO
ZOOM VR UNIT
FP6101

| | |
|---|------------|
| 1 | SCAN3 |
| 2 | PHOTO SHOT |
| 3 | Z SW1 |
| 4 | Z SW2 |
| 5 | A V REF |
| 6 | ZOOM AD |
| 7 | SW GND |
| 8 | |

NOTE:
DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC
DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE
REFER TO PARTS LIST.

1

2

3

4