

(CASSETTE DOWN FLEX. CARD)

B

EJECT

C DOWN

S6212

S6211

A

TO  
MAIN CONNECTION

5	C DOWN
4	GND
3	GND
2	
1	EJECT SW

TO FP6506

NV-MX500EG/B/EN/A/ENT  
MAIN FRAME UNIT(CASSETTE DOWN FLEX.)  
SCHEMATIC DIAGRAM

1

2

3

4