

AUDIO/VIDEO STEREO RECEIVER
AMPLI-SYNTONISEUR STEREO
AUDIO/VIDEO
AUDIO/VIDEO STEREO-EMPFÄNGER
SINTOAMPLIFICATORE STEREO
AUDIO/VIDEO


Operating Instructions

Mode d'emploi

Bedienungsanleitung

Istruzioni per l'uso

VSX-806RDS



 **PIONEER®**

IMPORTANT



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**

CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Thank you for buying this Pioneer product. Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.

In some countries or regions, the shape of the power plug and power outlet may sometimes differ from that shown in the explanatory drawings. However the method of connecting and operating the unit is the same.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

This product complies with the Low Voltage Directive (73/23/EEC), EMC Directives (89/336/EEC, 92/31/EEC) and CE Marking Directive (93/68/EEC).

VENTILATION

- When installing this unit, make sure to leave space around the unit for ventilation to improve heat radiation (at least 60 cm at top, 10 cm at rear, and 30 cm at each side). If not enough space is provided between the unit and walls or other equipment, heat will build up inside, interfering with performance or causing malfunctions.
- Do not place on a thick carpet, bed, sofa or fabric having a thick pile. Do not cover with fabric or other covering. Anything that blocks ventilation will cause internal temperature to rise, which may lead to breakdown or fire hazard.

FEATURES

DOLBY PRO LOGIC COMPATIBLE

Best suited for playing back movies and music by reproducing surround effects.

60 W 5 ch EQUAL POWER DISCRETE AMPLIFIER

5 ch equal power discrete amplifier which plays back the high quality effects of Dolby Pro Logic.

5-D THEATER

The 5-D THEATER function provides clear dynamic sound effects by outputting audio signals through the rear channel to simulate stereo sound.

TWO SFC MODES

Reproduces STUDIO and ARENA surround effects.

RDS (Radio Data System)

FM broadcast stations display transmitting information.

CONTENTS

1 BEFORE USE

CHECKING ACCESSORIES	7
REMOTE CONTROL UNIT	7
INSTALLATION	8

2 NAMES AND CONNECTIONS OF PARTS

NAMES OF PARTS	9
CONNECTING DEVICES	12

3 BASIC OPERATIONS

LISTENING TO FM/AM BROADCASTS	14
RECORDING	18
OPERATING OTHER COMPONENTS (PIONEER products bearing the  mark only)	20
CD PLAYER operation	20
LD PLAYER operation	20
CASSETTE DECK operation	21
DVD PLAYER operation	21
TV operation	22

4 VARIOUS OPERATIONS

ENJOYING SURROUND EFFECTS	23
RDS (Radio Data System) BROADCAST RECEPTION	26

5 OTHER

SURROUND	31
RDS (Radio Data System)	32
TROUBLESHOOTING	35
SPECIFICATIONS	37




READING THIS MANUAL


■Meaning of Marks



Provides detailed precautions and advice on operations, etc.



Indicates that buttons or displays are blinking.



Indicates that buttons or displays are lit.



Indicates that display changes automatically.

■Meaning of Illustrations


The following describes illustrations on pressing buttons.



Means to press the RECEIVER POWER button (of the remote control unit).



Means to press the ENTER button (of the main unit).




Means to rotate (adjust) the MULTI JOG.

1. BEFORE USE


CHECKING ACCESSORIES




FM antenna



AM loop antenna



Remote control unit




Dry cell battery (size "AA" IEC R6) x 2

REMOTE CONTROL UNIT


Loading remote control batteries

1.



2.

Dry cell batteries (size "AA" IEC R6)




CAUTIONS

Incorrect use of batteries may result in such hazards as leakage and bursting.

Observe the following precautions.

- Never use new and old batteries together.
- Insert the plus and minus sides of the batteries properly according to the marks in the battery case.
- Batteries with the same shape may have different voltages. Do not use different batteries together.

Operating range of the remote control unit




memo

- The remote control unit may not work if there is an obstacle between the remote control unit and this unit, or if the remote control unit is not directed towards the remote sensor of the main unit at the correct angle.
- The remote control unit may not work properly if strong light such as direct sunlight or fluorescent light is shining onto the main unit's remote sensor.
- The remote control unit may not work properly when this unit is used near devices emitting infrared rays, or when remote control units of other devices which use infrared rays are used. On the other hand, the use of this remote control unit may cause other devices to work improperly.
- When the operating range of this remote control unit becomes too short, replace the batteries.

Operating the remote control unit

By connecting a control cord (optional), other PIONEER products can be operated using this remote control unit via this unit. Direct the remote control unit towards the remote sensor of this unit.

The remote control signals are received by the remote sensor of this unit, and sent to the other devices via the CONTROL OUT terminal.




BEFORE USE

INSTALLATION

Installing speakers

To achieve the best surround effects, install speakers as shown in the following figure.

Installation Example




* In the above figure, F indicates front speakers, R indicates rear speakers, C indicates center speaker, SW indicates sub woofer, r indicates right, and l indicates left.

memo

- If installing the rear speakers far away from the front and center speakers, surround effects cannot be fully achieved.
- Installing speakers near the TV may cause interference such as the TV color to change. In such cases, use magnetically shielded speakers or install the speakers away from the TV.
- Install the left and right speakers at equal distance from the TV.
- Install the center speaker at the top, bottom, or behind the TV so that TV sound and images match.
- It is recommended to install the rear speakers slightly above ear level.

Installing the cassette deck

Installing the cassette deck in the following (A) positions in the figure may affect playback. It is recommended that it be installed in the (B) position.




2 NAMES AND CONNECTIONS OF PARTS

NAMES OF PARTS

* The size of characters shown in the figure may differ from that on the actual product.


Front panel



- | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>① SFC MODE button (P.23)</p> <p>② STANDBY indicator</p> <p>③ DOLBY PRO LOGIC button
Switches DOLBY PRO LOGIC SURROUND on and off.</p> <p>④ 5-D THEATER button (P.25)</p> <p>⑤ LOUDNESS button
Press this button when the volume is low to raise the low and high range levels so that the sound can be heard more easily.</p> <p>⑥ Display</p> <p>⑦ POWER STANDBY/ON button</p> <p>⑧ RF ATT button
Set this button to on when receiving strong FM signals (nearby stations) to reduce sound distortion. Normally, this button should be set off. This button does not affect AM reception.</p> <p>⑨ EON MODE button (P.30)</p> <p>⑩ CLASS button (P.16)</p> <p>⑪ SELECT button (P.15~)
Use to switch the control of the MULTI JOG between station mode and frequency mode when operating the tuner.</p> <p>⑫ Function buttons (P.15~)</p> | <p>⑬ MAIN POWER switch</p> <p>⑭ PHONES jack (Headphone terminal)</p> <p>⑮ TONE and BALANCE controls
Use to adjust tone and volume balance.</p> <p>⑯ SPEAKERS A, B buttons
ON/OFF switches for the A and B speaker systems.</p> <p>⑰ DIRECT button
Use to play back sound without going through the tone and balance control circuits. DOLBY MODE, DSP MODE and LOUDNESS also turn off.</p> <p>⑱ MEMORY button (P.16)</p> <p>⑲ FM/AM button (P.15)
Use to switch the FM/AM frequency band reception.</p> <p>⑳ ENTER button (P.16~)</p> <p>㉑ MULTI JOG (P.15~)</p> <p>㉒ MASTER VOLUME</p> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

NAMES AND CONNECTIONS OF PARTS

Display



① **Speakers A, B indicator**

The indicator of the speaker system (A, B) selected will light.

② **PRO LOGIC indicator**

Lights when Dolby Pro Logic is selected.

③ **LOUDNESS indicator**

Lights when LOUDNESS is ON.

④ **SFC indicator**

Lights when the SFC mode is selected.

⑤ **5-D THEATER indicator**

Lights in the 5-D THEATER mode.

⑥ **DIRECT indicator**

Lights when DIRECT is ON.

⑦ **TAPE 2 indicator**

Lights when TAPE 2 MONITOR is ON.

⑧ **CLASS 1, 2, 3 indicators**

The indicator of the class number selected lights.

⑨ **EON MODE indicator**

Lights when EON MODE is ON.

⑩ **RF ATT indicator**

⑪ **RDS indicator**

Lights when a RDS broadcast is received.

⑫ **TUNER indicator**

MONO:

Lights when the monaural mode is set using the MPX MODE button.

TUNED:

Lights when broadcasts are being received.

STEREO:

Lights when stereo broadcasts are received during auto stereo mode.

⑬ **EON indicator**

Lights when a station broadcasting EON information is received.

⑭ **JOG MODE indicator**

ST:

Lights when the station mode is selected.

FREQ:

Lights when the frequency mode is selected.

CHARA:

Lights when the station name memory mode is selected.

SEARCH:

Lights when the program type search mode is selected.

⑮ **MEMORY indicator**

Lights when station memory mode is set.

⑯ **AM/FM indicators**


The indicator of the band currently selected (AM/FM) lights.

⑰ **CHARACTER display**

⑱ **STATION display**

Indicates the station number currently selected.

Remote control unit



① CD/LD buttons

(When the MODE switch is set to AUDIO)

Sets CD.
CD POWER ON/OFF, DISC $-/+$, RANDOM, BEST, \square , \triangleright , \lll , \ggg , \square , \lll , \ggg

(When the MODE switch is set to VIDEO)

Sets LD.
LD POWER ON/OFF, SIDE A/B, \square , \triangleright , \lll , \ggg , \square , \lll , \ggg , \ggg

② TAPE/DVD buttons

(When the MODE switch is set to AUDIO)

Sets TAPE DECK.
TAPE POWER ON/OFF, \square , \lll , \ggg , DECK I/II, \square , \lll , \ggg

(When the MODE switch is set to VIDEO)

Sets DVD.
DVD POWER ON/OFF, AUDIO, \square , \triangleright , \lll , \ggg , \square , \lll , \ggg , \ggg

③ TUNER/TV buttons

(When the MODE switch is set to AUDIO)

Sets FM/AM tuner.
DISP. MODE, RF ATT, MPX, CLASS, D. ACCESS, FM/AM, FREQ $-/+$

MPX

Use to switch the auto stereo/monaural mode for receiving FM broadcasts. When the received broadcast signal is weak, press this button to set the monaural mode.

(When the MODE switch is set to VIDEO)

Sets TV.
TV POWER ON/OFF, MUTE, TV VOL $-/+$, DISPLAY, I/II, TV FUNC, TV CH $-/+$

④ Number buttons


⑤ RECEIVER buttons

PRO LOGIC

Use to turn ON/OFF DOLBY PRO LOGIC surround.


SFC MODE

Use to select from 2 types of SFC MODE.



5-D THEATER

Use to select from 2 types of 5-D THEATER.



TEST TONE/C.MODE

(When the MODE switch is set to VIDEO)

TEST TONE

When SFC MODE or DOLBY PRO LOGIC is ON, volume balance adjustment signals are output in order from each speaker and center/rear level can be adjusted.

(When the MODE switch is set to AUDIO)

C.MODE

Switches the center mode.



CENTER LEVEL $-/+$

Adjusts the center level.

RECEIVER POWER

Use to switch the RECEIVER power to ON or STANDBY.

REAR LEVEL $-/+$

Adjusts the rear level.

⑥ MODE switch

Use to switch the remote control unit modes.

⑦ DIRECT button

⑧ MUTING button

Turns ON when the volume is muted.

⑨ MASTER VOLUME $-/+$ buttons

Use to adjust the volume.

⑩ TAPE 2/FUNC. button

(When the MODE switch is set to VIDEO)

TAPE 2

Use to turn ON the TAPE 2 monitor.

(When the MODE switch is set to AUDIO)

FUNC. (FUNCTION)

Use to switch the function.


⑪ LOUD. (LOUDNESS) button



CONNECTING DEVICES


Before making or changing the connections, switch off the power switch and disconnect the power cord from the AC outlet.

■ For better reception of signals, use an FM external antenna.





■ When AM broadcast reception is poor

Connect a 5 to 6 meter long vinyl-coated wire to the AM antenna terminal. If possible draw horizontally outdoors to achieve better reception.




Don't detach the AM loop antenna.

■ Assembling the AM loop antenna





When attaching on a wall, etc.



Face towards the direction with the best reception.

Stretch out fully and secure onto the wall using pins.



■ AM antenna terminal

■ Input/output plugs


Connect the white plug to L, red plug to R, and yellow plug to VIDEO. Be sure to insert completely.

■ Speaker terminals

REAR, CENTER speaker

FRONT speaker

* The size of characters and terminal positions in the figures may differ from those on the actual product.



* The sub woofer can be connected in a different way. For details, refer to the instructions on the sub woofer.



Use nominal impedances ranging from 8Ω to 16Ω for the speaker system. When using the only front speakers, use nominal impedances ranging from 4Ω to 16Ω .


3 BASIC OPERATIONS

Turn ON the MAIN POWER button of this unit.

LISTENING TO FM/AM BROADCASTS




Turn OFF TAPE 2 MONITOR (the Indicator goes off).



1. Turn ON the power of the receiver.



→ STANDBY indicator goes off.





2. Set the mode switch to AUDIO.



3. Select the TUNER function.



4. Select the band (FM or AM).



5. Select the broadcast station.



Refer to "Selecting broadcast stations" below.

6. Adjust the volume.



Selecting broadcast stations


① Selecting step by step



Press lightly and release.

87.50
87.55
87.60
⋮

② Selecting automatically



(Press and hold for approx. 1 second, then release.)

87.50
↓
89.50

Stops when received.

③ Selecting at high speed




Press continuously.

87.50
87.55
⋮
89.50

Stops when released.





■ **Selecting a broadcast station using this unit**

1. Press the **POWER STANDBY/ON** button to turn the power ON.
2. Set the **TUNER** function.
3. Press the **FM/AM** button and select FM or AM broadcast.
4. Press the **SELECT** button, to set the frequency mode. **FREQ** indicator lights.
5. Rotate the **MULTI-JOG** and adjust to the desired broadcast station. The **TUNED** indicator lights up when a broadcast program is received.
6. Adjust the volume.




- The **TUNED** indicator will not light when a broadcast station is too far away or when the broadcasting signal is weak.
- The **MULTI JOG** cannot be used in "■ Selecting the broadcast station (② Selecting automatically)" on page 14.

Directly inputting the frequency [Direct Access (remote control unit only)]


A broadcast station (frequency) can be directly selected using the number buttons on the remote control unit.



Turn OFF the **TAPE 2 MONITOR** (the indicator goes off).




1. Set the mode switch to **AUDIO**.
2. Select the **TUNER** function.
3. Select the band (**FM** or **AM**).
4. Set the direct access mode.
5. Select the broadcast station.



Press the numbers of the frequency to be received in order.


For example, to receive FM 106,00 MHz.



■ **Canceling the frequency input**

The frequency input can be canceled by pressing the **D.ACCESS** button again. Input the frequency again correctly after pressing the **D.ACCESS** button again.

Memorizing frequently used stations (Main unit only)



- The frequency received, MPX MODE (FM only) and also RF ATT (FM only) can be memorized.
- Up to 10 stations can be memorized in each of three classes.

1. Receive the desired station. ➔ Refer to "Listening to FM/AM broadcasts" (Pages 14 and 15).


2. Set the MEMORY mode.

MEMORY





3. Select the desired class number.


CLASS



4. Select the desired station number.




Rotate the MULTI JOG to select the station number and press the ENTER button to memorize the selection. (Even if ENTER is not pressed, the selection will be automatically memorized in 5 seconds.)



Repeat steps 1 to 4 to memorize up to 30 stations.


Listening to Memorized Stations






1. Set the mode switch to AUDIO.




2. Select the TUNER function.



3. Select the CLASS number in which the desired station is memorized.



4. Select the station number of the desired station.




Example:
When FM99,50 MHz has been memorized in channel 7 of CLASS 2.



Use the CHANNEL +/- buttons to select other memorized station numbers.

■ Operating with the main unit

1. Press the TUNER button.
2. Press the SELECT button to set the station mode.
The ST indicator lights.
3. Press the CLASS button, and select the CLASS number in which the desired station has been memorized.
4. Rotate the MULTI-JOG, and select the desired station number which has been memorized.



When the power cord of the unit is disconnected from the wall outlet or the main power switch is turned off for several days, the stations memorized will be erased.

■ Last Station Memory

By turning ON the power and setting TUNER, the station set before the power was turned OFF will be received.




RECORDING

Recording with TAPE 1 or TAPE 2




Turn ON the power of all equipment to be used.



1. Set the mode switch to AUDIO.




2. Select the source to be recorded.



3. Start recording with TAPE 1 or TAPE 2.

4. Play back the source to be recorded.



■ Operating with the main unit

1. Select the source to be recorded using the Function buttons.
2. Start recording with TAPE 1 or TAPE 2.
3. Play back the source to be recorded.




- The VCR/TAPE 1 sounds cannot be recorded with TAPE 1.
- The volume, tone, balance, and surround setting of this unit have no effect on the recording signal.

■ Recording Monitor

When recording with TAPE 2, if the recording device connected has a recording monitor function, turning ON the TAPE 2 MONITOR button will enable recording to be carried out simultaneously with playback monitoring (the TAPE 2 indicator lights).


Recording with a VCR



1. Set the mode switch to AUDIO.



2. Select the source to be recorded.




3. Start recording with a VCR.

4. Play back the source to be recorded.



The signal from VCR/TAPE 1 cannot be recorded.




■ Operating with the main unit

1. Select the source to be recorded using the Function buttons.
2. Start recording with a VCR.
3. Play back the source to be recorded.



The volume, tone, balance, and surround setting of this unit have no effect on the recording signal.





OPERATING OTHER COMPONENTS
(PIONEER products bearing the SR mark only)

CD PLAYER operation

Switch the function to CD, switch the **MODE switch** to **AUDIO**, and operate as desired using the following buttons.


- ① **CD POWER**
Use to turn ON/OFF the CD player.
- ② **DISC -/+**
Use to select the disc for CD players which can play several discs.
- ③ **RANDOM**
Plays the tracks randomly.
- ④ **BEST**
Use to select and listen to only the desired songs. When pressed at the desired song while playing back CDs, the unit will memorize the track number, and play only the memorized songs later.

- ⑤ **⏮**
Pressing and releasing this button immediately returns playback to the beginning of the track currently being played. Pressing it continuously returns playback to the beginning of a previous track.
- ⑥ **⏭**
Pressing and releasing this button immediately advances playback to the beginning of the next track. Pressing it continuously advances playback to the beginning of a future track.
- ⑦ **▶**
Starts playback.
- ⑧ **■**
Stops playback.
- ⑨ **⏩**
Continuously pressing this button will set fast forward playback.
- ⑩ **⏪**
Continuously pressing this button will set fast rewind playback.
- ⑪ **⏸**
Use to pause playback.

LD PLAYER operation

Switch the function to LD, switch the **MODE switch** to **VIDEO**, and operate as desired using the following buttons.

- ① **LD POWER**
Use to turn ON/OFF the LD player.
- ② **SIDE A/B**
Switches between sides A and B of the disc.
- ⑤ **⏮**
Pressing and releasing this button immediately returns playback to the beginning of the chapter (track) currently being played. Pressing it continuously returns playback to the beginning of a previous chapter (track).
- ⑥ **⏭**
Pressing and releasing this button immediately advances playback to the beginning of the next chapter (track). Pressing it continuously advances playback to the beginning of a future chapter (track).
- ⑦ **▶**
Starts playback.
- ⑧ **■**
Pressing this button during playback will stop the unit. (With some LD players, the disc table may come out if pressed during stop.)
- ⑨ **⏩**
Continuously pressing this button will set fast forward playback.
- ⑩ **⏪**
Continuously pressing this button will set fast rewind playback.
- ⑪ **⏸**
Use to pause. (In some players, pressing this button may set still pictures.)



- ⑨ ◀◀ Rewinds the tape. Pressing this button during playback will start fast rewind playback.
- ⑩ || Pauses playback and recording.

DVD PLAYER operation


Switch the function to DVD/TV, switch the MODE switch to VIDEO, and operate as desired using the following buttons.

- ① ■ Pressing this button during playback will stop the unit.
- ② **AUDIO**
Use to select a sound mode.
- ③ **DVD POWER**
Use to turn ON/OFF the DVD player.
- ④ ◀◀ Pressing and releasing this button immediately returns playback to the beginning of the chapter (track) currently being played. Pressing it continuously returns playback to the beginning of a previous chapter (track).
- ⑤ ▶▶ Pressing and releasing this button immediately advances playback to the beginning of the next chapter (track). Pressing it continuously advances playback to the beginning of a future chapter (track).
- ⑦ ▶ Starts playback.
- ⑧ ▶▶ Continuously pressing this button will start fast forward playback.
- ⑨ ◀◀ Continuously pressing this button will set fast rewind playback.
- ⑩ || Use to pause. (In some players, pressing this button may set still pictures.)

CASSETTE DECK operation

Switch the function to VCR/TAPE 1 or TAPE 2 MONITOR, switch the MODE switch to AUDIO, and operate as desired using the following buttons. When operating a single deck, press the DECK II button first.

- ① ■ Stops tape running.
- ③ **TAPE POWER**
Use to turn ON/OFF the cassette deck.
- ④ **DECK I**
Press to operate DECK I for double decks.
- ⑤ **DECK II**
Press to operate DECK II for double decks.
- ⑥ ◀ Plays in the arrow direction.
- ⑦ ▶ Plays in the arrow direction.
- ⑧ ▶▶ Fast forwards the tape. Pressing this button during playback will start fast forward playback.



TV operation

Switch the function to DVD/TV, switch the MODE switch to VIDEO, and operate as desired using the following buttons.

- ① **MUTE**
Use to mute the TV volume.
- ② **TV POWER**
Use to turn ON/OFF the TV.
- ③ **DISPLAY**
Displays the state of TV setting.
- ④ **I/II**
Use to select a sound mode.
- ⑤ **TV VOL -/+**
Use to adjust the TV volume.
- ⑥ **TV CH -/+**
Use to select a TV broadcast channel.
- ⑦ **TV FUNC. (FUNCTION)**
Use to select the TV input.




If your unit does not have a certain function, it will not respond when the button of that function on the remote control unit is pressed.

4. VARIOUS OPERATIONS


ENJOYING SURROUND EFFECTS

Switching the SFC MODE




SFC MODE


Select the sound effects.



Refer to page 31 for the characteristics of the surround effects.




SFC MODE



■ Operating with the main unit


Press the SFC MODE button.

Each time it is pressed, the surround effects change as follows.




Switching the Dolby Pro Logic

When the Dolby mode is ON, Dolby Pro Logic Surround is automatically switched according to the input signal, and playback is performed.




PRO LOGIC

Switch Dolby Pro Logic .



Each time it is pressed, the mode is turned ON/OFF.

DOLBY PRO LOGIC




■ Operating with the main unit


Press the DOLBY PRO LOGIC button.

Dolby Pro Logic is turned ON/OFF each time it is pressed.

Enjoying movie and music sources in surround mode




1. Select Dolby Pro Logic or SFC mode.




Only when Dolby Pro Logic is selected

2. Select the center mode.
(Before operating, switch the MODE switch to AUDIO.)





Refer to page 31 for the characteristics of the center modes.




3. Adjust to the desired volume.




4. Set the test tone.
(Before operating, switch the MODE switch to VIDEO.)



5. Adjust the center level, rear level, so that the test tone volume output from each speaker is the same.*1



6. Turn OFF the test tone.




7. Play the desired source.



*1 When PHANTOM is selected in the center mode or when SFC mode is selected, no test tone is output from the center speaker.

*2 When 3CH LOGIC is selected in the center mode, no test tone from the rear speaker is output.

Turning ON 5-D THEATER



The 5-D THEATER function provides clear dynamic sound effects by outputting audio signals through the rear channel to simulate stereo sound. Select from the two modes according to the source.

① 5-D PRO LOGIC

Suitable for DOLBY PRO LOGIC surround sources with lots of movement such as action movies. It provides sounds with more speed.

② 5-D SURROUND




Suitable for stereo sources (CD, etc.).

Mixing the surround effects with the 5-D THEATER effects will provide sound with depth.




Effects may be less in scenes where sounds do not shift between L and R channels.

Select the 5-D THEATER mode.




5-D THEATER



■ Operating with the main unit

Press the 5-D THEATER button.


The mode is switched as follows with each press.




RDS (Radio Data System) BROADCAST RECEPTION

Refer to page 32 for RDS (Radio Data System) details.


Displaying the RDS data (remote control unit only)




1. Set the mode switch to AUDIO.



2. Select the TUNER function.




3. Select FM.




* If the received broadcast transmits RDS data, the RDS indicator lights, and the data of the display mode appears in the display.

4. Select a mode.




The display changes by pressing the DISP MODE button.



memo

- In the RT mode, should any noise be picked up while displaying the RT scroll, some characters may temporarily be incorrectly displayed.
- In the RT mode, when no RT data is transmitted from a broadcast station, "NO RADIO TEXT DATA" is displayed once and after that the PS data is displayed.
- In PTY mode during RDS broadcast reception, there are cases where "NO TYPE" is displayed. In this case, it will automatically switch to PS mode after a few seconds.
- When reception conditions are strong, and RDS data is incorrectly displayed, press the RF ATT button.

Memorizing a desired broadcast station name (Manual Station Name Memory) (Main unit only)



- Four characters can be memorized for each broadcast station.
- If a preset class number or station number is memorized, the old memorized data will be erased.
- The memorized name takes priority over the PS data and will be displayed.

1. Receive the desired station. → Refer to "Listening to FM/AM broadcasts" (Pages 14 and 15).


2. Select the character input mode.

SELECT



* Each time you press the SELECT button, the JOG MODE indicator changes as follows.



When FM is selected:



When AM is selected:



3. Enter the broadcast station name.




* Turn the MULTI JOG to display the desired character. (Refer to "Character display used station name input" on page 34.)

ENTER




Press the ENTER button to input the first of four characters. After four characters have been entered, the MEMORY indicator lights.






4. Select the desired class number.

CLASS



5. Select the desired station number.



Example:
When the station name WEST is memorized to 4 ch of CLASS 1.

6. Set the memory.

ENTER



Repeat steps 1 to 6 to memorize up to 30 broadcast station names.


■ To erase and change the memorized station name

Perform the procedures of “Memorizing a desired broadcast station name” and input four spaces to erase the memorized station name. When you want to change a memorized station name, input the new station name using the same procedure.



For greater convenience, record memorized station names in the STATION “memo” on page 34.


Searching for a desired program by program type (PTY) (Main unit only)




1. Select the FM band.

➔ Refer to "Listening to FM/AM broadcasts" (Pages 14 and 15).



2. Select the PTY search mode.



* Each time you press the SELECT button, the JOG MODE indicator changes as follows.




3. Select the desired program type.



* Refer to pages 33 and 34 for program types.

4. Search the selected program.




➔ Searches randomly for a memorized broadcast station. Press the ENTER button within 5 seconds after the desired program has been found. If the ENTER button is not pressed, the function will search for the next station automatically.



This function searches RDS stations preset in the 30ch memory. If this function is set when no stations have been preset, "NO PTY" will be displayed. And if the desired PTY could not be found amongst the RDS stations searched in the memory, the same display will appear.

Setting EON (Main unit only)





Refer to page 32 for EON details.

1. Receive the desired EON FM station. → Refer to "Listening to FM/AM broadcasts" (Pages 14 and 15).

2. Select the mode.

EON MODE



* When it is set to OFF, a receiving frequency or a memorized station name will be displayed.



- The EON mode is cancelled if you switch to AM reception during setting EON. It starts once more when you return to FM reception.
- Simultaneous request waiting for Traffic Information (TA) and News programs is not possible.
- Some functions cannot be used while the EON MODE indicator lights or flashes.
- Function other than TUNER cannot be changed while the EON MODE indicator flashes (receiving on EON broadcast).
If you want to change to a function other than TUNER, press the EON MODE button and turn the EON MODE off.
- You cannot listen to Traffic Information (TA) and News programs when you playback TAPE 2 while setting EON.