

CB CHANNEL FREQUENCY LIST

| Channel | Channel | Channel | Channel |
|---------|-----------|---------|-----------|
| 1 | 26.965MHz | 21 | 27.215MHz |
| 2 | 26.975MHz | 22 | 27.225MHz |
| 3 | 26.985MHz | 23 | 27.255MHz |
| 4 | 27.005MHz | 24 | 27.235MHz |
| 5 | 27.015MHz | 25 | 27.245MHz |
| 6 | 27.025MHz | 26 | 27.265MHz |
| 7 | 27.035MHz | 27 | 27.275MHz |
| 8 | 27.055MHz | 28 | 27.285MHz |
| 9 | 27.065MHz | 29 | 27.295MHz |
| 10 | 27.075MHz | 30 | 27.305MHz |
| 11 | 27.085MHz | 31 | 27.315MHz |
| 12 | 27.105MHz | 32 | 27.325MHz |
| 13 | 27.115MHz | 33 | 27.335MHz |
| 14 | 27.125MHz | 34 | 27.345MHz |
| 15 | 27.135MHz | 35 | 27.385MHz |
| 16 | 27.155MHz | 36 | 27.365MHz |
| 17 | 27.165MHz | 37 | 27.375MHz |
| 18 | 27.175MHz | 38 | 27.385MHz |
| 19 | 27.185MHz | 39 | 27.395MHz |
| 20 | 27.205MHz | 40 | 27.405MHz |

NOAA WEATHER CHANNEL LIST

| Channel | Channel | Channel | Channel |
|---------|------------|---------|------------|
| 1 | 162.550MHz | 4 | 162.425MHz |
| 2 | 162.400MHz | 5 | 162.450MHz |
| 3 | 162.475MHz | 6 | 162.500MHz |