

Troubleshooting and Adjustment

If a problem occurs with your TR-193WX Base Station, please check the following:

1. Check connections to the source of power and make sure it is a working ("live") 120V AC outlet.
2. Check the AC fuse (GMA 3 amp) in the back panel. The main power lead (red wire) in the DC cord has a 2 Amp 3AG type fuse in its holder. Use only these types of fuses for maximum protection. Failure to do so will void the warranty.
3. Make certain the microphone is properly plugged in.
4. Make certain the antenna is properly connected.

Adjustment Warning

Replacement or substitution of certain parts with replacements other than those recommended by Your Dealer, may be a violation of the technical regulations of part 95 of the FCC Rules, or of Type Acceptance requirements of Part 2 of said rules.

When making adjustments other than transmitter adjustments, be sure to re-read applicable portions of this instruction manual to make certain you are following correct procedure and that the radio was properly installed, etc.