

Contents	Page
Warnings and Safety Instructions	1, 2
What is Weather Radio?	3
Specifications	4, 5
Installation	
Location	6
Base Station Antenna	6
Remote Speaker	6
Operation	
Controls and Indicators	7, 8, 9
Operating Procedure to Receive	9
Operating Procedure to Transmit	10
Operating Procedure to Receive Weatherband	10
Alternate Microphones	11
Troubleshooting and Adjustment	12

Warnings and Safety Instructions

IMPORTANT: Please read and adhere to all warnings and safety instructions below and the operating instructions that follow:



The lightning flash with arrowhead symbol within an equilateral triangle, is intended to alert you to the presence of uninsulated "dangerous voltage" within this product's enclosure that may be sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point symbol within an equilateral triangle, is intended to alert you to the presence of important operating and maintenance (servicing) instruction in the literature accompanying the appliance.

1. Do not expose the TR-193WX base station transceiver to water or moisture; for example, do not locate the unit near a bathtub, sink, swimming pool or in a wet basement.
2. Do not locate the TR-193WX where there is insufficient space for proper ventilation; for example, on a bed, rug, in a bookcase—wherever air will be prevented from flowing freely through the vent openings located on the bottom of the cabinet.
3. Do not expose the TR-193WX to extreme heat such as from a stove or radiator.
4. Connect the TR-193WX only to a 120-volt, 60 Hz AC power source.
5. Route the TR-193WX power cord so as to avoid its being pinched, stepped on, or melted by heat from a hot stove or radiator.
6. To clean the TR-193WX base station, first unplug the AC power cord; then use only a soft, damp (not wet) cloth.
7. Take care to avoid liquids spilling into or objects falling on, the TR-193WX.
8. Do not attempt to disassemble the unit. It does not contain customer-serviceable components.
9. The TR-193WX base station should be serviced (only by qualified personnel) whenever:
 - a. The AC power cord or plug is damaged.
 - b. The system is exposed to rain or moisture.
 - c. The unit is dropped or the cabinet is damaged.
 - d. The transceiver does not operate normally, or when a change in operation occurs.
10. Nonuse Periods—The power cord of the TR-193WX should be unplugged from the outlet when left unused for a long period of time.