



ROHDE & SCHWARZ

Test and Measurement

Division

Release Notes

3G FDD UE

Application Firmware R&S FS-K73

Release 4.61

for R&S FSP, FSU, FSQ, FSG, FSMR, FSUP, FMU
Analyzer Firmware 4.6x

Release Note Revision: 3

Printed in the Federal Republic of Germany

Contents

History	2
General Topics	2
Hardware Requirements	2
Compatibility of the R&S FS-K73 3G FDD UE Application Firmware.....	3
Firmware Update of the R&S FS-K73 3G FDD UE Application Firmware	4
Enabling the Application Firmware via License Key Code Entry.....	4
New Functions in Version V4.61	4
Improvements with Version V4.61	5
Modified Functions	5
Modifications to the Operating Manual	6
Modified Chapters for manual operation	6
Modified Chapters for remote operation.....	6
Customer Support	7
Technical support – where and when you need it	7
Up-to-date information and upgrades	7

History

Date	Rel Note Rev	Changes
17 June 2010	1	First revision for R&S FS-K73 version 4.61.
07 March 2011	2	New chapter "Customer Support".
06 June 2011	3	Entry for FSUP.

General Topics

Hardware Requirements

Please note that R&S FS-K73 requires option R&S FSP-B15 in order to run on an R&S FSP.

If the required hardware option is not installed the unit will not accept the license key for the corresponding application firmware.

Additionally please note that FRAME based analysis with R&S FS-K73 on an R&S FSP is only possible if R&S FSP-B70 is installed; otherwise only SLOT based analysis will be available on the R&S FSP.

Compatibility of the R&S FS-K73 3G FDD UE Application Firmware

The following table shows the compatible versions of the basic analyzer firmware and the 3G FDD UE Application Firmware:

Table of compatible versions:

R&S FS-K73 Application Firmware	R&S FSP Basic Firmware	R&S FSU Basic Firmware	R&S FSQ Basic Firmware	R&S FSMR Basic Firmware	R&S FSUP Basic Firmware	R&S FMU Basic Firmware	R&S FSG Basic Firmware
4.61	-	4.61 SP1	4.65 SP1	-	Please refer to the FSUP release notes	-	4.69 SP1
4.60	-	4.61	4.65	-		-	4.69
4.50 SP1	4.50	4.51	4.55 SP2	-		-	4.59 SP1
4.50	-	-	4.55	-		-	4.59
4.40 SP1	-	-	-	-		-	-
4.40	4.40	4.41	4.45	-		-	4.49
4.30	4.30	4.31	4.35	4.36		4.38	4.39
4.20 SP1	4.20	4.21	4.25	4.26		-	4.29
4.20	4.20	4.21	4.25	-		-	4.29
4.17	-	-	-	-		-	-
4.10	4.10	4.11	4.15	4.16		-	-
4.01	-	-	-	-		4.08	-
4.00	4.00	4.01	4.05	4.06		-	-
3.90 SP1	3.90	3.91	3.95	3.96		-	-
3.90	3.90	3.91	3.95	3.96		-	-
3.80	3.80	3.81	3.85	3.86		-	-
3.70	3.70	3.71	3.75	-		-	-
3.60 SP1	3.60	3.61	3.65	3.66 SP1		-	-
3.60	3.60	3.61	3.65	-		-	-
3.50	3.50	3.51	3.55	-		-	-
3.40	3.40	3.41	3.45	-		-	-
3.35	-	-	3.35	-		-	-
3.30	3.30	3.31	-	-		-	-
3.28	3.20	3.21	3.25	-		-	-
3.24	3.10	3.11	3.15	-		-	-
3.20	3.00	-	3.05	-		-	-
2.80	2.80	2.81	-	-		-	-
2.60	2.60	2.61	-	-		-	-
2.40	2.40	2.41	2.45	-		-	-
2.35	-	-	2.35	-		-	-
2.30	2.30	2.31	-	-		-	-
2.28	2.20	2.21	2.25	-		-	-
2.24	2.10	2.11	2.15	-		-	-
1.21	-	-	2.05	-		-	-
1.20	1.80	1.81	1.85	-		-	-

Application firmware versions 3.xx/4.xx running on FSPs with order # 1164.4391.xx or FSU with order # 1166.1660.xx are adequate to version 2.xx for FSPs with order # 1093.4495.xx or FSU with order # 1129.9003.xx. (Version 3.20 is adequate to 1.20)

On the FSQ application firmware versions 3.xx requires the Windows-XP upgrade kit FSQ-U2, order # 1162.9696.02.

Note:

Applications with version number 3.xx are only compatible with basic firmware 3.yy (see table above). Do not install them on basic firmware versions below 3.00!

Firmware Update of the R&S FS-K73 3G FDD UE Application Firmware

Since basic firmware version 4.2x a ZIP file with the update sets of the basic system firmware and all available applications is provided. This ZIP file is available in the instruments FIRMWARE section, e.g. R&S FSU of the Service Board on GLORIS.

Please follow the steps described in the instrument's basic firmware release note to perform a complete firmware update.

Enabling the Application Firmware via License Key Code Entry

This section can be skipped if the option key was entered once.

After installing the application firmware package a license key for validation must be entered. The license key is printed either on a label on the rear panel of the instrument or delivered as a part of the R&S FS-K73 3G FDD UE application firmware package.

The key sequence for entering the license key is:

SETUP - GENERAL SETUP – OPTIONS - INSTALL OPTION

Use the numeric keypad to input the license key number and press ENTER.

- On a successful validation the message 'option key valid' will appear.
- If the validation failed, the application firmware is not installed.
 - The most probable reason will be that the instrument is not equipped with the correct basic firmware version. Therefore a message box will appear asking for installation of the correct basic firmware version.
 - If the application firmware package was not installed prior to entering the license key code, a message will appear asking for installation of the application firmware package.
 - In any case please make sure that the correct basic firmware version and the application firmware package is installed prior to entering the license key code.**

New Functions in Version V4.61

None

Improvements with Version V4.61

1. [V4.60] Improved consistency check of remote channel table definition.
2. [V4.60] Higher reference level offsets influenced the EVM results. This issue is solved now.

Modified Functions

The version numbers in brackets indicate the version in which the function was modified.

1. [V1.12] New result display type Power vs. Symbol
2. [V3.24/V2.24] Code Domain Error Power measurement is now available
3. [V3.24/V2.24] Improved Resolution of Trigger to Frame measurement
4. [V3.24/V2.24] Improved absolute accuracy of Trigger to Frame measurement
5. [V3.24/V2.24] Trace statistic available on result summary parameters (MIN Hold, MAX Hold, Averaging)
6. [V3.28/V2.28] Unit circle display in constellation diagrams
7. [V3.28] Option FS-K9 power sensor support for RF measurements
8. [V3.30/V2.30] Multi-Frame Measurement supported
9. [V3.30/V2.30] Read out of spectrum emission mask worst fail position
10. [V3.35/V2.35] Detecting of incorrect pilot symbols of the DPCCH
11. [V3.40/V2.40] Detection of HS-DPCCH in HSDPA signal (TM5)
12. [V3.40/V2.40] Remote readout of frame bit-stream available
13. [V3.50/V2.60] Full Support of Uplink HSDPA signals (TM5)
14. [V3.50/V2.60] Eliminate 25us of each slot for EVM calculation:
According to 3GPP specification Release 5 the measurement interval for error vector magnitude (EVM) is one slot (4096 chips) less 25 μ s at each end of the burst (3904 chips). This requirement depends on the expected power changes of the channel. The consideration of eliminating the tail of a slot can be switched ON or OFF.
15. [V3.50/V2.60] Absolute and relative slot power display for Power vs Slot
16. [V3.50/V2.60] Disable/Enable root raised cosine (RRC) receiver filter
17. [V3.50/V2.60] Extended trigger range:
In external trigger mode, the trigger event is expected in a time range of a half slot (333us) before and a half slot (-333us) after the start of the frame
18. [V3.60/V2.60] Display of frequency error versus slot, phase discontinuity versus slot, symbol magnitude error, symbol phase error
19. [V3.60/V2.60] Result Summary: added value RHO and timing offset
20. [V3.60/V2.60] Scrambling code input in hexadecimal and in decimal format
21. [V3.60/V2.60] HSDPA mode channel detection can be switched ON or OFF
22. [V3.60/V2.60] SEM: Adjustable transition frequency (30 kHz/1 MHz RBW)

- 23. [V3.60/V2.60] External trigger level adjustable from 0.5 to 3.5
- 24. [V3.60/V2.60] Carrier frequency step size softkey available
- 25. [V3.70] Remote command to read out total power versus slot
- 26. [V3.70] ACP/MCACP: number of adjacent channels increased to 12
- 27. [V3.70] ACP/MCACP: power mode to max hold the power results
- 28. [V3.80/V2.80] Support of enhanced channels (HSUPA)
- 29. [V3.80/V2.80] Trace view available within code domain analyzer
- 30. [V4.00] Vector error of Error Vector Magnitude (EVM) versus chip, Magnitude error of Error Vector Magnitude (EVM) versus chip, Phase error of Error Vector Magnitude (EVM) versus chip, Composite constellation diagram of scrambled chip buffer available
- 31. [V4.00] Spectrum emission mask: List evaluation in lower screen now supported
- 32. [V4.00SP1] Error Vector Magnitude (EVM) versus chip for composite signal
In the vector error, magnitude error and phase error display the averaging interval for RMS values is shown.
- 33. [V4.00SP1] Automatic determination of the measurement interval for EVM (RMS) versus slot measurement according to 3GPP specification 34.121.
- 34. [V4.10] New remote command CALC:MARK:FUNC:WCDP:RES? MTYPE | AChannels
- 35. [V4.20] Support for instrument R&S FSG.
- 36. [V4.20] Soft key REF VALUE Y AXIS available for CDP measurements.
- 37. [V4.30] Support for variable length of analysis (variable time slot length 1280 / 2560 chips) according to 3GPP specification.
A new Half Slot mode is available for all graphical displays.
Hint: The command SENSE:CDPower:ETCHips ON | OFF is no longer supported.
- 38. [V4.30] New remote command CALC:MARK:FUNC:WCDP:RES? MPIC returns the average power of the inactive codes for the selected slot.
- 39. [V4.40] Result Summary: added value RCDE and Average RCDE
- 40. [V4.40] New remote command CALC:MARK:FUNC:WCDP:RES? MTYPE | AChannels RCD | ARCD
- 41. [V4.40] Support for HSPA+ with new key code K73+

Modifications to the Operating Manual

The R&S FS-K73 3G FDD UE analyzer functions are included in a separate manual set. Please refer to the following order numbers:

- 1154.7275.42-05 (English)
- 1154.7275.44-05 (German)

Modified Chapters for manual operation

None.

Modified Chapters for remote operation

None.

Customer Support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz equipment, contact one of our Customer Support Centers. A team of highly qualified engineers provides telephone support and will work with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz equipment.

Up-to-date information and upgrades

To keep your instrument up-to-date and to be informed about new application notes related to your instrument, please send an e-mail to the Customer Support Center stating your instrument and your wish.

We will take care that you will get the right information.

Europe, Africa, Middle East

Phone +49 89 4129 12345
customersupport@rohde-schwarz.com

North America

Phone 1-888-TEST-RSA (1-888-837-8772)
customer.support@rsa.rohde-schwarz.com

Latin America

Phone +1-410-910-7988
customersupport.la@rohde-schwarz.com

Asia/Pacific

Phone +65 65 13 04 88
customersupport.asia@rohde-schwarz.com